




Sunny Island 4500

**Bi-directional Battery Inverter SI4500
for Stand-alone Applications**



Installation & Operating Instructions

Sunny Island

Installation & Operating Instructions

Version 3.1

Bi-directional Battery Inverter SI4500 for Stand-alone Applications

Alteration Review

Document number BWRI45	Issue and type of alteration ¹⁾		Comments	Author
-13:EE5103	3.0	A,C	Compilation and enhancement of SI3300 documentation for SI4500	Sabban
-13:EE0304	3.1	A	Minor changes of layout	Salisbury

¹⁾ A: Changes due to faulty documents or improvement of the documentation

B: Changes maintaining full or upward compatibility

C: Changes limiting or excluding compatibility

Explanation of Symbols used in this Document

To enable optimal usage of this manual and safe operation of the device during installation, operation and maintenance routines, please note the following description of symbols:



This indicates a feature that is important either for optimal and comfortable usage or optimal operation of the system.

Example: "To keep string voltage low we recommend the following procedure."



This indicates a fact or feature which is very important for the safety of the user and / or which can cause a serious defect if not applied appropriately.

Example: "Disconnect the mains plug before opening the case!"



This indicates an example.

Contents

1	Introduction	10
1.1	About these instructions	12
1.2	What to do in case of transport damages?	12
1.3	General Safety Instructions	13
2	Device Description	14
2.1	Operating Modes	15
2.1.1	Grid-Forming Operation (RUN_U)	16
2.1.2	Grid-Tied Operation (RUN_I)	18
2.1.3	Droop-mode operation (RUN_U, RUN_UEXT)	19
2.1.4	Overload Behavior	21
2.2	Battery Management	23
2.2.1	Charging Methods	24
2.2.2	Battery States	26
2.2.3	Low Battery Load Mode	29
2.2.4	Failure of Individual Cells	30
3	Installation	31
3.1	Mounting Accessories Included in Delivery	31
3.2	Placement of the Sunny Island	33
3.3	Electric Connection	38
3.3.1	Preparing the Connection	38
3.3.2	Cable Connections	40
3.4	Examples for Connection	43
3.4.1	Connection to Ground	43
3.4.2	Connection of the battery	45
3.4.3	Connection of Battery Temperature Sensor	47

3.4.4	Connection to AC Voltage	48
3.4.5	Connection measure Generator / Mains Current and Voltage	49
3.4.6	Connection of a Generator	51
3.4.7	Connection to an External Utility	53
3.4.8	Connection to Generator and Utility	56
3.4.9	Connection of a Battery Room Fan and Electrolyte Pump	58
3.4.10	Connection of a Dump Load	60
3.4.11	Connection to “ecopower-Mini-BHKW”	61
3.4.12	Connection to “ecopower-Mini-BHKW” and utility	62
3.5	Finalization of Electrical Wiring	63
3.6	Interfaces for Communication	64
3.6.1	Assignment of COM1 Interface (Three-Phase Operation)	65
3.6.2	Assignment of COM2 Interface	66
3.7	Connection with Sunny Boy and Sunny Boy Control	67
3.7.1	Simple Connection at COM2 Interface	67
3.7.2	Multiple Connection at COM2 Interface	69
3.7.3	Simple Connection to PC	71
3.7.4	Alternative Communication at COM1 Interface	72
3.7.5	Assignment of COM3 Interface	73
3.8	Communication in a Three-Phase Island Grid	74
4	Operating Instructions	75
4.1	Display and Operating Elements	75
4.1.1	Key Assignment	76
4.1.2	Contrast in Display	77
4.1.3	Return to Status Display	77
4.1.4	Edit Mode	78
4.2	Menu Structure	78

5	First Commissioning of the Sunny Island	81
6	Configuration	84
6.1	First Configuration.....	85
6.1.1	“Master” or Single Sunny Island (“New Sys MASTER”)	85
6.1.2	“Slave” Sunny Island (“New Sys SLAVE”).....	92
6.2	Configuration after Battery Exchange (“New Battery”).....	95
6.3	Configuration after Restart (“Restart”).....	98
7	Operation (OPERAT).....	99
7.1	Menu “START” (2-1), Operation of the Sunny Island.....	100
7.2	Menu “GENSET” (2-2), Operation of Generator	101
7.3	Menu “FUNCT“ (2+3), Special Functions.....	104
7.4	Menu „BHKW“ (2+5), ecopower support.....	105
8	Settings (SETUP)	107
8.1	Menu “SETTIM“ (3-1), Setting the System Clock.....	108
8.2	Menu “PASSWD“ (3-2), Entry of Password	109
8.3	Menu “PARSYS“ (3+3), Parameters System	110
8.4	Menu “PARGRD“ (3+4), Parameters Grid	112
8.5	Menu “PARBAT“ (3+5), Parameters Battery	114
8.6	Menu “PARGEN“ (3+6), Parameters Generator	117
8.7	Menu “PARREL“ (3+7), Parameters Relays	121
8.8	Menu “PARSB“ (3+8), Parameters Sunny Boy	128
8.9	Menu “PARALL“ (3+9), all Parameters	130
9	Operating Data (DATA)	131
9.1	Menu „DATAV“ (1-0), Overview of Measured Values	133
9.2	Menu “DATSYS“ (1-1), System Data	134
9.3	Menu “DATALL“ (1-2), Overall Plant Data	134
9.4	Menu “DATBAT“ (1+3), Battery Data	136

9.5	Menu “DATGRD“ (1+4), Grid Data.....	138
10	Diagnosis (DIAG).....	140
10.1	Menu “ACKN“ (4-1), Error Confirmation.....	142
10.2	Menu “HISTOR“ (4-2), Overall Protocol.....	142
10.3	Menu “ERRHIS“ (4-3), Error Protocol	143
10.4	Menu “EVTHIS“ (4-4), State Protocol.....	143
11	Island Grids – Examples.....	144
11.1	Photovoltaically powered Island Grid	145
11.2	Photovoltaically powered Island Grid with Generator	150
11.3	Mains Backup System with Photovoltaics.....	154
11.4	Mains Backup System with Generator and PV	157
11.5	Integrating CHP-Units	161
11.6	Multiple Sunny Island Systems (w/ Data interchange).....	165
11.6.1	Single-Phase System.....	165
11.6.2	Three-Phase System	169
11.7	Multiple Sunny Island Systems (w/o Data interchange).....	172
11.7.1	Single-Phase System.....	173
11.7.2	Three-Phase System	173
11.7.3	Mixed Single/Three-Phase Systems.....	174
12	Terminal Diagrams for Generator Options	175
12.1	Stationary Generators	175
12.2	Temporarily connected Generators.....	179
12.3	“ecopower Mini-BHKW”, CHP-units	181
13	Technical Data.....	182
14	Servicing and Maintenance	185
15	Warranty and Liability Regulations	188
16	Parameters (Overview).....	190

17	Measured Values Displayed (Overview)	211
18	Error and Status Signals.....	217
18.1	Error Signals	217
18.2	Status Signals (“Events“)	219
19	Declaration of Conformity	222
20	Contact	223
21	List of Figures	224
22	List of Tables	228

Important Safety Notice:



The Sunny Island inverter may only be opened, installed and serviced by qualified personnel. The device can still be charged with very high hazardous voltages even when disconnected. Please closely follow all steps as described in this document when working on the inverter. All safety instructions and all appropriate technical and local regulations must be followed.

1 Introduction

By purchasing a Sunny Island you have decided to use one of the most advanced modular battery inverters.

The Sunny Island works as

- a **high-quality sine wave AC source** for 230 V, 50 or 60 Hz island grids with sophisticated overload behavior
- a **high-class battery charger** that assures a maximum lifetime of the connected lead storage battery by using highly sophisticated charging algorithms and providing external signals in order to activate electrolyte pumps and even battery room fans
- a controller providing a **high level energy management**, including loadmanagement and interaction with power sources like generators or photovoltaic inverters
- a **universal generator management system**, with capability to start, pre-heat, cool down etc. combustion engines and even to control dedicated CHPs (Combined Heat and Power units)
- a **modularly expandable unit** that can be combined with other Sunny Islands for higher power demands or for three-phase systems

Furthermore it provides a large number of valuable features like system data monitoring, time dependent switching operations etc. and complies with the according European standards on EMC as certified in the CE declaration (see Chapter 19).

In the following you will find the installation and operating instructions of the Sunny Island¹ battery inverter. Don't worry about the size of the document, it is not necessary to read everything at once. However, the general safety instructions described in Chapter 1.3 have to be observed at any rate.

This is both installer's guide and user manual, so it is used as reference for the commissioning and as guideline on how to use all functions of the inverter optimally.

¹ Sunny, Sunny Family, Sunny Island and Sunny Boy are registered trademarks of SMA Regelsysteme GmbH, Germany.

All other trademarks used in this documentation are the property of their respective owners and are used herein for identification purposes only.

1.1 About these instructions

This document contains important information for the installation and commissioning of the Sunny Island as well as its safe operation. Please read these instructions carefully before starting the inverter. The inverter must be installed and commissioned by qualified personnel. Work must be carried out according to the local installation and safety regulations. Please also refer to our warranty and liability terms at the end of this document. This version of Installation and Operating Instructions considers the features for the Sunny Island SI4500 with firmware BFR 2.00 / DSP 2.00, and higher.

1.2 What to do in case of transport damages?

Our products are thoroughly checked before they are shipped. Even though they are delivered in sturdy packaging (which can be recycled) the inverters can be damaged in transit which is usually the forwarder's fault.

Please inspect your inverter thoroughly after it has been delivered. If any damages can be detected on the packaging that could make you conclude the contents is damaged or if you detect any damage please immediately notify the forwarding company.

SMA or your local supplier can help you in this matter. In any case a declaration of transport damage must be made within six days upon receipt of the product and must be stated in writing directly to the forwarding agent.

1.3 General Safety Instructions



The Sunny Island is only suitable for installation in closed rooms. Therefore do not expose it to humidity, rain or direct sunlight.

The inverter is designed for use in places up to 2000 m (6561 ft) above sea-level.

Make sure there is sufficient air circulation in the battery room. Batteries can develop an explosive atmospheres in normal operation.

Use specialized tools when mounting and wiring the storage battery (risk of short circuit).

As a precaution against injuries wear suitable clothes for handling heavy and bulky devices when mounting and removing the Sunny Island (such as working gloves and safety shoes).

The device may only be opened, installed and serviced by a qualified electrician. Even when disconnected there can be high touch voltages within the device. Please see our detailed description of how to handle the Sunny Island and closely follow all instructions!

Under certain circumstances the Sunny Island may start up autonomously! Keep this in mind when working on the island grid and always switch off the AC fuses of all Sunny Islands in the island grid!

2 Device Description

As the central component of a modular power supply system the Sunny Island will not only convert the energy to supply various kinds of electrical consumers or to charge its batteries but also allow to connect the SMA Sunny Boy® String Inverters for supplementary grid feeding. Furthermore, small wind energy converters or generator sets and even Combined Heat and Power units (CHPs) are also supported.

To fulfill its tasks the Sunny Island can work in different operating modes. A short overview is given in Chapter 2.1.

An outstanding feature of the Sunny Island is its capability to take care of the connected lead storage battery. Highly sophisticated charging algorithms assure a maximum lifetime of the battery. A quick abstract of the battery management is given in Chapter 2.2.

Although the first commissioning of stand alone systems using the Sunny Island can be kept very simple, it is just as well possible to fine-tune the system by a vast number of parameters (see Chapter 16) giving the users complete satisfaction.

Moreover, using this system-compatible battery inverter lets the planner / installer reduce planning, execution and system costs for PV island supply considerably.

2.1 Operating Modes

The Sunny Island can be modularly combined with other power sources and must then operate in different operating modes. Depending on the system's structure, the Sunny Island can be configured to toggle automatically between these operating modes. This chapter covers both basic grid configurations and the resulting requirements for the Sunny Island and the other components in the island grid.

Control of voltage and frequency in the island grid

Operation of the Sunny Island is based on the following operating modes:

- Grid forming (RUN_U), the Sunny Island keeps the voltage and the frequency of the grid at a constant level.
- Grid-tied (RUN_I), the Sunny Island complies with the voltage and frequency that is defined by an additional component of the island grid that itself forms the grid.
- Droop-mode (special kind of RUN_U), the Sunny Island varies its battery current depending on the grid's frequency, and the grid's voltage depending on its current reactive power. It also tries to affect the grid's frequency according to its battery state. In case of being synchronized to a generator, the status "RUN_UEXT" is shown in the display.

2.1.1 Grid-Forming Operation (RUN_U)

In grid-forming mode the Sunny Island keeps the grid voltage at a constant sine-wave voltage and constant frequency. The voltage and frequency is defined in the “PARGRD” 3+4 menu. The Sunny Island then has to provide the necessary active and reactive power that is required for the control of the grid. All other components in the grid then have to operate as grid-controlled power generators or consumers.




Fig. 2.1: Sunny Island as grid-forming element

This operating mode requires that there are no further components within the grid that control the frequency or the voltage. Parallel operation with the public utility or an independent synchronous generator is not possible in this mode.

In this mode the Sunny Island can only charge the batteries whenever the components within the grid (Sunny Boy inverters, synchronous generators) generate more power than required. In case that these components generate less power than consumed within the grid the Sunny Island supplies power to the grid by discharging the batteries.

The state of charge of the batteries can therefore only be manipulated by controlling the power generating components and the consumers within the grid.

Due to the battery management, the Sunny Island can perform a full charge of high quality even in this operating mode. This might take several days, if necessary (for example if there are only photovoltaic feeders).

2.1.2 Grid-Tied Operation (RUN_I)

In grid-tied operation the Sunny Island follows the voltage and frequency defined by an external power source. This can be an independent synchronous generator or the public utility. In this case, the Sunny Island does not control the grid voltage and grid frequency but controls the current it draws from the grid to charge the battery in a defined and most suitable manner.




Fig. 2.2: Sunny Island with external grid-former

2.1.3 Droop-mode operation (RUN_U, RUN_UEXT)

The droop mode allows to connect several Sunny Islands (each provided with its own battery) in parallel, even though each Sunny Island will act as a grid-forming device. Such a system will behave in many respects similarly to the large public electric utility:




Fig. 2.3: Frequency vs. load characteristics

If the available power on the AC bus of the system is higher than the power demanded, all Sunny Islands will charge their batteries and let the AC frequency slightly rise, analog to the amount of energy stored in their batteries.

If the available power is less than the power demanded, the missing amount will be fed into the AC bus by the Sunny Islands, slightly reducing the AC frequency.




Fig. 2.4: Voltage vs. reactive power characteristics

Furthermore, the Sunny Island will respond to voltage fluctuations with reactive current in droop mode. Thus, only an average $\cos \varphi$ of 1 will be reached. Temporarily, it will deviate from this value.

In such systems further grid-forming elements (e.g. gensets) can only then be connected if these are capable of automatically synchronizing themselves to the grid and have a droop characteristic. However, for some common system structures the Sunny Island provides functions to synchronize the system to the genset, even in droop mode.

2.1.4 Overload Behavior

One major feature of an island inverter is the performance in terms of overload. While the consumers within the island grid will require an uninterrupted and continuous power supply, the plant operators will want a long-term reliability and operation of the inverter and the batteries as well. The manufacturer of the island inverter must take into account fundamental aspects in terms of safety in order to provide maximum safety for the personnel and the connected components.

Another reason for the careful observation of the overload performance is the connection or activation of “problematic loads“. These are consumers that extract a very high amount of power from the grid when they are activated. This power can be very much higher than the nominal power, e. g. even simple halogen lamps extract the fifteen-fold nominal power, when they are turned on.

These consumers do not continuously require this high power. Therefore, the Sunny Island does not have to be capable of generating this power. What is more important is a sophisticated control strategy. When such loads are connected, the Sunny Island therefore reduces the AC voltage for a short time. This not only reduces the current peaks on the AC side, but also those on the DC side – thus preserving the battery power and prolonging the battery’s service life.

The overload capacity of the Sunny Island depends on all these requirements and takes place in three stages:

In case that a short circuit is detected on the AC side, the output current is limited to approx. $70 A_{eff}$. If the short circuit persists for more than approx. 5 seconds, the Sunny Island 4500 switches off with an error message. This is enough in order to trigger automatic circuit-breakers with A or R characteristics, respectively.

In case of a high overload, this is not yet detected as short circuit, the output active power of the Sunny Island is limited by voltage decrease. Thus, the DC input current

does not exceed approx. 125 A. The active power available at the output port therefore depends on the current battery voltage and is $P = U_{\text{Bat}} \times I_{\text{Bat}} \times \eta$.

This means, in case of battery voltage of 60 V it is approx. 7000 W. In case that the load does not fall below this limit after a time of approx. 5 seconds, the Sunny Island switches off with an error message. But all "problematic loads" should be able to startup with this power.

In the overload area up to the limit mentioned above, the Sunny Island thermally limits the power. This means, that the device – depending on the ambient temperature, previous load and level of overload – can provide the power for several minutes or even hours, before the device is derated or switched off. Another limiting element is the DC-breaker F1 that might trip, also depending on the ambient temperature, previous load and level of overload.



However, even in the case, that permanently low ambient temperatures are assumed, a plant should never be designed in a way that the Sunny Island 4500 is continuously operated in overload operation. Otherwise, a reduction of the durability of the device cannot be excluded.

2.2 Battery Management

The battery management monitors the limit values for current, voltage and temperature, calculates the current state of charge and battery state, controls and monitors the charge depending on the previous situations and can control an electrolyte circulation pump as well as a battery room fan.

In order to have always reliable battery-related measured values, the Sunny Island has to be the only device in the system that is connected to the battery directly.



External devices connected to the battery (e. g. DC loads or battery chargers) will lead to a faulty battery management! This will not only result in wrong battery states and associated erroneous switching operations but also in an incorrect estimation of the battery's condition and thus to a significant reduction of the battery's lifetime!



The associated parameters are described in Chapter 8.5.

All settings for the first operation are described in Chapters 6.1.1.

After having exchanged the lead storage battery of the system, restart the Sunny Island(s) and follow the instructions in Chapter 6.2.

2.2.1 Charging Methods

The battery is charged in a charging procedure adjusted to the type of battery (gel, flooded or lead storage battery). The Sunny Island is informed of the battery type via the parameter “502_Bat Type” – e. g. in the menu “PARBAT” (3+5). If you have installed a non VARLA battery with electrolyte circulation, please set the battery type to gel battery as the charging voltages and times are more suitable for this type. The final charge voltage of the battery is adjusted to the respective battery temperature, which in turn has been determined via a battery temperature sensor. Above 20 °C the reference value for the final charge voltage is therefore decreased by 4 mV/K (visible in the menu “PARBAT” (3+5)). Below 20 °C the value is increased accordingly.

The Sunny Island is capable of running four different charging methods. The different voltage values and charging times of those methods are adjusted with temperature compensation to the respective battery type that has been set via parameters. The charging methods have been designated as follows:

- Normal charge (as often as possible)
- Full charge (at least once a month if possible)
- Equalizing charge (every two to three months)
- Float charge (after one of the other charging procedures has been completed)

Charging is initiated by the battery management, i. e. requested from the system management when certain battery states have been reached.




Fig. 2.5: Battery states with charging methods

The specified values are default values for a closed not circulated lead-acid battery.

A normal charge is made when the charging degree has fallen below 70 %. The priority is a short run-time of an additional aggregate (e. g. diesel generator).

By default, a full charge is completed every two weeks or 8 charge throughputs. A full charge leads to complete charging of the battery in order to avoid irreversible aging due to low charge degrees.

An equalizing charge is initiated every 180 days or 30 charge throughputs preventing that the individual cells within the entire battery system over time have charge degrees differing among each other and avoiding aging of individual cells.

The respective charges are switched off according to the criteria for voltage, current and time periods adjusted to the individual battery types.

2.2.2 Battery States

The battery management determines the state of the battery out of a selection of eleven possible battery states. It informs the relay control about the determined battery state. The most dominant input variable which is most important for the calculation of the battery state is the actual state of charge (see Fig. 2.6). This mainly provides information on the availability of the battery. In addition to the state of charge, however, other variables mainly concerning battery aging are also used for calculation. These are e. g. the battery voltage during overcharging or exhaustive discharging, but also the times after a full charge or an equalizing charge has first been requested. The battery state therefore shows that either the availability of the energy stored deteriorates considerably due to the decreasing state of charge or the battery is in an area with increasing aging while its state of charge can still be high.




Fig. 2.6: Battery states, states of charge and suggested switching operations



The battery states do not correspond as directly to the actual state of charge as Fig. 2.6 suggests. Under certain circumstances the battery state will remain stable even though the actual state of charge will vary widely. It might even jump to a non contiguous state.

For example, in a new system the battery state will initially be set to L1 and will not change until a normal charge has been completed. Afterwards it will be set to N1 immediately.

Of course, in such cases all switching operations of the relays will be executed as if the intermediate states were perambulated.

Battery states	Description
L4, L3, L2, L1	Reduced availability of the battery and increased battery aging
N4, N3, N2, N1	Normal working area with varying availability of the battery
O1, O2, O3	Overload

Table 2.1: Classification of battery states

The eleven defined battery states allow the user to make switches according to the battery state. How to define battery state dependent switching operations is shown in Chapter 8.7. The following table provides an overview of the different battery states (BST), their meaning and recommendations for possible switching measures:

BST	Meaning	Recommendations	Possible switching measures
O3	Very high overload	Immediately stop charging	Switch off all feeders via the frequency
O2	High overload	Drastically decrease charging power	Slight increase of frequency to switch off first PV inverters
O1	Overload	Decrease charging power	Switch on dumpload
N1	Very high security of supply	None	Switch off dumpload
N2	High security of supply	Notification of state of charge; if required first reduction of consumers	Switch off first load groups that are not continuously used or reduction of power
N3	Normal security of supply	Either reduce consumption or make sure battery is charged soon	Switch on genset soon or switch off certain load groups
N4	Low security of supply	Either reduce consumption drastically or make sure battery is charged soon	Switch on genset also at night or switch off all load groups that are not urgently required
L1	Increasing aging	Reduce consumption except for emergency supply; initiate charging, alarm message	Switch on genset immediately or switch off all load groups except for emergency supply
L2	Strong aging	Switch off all consumers, initiate charging	Switch on genset immediately or switch off all external load groups. Low battery load mode will automatically be set at night.
L3	Very strong aging	Reduce internal consumption immediately, initiate charging, alarm message via switch-off	Inverter into standby operation. Low battery load mode will automatically be set day and night
L4	Destruction of battery imminent	Immediately reduce internal consumption, initiate charging, alarm message via switch-off	Switch off the inverter Sunny Island will go into standby mode automatically

Table 2.2: Battery states and recommended measures

2.2.3 Low Battery Load Mode

In order to prevent the lead storage battery from getting totally exhausted, the Sunny Island provides three steps of power saving:

Step 1

If the battery state reaches the value defined by parameter “535_State StopT” (default setting: L2) the Sunny Island switches to standby mode in a certain period of time (e. g. during the night) but will still be fully active during the rest of the day. This special time period can be defined with parameters “533_Stdbyt beg” and “534_Stdbyt end” (cf. Fig. 8.14 in Chapter 8.7).

Step 2

In all battery states below the one defined by parameter “535_State StopT” the Sunny Island will be in standby mode day and night, but will run in intervals of four hours for five minutes during daytime in order to allow AC-sources to feed their energy into the grid.

Step 3

If the battery state drops to L4 the Sunny Island will be in standby mode day and night, and will only be activated for five minutes when started manually.

2.2.4 Failure of Individual Cells

If individual cells of the battery fail towards the end of the battery's expected service life, it may be more useful to remove them completely instead of replacing them. Otherwise, the remaining service life of the other cells may be decreased. Any removal of cells, however, must always be advised to the battery management of the Sunny Island by changing the parameter "503_Ubat nom" in the menu "PARBAT" (3+5) accordingly. Of course, in systems with a nominal battery voltage of 48 V this removal of single cells is not possible as 48 V are already the least possible value for the Sunny Island.

The failure of individual cells should always be taken as a clear signal that the whole battery will fail within a short period of time. When installing a new battery via "New Battery" in the "INIT" (0-0) menu make sure to properly reset "503_Ubat nom" to the correct value.

3 Installation



The Sunny Island may only be installed by a qualified technician. Please read the corresponding chapters carefully. All installation work must be executed in compliance with the relevant standards. Please follow the general safety instructions (Chapter 1.3).

3.1 Mounting Accessories Included in Delivery

Please find below the components ensuring easy mounting and installation of the Sunny Island which are included in delivery:

- 1 Installation & Operating Instructions (which you are reading here)
- 1 Bracket for recommended mounting to wall (Fig. 3.1)
- 4 PG 13.5 glands incl. nuts
- 4 PG 13.5 blank screwed joints
- 3 PG 16 glands incl. nuts
- 3 Alkali manganese battery cells
- 1 Plug for battery temperature sensor
- 1 Plug "Generator / Mains I U"

The following components can be delivered as an option for the Sunny Island 4500:

- Pt100 contact sensor to determine the battery temperature (SMA order code “SI-BTS“). It is absolutely necessary to connect a temperature sensor.
- Battery fuse box for the protection of the DC cables (SMA order codes “SI-BATCASE.01” (for connection of a single Sunny Island) and/or “SI-BATCASE.03” (for connection of up to three Sunny Islands).
- Three-phase synchronization cable (connection between the different Sunny Islands in three-phase operation, SMA order code “SI-Synckabel-Set“).
- Plug-in relay to switch loads or start/stop (diesel) generator etc. (SMA order code “SI-BPRE“ (NO-type) resp. “SI-BPRE-OE” (NC-type)).
- 24 V auxiliary supply output port for special plant interconnections (see Chapter 3.4), (SMA order code “SI-BP24“).
- RS485 interface or RS232 interface as Piggy-Back.
- Installation box for simplified connection of a mobile generator (SMA order code “SI-GENCASE.01“).
- Kit for update of the Sunny Island firmware (SMA order code “SI-UPDATE“).

3.2 Placement of the Sunny Island

The Sunny Island is a highly integrated, electronic device which is therefore sensitive to moisture within the enclosure.



The Sunny Island is not suitable for outdoor installation.

For overall planning of your plant it is important to select a favorable location for the inverter/s. The following criteria are meant to help you decide where to position the Sunny Island:

Criteria for placement:

- Installation only possible indoors due to protection degree IP20.
- Do not expose the inverter to direct or indirect humidity.
- Keep cables leading to the battery storage as short as possible (DC cabling).
- Avoid installing in the living area as slight noise emission is possible.
- Avoid mounting on resonant parts and easily combustible materials (e. g. thin wooden panels, plaster panels, etc.)
- Provide accessibility for installation and later service.
- Installation at level height makes it possible to easily view the display and press the keys.

Please note the following points in any case for the installation of the Sunny Island:



- The mounting background must be firm (weight of Sunny Island 4500 approx. 45 kg).
- The ambient temperature must be between -25 °C and +45 °C.
- If the Sunny Island is transferred from a cold to a warm place, wait for a sufficient time (at least 15 minutes) before commissioning so that any moisture condensation that might have occurred can evaporate.
- A minimum clearance of 20 cm must be available above the Sunny Island for ventilation, i.e. no installation in cabinets without ventilation, no installation directly under ceiling, etc.
- The free air circulation around the case must not be obstructed to ensure sufficient cooling.
- If you install the Sunny Island in a cabinet or closet etc., the air circulation must be sufficient for heat dissipation - provide external ventilation.
- The heat sink can reach a temperature of more than 80 °C.
- Provide a correct position of the battery inverter (see Fig. 3.1 and Fig. 3.2).

Mounting on the wall

The Sunny Island is mounted on a mounting bracket on a firm surface. Four screws and the corresponding wall anchors are necessary. The screws and wall anchors are not included in the delivery and have to have a sufficient size. We recommend two 6 mm hexagon head screws and 8 mm wall anchors for fastening (see Fig. 3.1).



Make sure the mounting bracket is securely fastened as it carries the Sunny Islands total weight.

After fastening and checking the secure position of the mounting bracket the Sunny Island is hung into the intended strap on the mounting bracket and positioned with the correct orientation.

To prevent lifting up the Sunny Island is fastened on the wall with two screws (4.5 mm) and the corresponding wall anchors (M6) (see following figure).




Fig. 3.1: Mounting bracket with fastening points




Fig. 3.2: Side view of the Sunny Island with dimensions

3.3 Electric Connection

The electric connection of the Sunny Island can be done once the device is correctly mounted in its position.

The storage battery and the grid (connection to distribution panel) are connected to the lower part of the Sunny Island. At the bottom of the Sunny Island there are seven heavy-gauge conduit-threaded joints (four PG 13.5 and three PG16).

3.3.1 Preparing the Connection

Take off the case lid of the inverter's lower part. To this end remove the two hexagon socket screws (M5) accessible from the front.



Inside the lid there is a tab and receptacle connector with a green-yellow grounding cable (PE). Carefully disconnect this connector. After finishing the installation reconnect it.

Make sure the two automatic circuit breakers F1 and F2 are switched off.

After removing the two fastening screws the lower part of the plastic clamp cover can be removed as well ("lower protective cover").



Always mount this "lower protective cover" again before connecting any power supply units.

You now have the open part of the inverter in front of you and can familiarize yourself with the position of relevant components and clamps.




Fig. 3.3: Cable glands and terminals of the Sunny Island



You will find a diagram with designations of the different terminals inside the lower case lid as well.

3.3.2 Cable Connections

All possibilities to connect the Sunny Island with the island grid are combined on one terminal strip (see Fig. 3.4).

- Terminals for battery temperature sensor (four-wire measurement)
- Storage battery terminal (at F1:+ and F1:- of the automatic circuit breaker on the left). There will be terminal blocks instead, in case the Sunny Island was ordered without DC circuit breakers.
- Terminals for generator start via relay K1
- Terminals for generator contactor via relay K2
- Terminals for grid contactor via relay K3
- Terminals for additional switchable components such as wind energy converters, ohmic/inductive loads (via relays K1 to K8), freely configurable
- Terminals for battery room fan via relay K7
- Terminals for battery acid circulation via relay K8



If the relays K1, K2, K7 and K8 are not used for their special tasks, they can also be freely configured.



The terminals K1 to K8 can only be used if they have been equipped with their respective relays/modules optionally available.

- Terminals for the measurement of generator voltage and current
- Grid connection (at F2:L and F2:N of the automatic circuit breaker as well as at the PE terminals on the right)




Fig. 3.4: Terminal strip of the Sunny Island

Table 3.1 shows the connector assignment on the terminal strip of the Sunny Island:

Designation	Description	Comments
X1:1	Battery temperature sensor	+ RETURN
X1:2		+ SEND
X1:3		- SEND
X1:4		- RETURN
X1:5	Shielding	Possibility to connect shielding of sensor cable
PE	Chassis earth	Connection to ground, 2.5 mm ²
F1: +	Battery input	terminal block / 63 A fuse, 25 mm ²
F1: -		terminal block / 63 A fuse, 25 mm ²
K1:14	Relay K1 (Generator start)	Relay K1, special functions are described in detail in Table 8.5
K1:13		
K2:14	Relay K2 (Generator contactor)	Relay K2, special functions are described in detail in Table 8.5
K2:13		
K3:14	Relay K3 (Mains contactor)	Relay K3, special functions are described in detail in Table 8.5
K3:13		
K4:14	Relay K4 (SI contactor)	Relay K4, special functions are described in detail in Table 8.5
K4:13		
K5:14	Relay K5 (Syncsw. / operate / load)	Relay K5, special functions are described in detail in Table 8.5
K5:13		
K6:14	Relay K6 (Gen. crank / operate / load)	Relay K6, special functions are described in detail in Table 8.5
K6:13		
K7:14	Relay K7 (Battery fan)	Relay K7, special functions are described in detail in Table 8.5
K7:13		
K8:14	Relay K8 (Battery circulation)	Relay K8, special functions are described in detail in Table 8.5
K8:13		
X2:1 / -I	Generator/Mains current input	Generator/Mains current measurement input, via current probe, K
X2:2 / +I		Generator/Mains current measurement input, via current probe, L
X2:3 / L	Generator/Mains sync. input	Generator/Mains voltage measurement input, L
X2:4 / N		Generator/Mains voltage measurement input, N
F2:L	AC outlet	25 A fuse
F2:N		25 A fuse
PE	Chassis earth	Connection to ground 2.5 mm ²
PE	Chassis earth	Connection to ground 10 mm ²
PE	Chassis earth	Connection to ground 10 mm ²

Table 3.1: Description of terminal strip

3.4 Examples for Connection

In the following chapters you can read about the possibilities how to connect the inverter to its environment. Examples for the different connection types are provided.



How to wire the components and the Sunny Island for protective grounding depends on the type of grid installed and can therefore differ. Therefore, the figures below do not show any PE-wiring / grounding. Of course, the entire cabling must be installed in compliance with all relevant standards and regulations.



Furthermore, to allow different kinds of grounding concepts the Sunny Island's N-terminal is NOT connected to PE by default. Thus, any required connection between N and PE has to be performed externally. Due to EMI-measures the voltage of the AC terminals will be round about symmetrically to PE without any further wiring.

3.4.1 Connection to Ground

Due to filtering measures within the Sunny Island increased leakage currents to PE can occur during operation. Therefore make sure the inverter is firmly grounded according to DIN EN50178.



To this end the inverter can be grounded at the ground terminals in the terminal area either with one single copper conductor of a minimum 10 mm² cross-section or with two separate copper conductors with cross-sections corresponding at least to the respective AC conductor.

If the two ground conductors are not part of the AC connection cable they should have a minimum cross-section of 4 mm² each.

Due to galvanic isolation between the battery and grid side within the Sunny Island it is basically possible – but not necessary – to ground the minus or plus pole of the battery externally. In this case make sure that the very high currents that can occur for a short time in case of an error are discharged as well.

We cannot make general recommendations for the dimensioning of the required grounding cable as this considerably depends on the type of battery used, the external fused interrupter and the design of the incoming cables of the battery.

If an additional grounding cable with a larger cross-section is required this can be connected to the M6 threaded hole (marked as such) on the aluminum backplane (heat sink) of the Sunny Island.



The required cable cross-section of the grounding conductor can be estimated with the following formula for fused interrupters with disconnecting times up to 5 s if a copper cable is used:

$$S = \frac{\sqrt{(I_{sc}^2 \cdot t)}}{143}$$

t = disconnecting time in seconds, I_{sc} = maximum battery current (short-circuit current) in amperes, S = conductor cross-section in mm²

The maximum battery current can be seen in the data sheets for the battery. If this is not possible it can usually be estimated with the following formula:

$$I_{sc} = \frac{C}{0,05h}$$

C = battery capacity in Ah

For an exact determination of the grounding conductor cross-section please refer to the relevant standards (e. g. VDE 0100 part 540).

3.4.2 Connection of the battery

On the DC side a suitable storage battery has to be connected according to DIN VDE 0510 (VDE specification for electric storage batteries and battery plants).



Make sure that the cable to the storage battery has a sufficient cross-section. Pay attention to the correct polarity of the connection to the storage battery.

If the battery is to be grounded please follow the special instructions in Chapter 3.4.1.

We urgently recommend a fused interrupter to disconnect the Sunny Island. If there is no line protection (fuse) the installation of DC cables has to be inherently ground-fault-proof and short-circuit-proof. The internal DC fuses of the Sunny Island are designed for interrupting currents of up to 20 kA (for $\frac{R}{L} < 0,015 \text{ s}$).

If your Sunny Island was ordered with terminal blocks instead of circuit breakers on the DC connection, the installation of a fused interrupter is mandatory! See detailed information below.

The relevant regulations for installation have to be followed.




Fig. 3.5: Connection of battery to the Sunny Island



Never remove the battery cable during operation. Always switch the inverter off first.

The battery cables should be as short as possible. Long cables reduce efficiency as well as the tolerable overload and have effect on the battery management.

In order to obtain always reliable battery-related measured values the Sunny Island has to be the only device in the system that is connected to the battery directly.



External devices connected to the battery (e. g. DC loads or battery chargers) will cause the Sunny Island's battery management to fail!

If the Sunny Island was ordered with terminal blocks instead of circuit breakers on the DC connection, it has to be assured that currents are limited to a certain value and time in case of failure. This is possible by installing a separate double pole circuit breaker (63 A, B-characteristic or similar) between the battery and each Sunny Island.

3.4.3 Connection of Battery Temperature Sensor

A PT 100 sensor with four-wire technology is required to measure the battery temperature. The sensor is connected to the inverter at the terminals X1:1-X1:4 (Fig. 3.6).

If the temperature sensor is to be connected with a shielded cable, connect the shielding to terminal X1:5. This terminal is connected to the case and thus to the PE connections of the inverter. Therefore make absolutely sure to avoid creating any electric bond by attaching the temperature sensor to the battery.




Fig. 3.6: Connection of a temperature sensor



To protect the battery always connect a battery temperature sensor (the Sunny Island displays a failure if no sensor is installed).

In configurations with more than one Sunny Island per battery only the master Sunny Island needs to be equipped with a battery temperature sensor.

3.4.4 Connection to AC Voltage

On the power side the AC voltage is connected to the automatic circuit breaker F2. If there is only one electric circuit this can be directly supplied by the Sunny Island. If there are additional devices feeding the grid, such as wind generators, separate circuits and thus an external distribution is recommended.




Fig. 3.7: AC voltage connection

Fig. 3.7 shows an exemplary layout of a sub-distribution if additional electric circuits and grid-feeding devices are integrated into the system.



To allow different kinds of grounding concepts, the Sunny Island's N-terminal is NOT connected to PE by default. Thus, any required connection between N and PE has to be performed externally. Due to EMI-measures, the voltage of the AC terminals will be round about symmetrically to PE without any further wiring.

3.4.5 Connection measure Generator / Mains Current and Voltage

If a generator (diesel, gas) is integrated into the island grid the diesel voltage must be measured via the input “Generator / Mains sync. input” of the Sunny Island.

Most integrated generator-monitoring and -control features are not available until also the generator current is fed to the Sunny Island via a current transformer. The measurement is connected as shown in Fig. 3.8.




Fig. 3.8: Connection of generator current and voltage measurement

1) Fuses for the protection of the generator voltage sensor cables, 2) Current transformer



Ensure sufficient fusing of the generator voltage sensor cables. The cross-section of the cable leading from the current converter to the inverter should be large enough to keep losses low (see also Fig. 3.9).

If the measuring circuit of the inverter is opened during operation this can lead to overvoltages and destruction of the current converter. The measuring circuit has therefore to be short-circuited at the current converter.




Fig. 3.9: Power loss due to the secondary circuit to the inverter



Basically the output of the current transformer connected to the Sunny Island's generator / mains current input is supposed to be electrically floating.

The terminal X2:1 is connected internally to the Sunny Island's enclosure. Thus, the current transformer will be grounded functionally anyway. If - for a grounding in terms of protective earthing - an additional wire of an appropriate cross section is necessary, it should connect the terminal X2:1 to one of the Sunny Island's PE terminals and should be as short as possible.

3.4.6 Connection of a Generator

If e. g. a diesel generator is integrated into the island grid, not only the measurement signals listed in Chapter 3.3, but also the control signals “Generator start” and “Generator contactor” have to be wired as shown in Fig. 3.10.

The generator is switched on with the relay “Generator start” (K1). When it has started up the Sunny Island goes idle (short interruption) and connects the generator’s voltage to the island grid by switching the relay “Generator contactor” (K2). Afterwards the Sunny Island changes to grid tied operation (“RUN_I”).




Fig. 3.10: Connection of a (diesel) generator

Three common options to start diesel generators are described in Chapter 12.

In most switch-over situations the period of time for „short interruptions“ can be eliminated by means of a slightly more complicated cabling (Fig. 3.11). Naturally, this time cannot be reduced in case of a shutdown of the generator – unpredictable for the Sunny Island - (manual deactivation, failure due to fuel deficiency, or similar).




Fig. 3.11: Example of connection for an accelerated switch-over (generator)

* This relay shall not overcharge the 24 V auxiliary supply output (SMA order code "SI-BP24")! A relay complying with the requirements is available with the SMA order code "SI-BPRETR".

3.4.7 Connection to an External Utility



Such a plant option requires a very careful design and installation in order to prevent accidents based on the assumption that the plant is deenergized as it is disconnected from the utility!

In several operating modes energy feeding into the external utility is possible via the Sunny Island!

The illustrated interconnection plans show the grid connection only in principle. In any case, the local applicable regulations have to be complied with and the approval of the public utility company is mandatory!

If the public mains supply often fails, an island utility can be desirable. In this case the Sunny Island will normally charge the battery during supplementary grid feeding from the external utility. In case of mains failure the plant must be disconnected from the external utility and the Sunny Island must provide the 230 V island grid in grid-forming operation. After the external utility has recovered, the Sunny Island needs to detect this voltage and the switch-over to island operation mode has to be reversed.

The necessary wiring is shown in Fig. 3.12. The voltage sensor cables that also have to be connected with the voltage measurement input port “Generator / Mains sync input” – just like in the case of the connection of a generator (see Chapter 3.4.5 and Chapter 3.4.6) – are not shown.




Fig. 3.12: Connection to an external utility

The switch-over times can also be eliminated by means of a more complicated wiring for the connection to the recovered external utility (Fig. 3.13). Of course, the Sunny Island can by no means forecast a failure of the external utility. Thus, it is in principle not possible to reduce this time during the switch-over to island operation mode.



In this configuration the “external distribution” will remain connected to the utility grid even when the Sunny Island is in standby mode.

Fig. 3.13 does not show the necessary wiring of voltage sensor cables either.




Fig. 3.13: Connection for an accelerated switch-over (utility)

* This relay shall not overcharge the 24 V auxiliary supply output (SMA order code "SI-BP24")! A relay complying with the requirements is available with the SMA order code "SI-BPRETR".

3.4.8 Connection to Generator and Utility



Such a plant option requires a very careful design and installation in order to prevent accidents based on the assumption that the plant is deenergized as it is disconnected from the utility!

In several operating modes energy feeding into the external utility is possible via the Sunny Island!

The illustrated interconnection plans show the principle grid connection. In any case, the local applicable regulations have to be complied with and the approval of the public utility company is mandatory!

The connection of the island grid with generator to an external utility is supported by the Sunny Island from Firmware BFR 1.50 and higher. For this purpose a special external interconnection with the voltage measurement is required, as shown in Fig. 3.14.




Fig. 3.14: Connection to generator and utility

* This relay shall not overcharge the 24 V auxiliary supply output (SMA order code "SI-BP24")! A relay complying with the requirements is available with the SMA order code "SI-BPRETR".

The switch-over times can also be eliminated as described in the preceding chapters just by a little more expenditure (Fig. 3.15).



In this configuration the "external distribution" will remain connected to the utility grid even when the Sunny Island is in standby mode.




Fig. 3.15: Example of an accelerated switch-over (generator and utility)

* This relay shall not overcharge the 24 V auxiliary supply output (SMA order code "SI-BP24")! A relay complying with the requirements is available with the SMA order code "SI-BPRETR".

3.4.9 Connection of a Battery Room Fan and Electrolyte Pump

If lead storage battery arrays with liquid electrolytes are used as energy stores, the control of an electrolyte circulation pump is to be connected via the relay terminal K7. A battery room fan can be controlled via the relay terminal K8. Switch-on and switch-off criteria can be defined via the menu of the Sunny Island. For wiring see Fig. 3.16.



The switched current of the relays K7 and K8 is a maximum of 5 A at 230 V AC. A detailed limit curve is shown in Chapter 13.




Fig. 3.16: Connection of a battery room fan and electrolyte pump

3.4.10 Connection of a Dump Load

If there is a surplus of energy in the island grid which is not utilized, but cannot be stored either because the batteries are fully charged, it makes sense to connect an additional consumer (dump load). It is connected to one of the relays not yet used otherwise (K1 to K8) as shown in Fig. 3.17.



The switched current of the relays K1 to K8 is a maximum of 5 A at 230 V AC. A detailed limit curve is shown in Chapter 13.




Fig. 3.17: Connection of an additional load (“dump load“)

3.4.11 Connection to “ecopower-Mini-BHKW”

The Sunny Island is capable of controlling an “ecopower Mini-BHKW”-CHP unit via its communication port COM3. To this extend the interconnection between the Sunny Island and the CHP unit has to be performed as shown in Fig. 3.18. A three-wire RS232 null-modem style communication (RxD, TxD, GND) is sufficient.

In order to afford an optimal charge regulation it has to be assured that sufficient dumploads are installed in the system.



Be sure that the „ecopower Mini-BHKW“’s communication capability is enabled!




Fig. 3.18: Connection to an „ecopower Mini-BHKW“

3.4.12 Connection to “ecopower-Mini-BHKW” and utility



Such a plant option requires a very careful design and installation in order to prevent accidents based on the assumption that the plant is deenergized as it is disconnected from the utility!

In several operating modes energy feeding into the external utility is possible via the Sunny Island!

The illustrated interconnection plans show the principle grid connection. In any case, the local applicable regulations have to be complied with and the approval of the public utility company is mandatory!




Fig. 3.19: Connection to an „ecopower Mini-BHKW“ and utility

3.5 Finalization of Electrical Wiring

Always mount the “lower protective cover” (lower part of plastic terminal cover, see Chapter 3.3.1) with the two corresponding screws after wiring has been completed and before any power supply units are connected!

3.6 Interfaces for Communication

The Sunny Island has three communication interfaces. These interfaces make it extremely easy to configure and operate the Sunny Island.




Fig. 3.20: Interfaces of the Sunny Island

COM1 (SYNC BUS) is an RS485 interface e. g. for data exchange between the system management processors of several Sunny Islands in three-phase operation. A synchronization signal ensures phase synchronization in three-phase operation. This signal is exchanged among the control processors of the individual Sunny Islands. As it is transmitted in one cable together with the RS485 signal, a special cable set (SMA order code “SI-Synckabel-Set“) is required for three-phase operation.

The COM2 interface can be equipped to comply with different electrical standards such as RS232 or RS485 by plugging on a Piggy-Back. Via this interface parameters can be set or modified with a PC or Sunny Boy Control. If Sunny Boy String Inverters are used in the island grid defined power control of the Sunny Boys is possible via this interface as well. This is especially important for optimum battery management (e. g. for full charging, compare Chapter 2.2). With a PC and the software package Sunny Data which is available as an accessory it is possible to diagnose and record data of all SMA components (Sunny Boy and Sunny Island) connected to this interface.

COM3 is an RS232 interface used to control the “ecopower Mini-BHKW” and for different service purposes. A complete software update for the system management processor or the control processor can be made via COM3. In addition to a PC and a null modem cable a software tool available at SMA’s website (<http://www.sma.de>) is required.

3.6.1 Assignment of COM1 Interface (Three-Phase Operation)

In a three-phase island grid the COM1 interface is required for synchronization of the three phases. The three Sunny Islands in one system have to be interconnected with special 15-pin interface cables available as an accessory (SMA order code “SI-Synckabel-Set”). The assignment of the SYNC BUS interface is shown in Table 3.2.

Each Sunny Island is equipped both with a plug connector (A) and a socket connector (B).

PIN	Plug connector A (RS485) top	Socket connector B (RS485) bottom
1	+5 V	+5 V
2	Sync	Sync
3	/Sync	/Sync
4	DO/DI	DO/DI
5	/DO/DI	/DO/DI
6	SPICLK	SPICLK
7	/SPICLK	/SPICLK
8	SPIMAOOUT/SIN	SPIMAOOUT/SIN
9	/SPIMAOOUT/SIN	/SPIMAOOUT/SIN
10	SPIMAIN/SOUT	SPIMAIN/SOUT
11	/SPIMAIN/SOUT	/SPIMAIN/SOUT
12	AB CONFIG A	GND
13	GND	AB CONFIG E
14	GND	GND
15	GND	GND

Table 3.2: Assignment of COM1 (SYNC BUS) interface

3.6.2 Assignment of COM2 Interface

The signals listed in Table 3.3 are available when the corresponding Piggy-Back has been installed.

PIN	RS485 Signal	RS232 Signal
1		
2	Data +	/RXD (Input of Sunny Island)
3	Data +	/TXD (Output of Sunny Island)
4		DTR (Output of Sunny Island)
5	GND	GND
6	+5V	DSR (Input of Sunny Island)
7		RTS (Output of Sunny Island)
8	Data -	CTS (Input of Sunny Island)
9	Data -	

Table 3.3: Assignment of COM2 interface (RS485 / RS232)

Recommended cable for RS485 (COM1 and COM2)

We generally recommend a so-called LICY 2 x 2 x 0.25 mm² cable as shown in Fig. 3.21.




Fig. 3.21: Recommended cable for RS485 communication



The total length of the RS485 connection cable may not exceed 1200 m.

3.7 Connection with Sunny Boy and Sunny Boy Control

To establish the recommended communication connection via RS485 (COM2) from the Sunny Island to the Sunny Boy Control and Sunny Boy, all devices have to be equipped with an RS485 interface. This option can be requested when ordering a device. Devices that have already been installed can be upgraded with RS485 communication later. This requires a special conversion kit.

The RS485 connection between the three devices, as already described in Chapter 3.6, not only makes possible configuration of the Sunny Island, but also defined power limitation of the Sunny Boys as well as data recording with Sunny Data or Sunny Boy Control.

If a Sunny Boy Control is installed later, pay attention to the required settings, jumpers etc. as described in the manual for the Sunny Boy Control.

3.7.1 Simple Connection at COM2 Interface

An RS485 G1 Piggy Back is required to upgrade the Sunny Island with a communication connection via the RS485 interface (COM2) later. Balancing and termination at the Sunny Island should be provided as shown in Fig. 3.22

In this plant layout this interface of the Sunny Island (COM2-RS485) is used for controlled power limitation of the Sunny Boys to ensure controlled full charging of the storage battery.




Fig. 3.22: Connection of Sunny Boys at Sunny Island's COM2 (RS485)



Note: This image describes the connection of a Sunny Island to Sunny Boy inverters type "SWR". **Sunny Boy Inverters type "SB" are not equipped with any resistors, that have to be removed.**

3.7.2 Multiple Connection at COM2 Interface

To ensure fail-safe and troublefree installation of the communication connection please follow the instructions below:



Make sure that termination resistors are provided at the beginning and the end of the RS485 bus. These resistors can be activated by jumpers within the device, alternatively for the Sunny Boy Control by an external bridge between pin 7 and pin 9 or by external resistors in the plug.



One of the devices on the RS485 bus has to be equipped with balancing resistors. In the Sunny Boy Control these resistors are already activated by jumpers inside the device. Normally no additional measures have therefore to be taken.

In Fig. 3.23 a detailed wiring example for communication is shown for systems including Sunny Boys and Sunny Boy Controls.




Fig. 3.23: Connection of Sunny Boys and a Sunny Boy Control at COM2 (RS485)

3.7.3 Simple Connection to PC

A PC is connected to a Sunny Island via RS232 with an ordinary serial data transmission cable (null modem cable, SMA order code "36-5001 ").

If your PC is equipped with DB25 plugs or if only a DB25 plug is free (e. g. the COM1 DB9 plug is already used by a serial PC mouse) you additionally require a DB25/DB9 adapter (SMA order code 36-5010).

You can also manufacture such a cable yourself following the description in the manual for the Sunny Boy Control (Chapter 3.2, PC interface). You will find this manual on our website www.SMA.de for download.

3.7.4 Alternative Communication at COM1 Interface

Fig. 3.24 shows as an example a simple island grid plant with a Sunny Boy as the photovoltaic feeder, Sunny Island, Sunny Boy Control Plus and communication PC. A motor feeding the grid is not included here but could be easily integrated.

The RS485 interface (COM1, SYNC BUS) of the Sunny Island to the PC is available for communication in a single-phase island grid. All parameters and measured values of the Sunny Island can be displayed in the well-known manner with the communication software Sunny Data.




Fig. 3.24: Data communication with serial interface



Please read Chapter 8.3 carefully!

3.7.5 Assignment of COM3 Interface

The service interface COM3 can only be used as an RS232 interface. In addition to control purposes of the “ecopower Mini-BHKW” (see Chapters 3.4.11 and 7.4) it is used for service, maintenance and necessary software updates. To be able to update the software, an additional PC program is required. Table 3.4 shows the pin assignment.

PIN	RS232 Signal
1	DCD
2	/RXD
3	/TXD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI

Table 3.4: Assignment of Sunny Island interface (COM3)

3.8 Communication in a Three-Phase Island Grid

The following figure shows which interconnecting cables can be installed for communication in a three-phase island grid to ensure convenient and troublefree operation.

Normally the connection between COM3 and a PC will be of temporary nature. As COM3 is a RS232-style port, only one Sunny Island can be connected at a time.




Fig. 3.25: Communication in a three-phase island grid



Please read Chapter 8.3 carefully!

4 Operating Instructions

The Sunny Island is operated with keys and an eight-line graphic display. All functions of the device can be carried out and modified according to the respective user group (operator or installer).

4.1 Display and Operating Elements

The Sunny Island is operated with six keys placed below the display. A graphic display with eight lines shows the inverter status, issues error notices and shows up-to-date information on the operation of the Sunny Island.




Fig. 4.1: Operation of the Sunny Island

As it is often more than six lines of information that is shown there are symbols in the lower line and the right-hand column of the display. These indicate to the user whether there are further lines beyond those shown on the display.

Symbols	Meaning
↓, ↑	Additional lines below / above the display (scrolling main view)
←, →	Additional menus (scrolling to left, right)

Table 4.1: Meaning of symbols

4.1.1 Key Assignment

The Sunny Island is operated with six keys. Each key is assigned several functions. Which of them is active depends on the menu item selected (see Table 4.2).

Key	Function
[↑]	One line up / increase value / (special function, see Chapters 4.1.2 and 4.1.3)
[↓]	One line down / decrease value / (special function, see Chapters 4.1.2 and 4.1.3)
[←]	Scroll menu bar to the left
[→]	Scroll menu bar to the right
[ESC]	Interrupt / stop function / (special function, see Chapters 4.1.2 and 4.1.3) / <NO>
[ENTER]	Select menu item / change to edit mode / confirm entry / <YES>

Table 4.2: Function of keys

4.1.2 Contrast in Display

The Sunny Island is equipped with a display that is easily legible in the standard setup even at a strong angle. If you still desire to modify the contrast you can do so starting from any menu item. Furthermore you can re-initialize the display which automatically resets the contrast to the standard value.

Keys	Function / Operation
[ESC] + [↑]	Weaker contrast / brighter display (pressing both keys simultaneously)
[ESC] + [↓]	Stronger contrast / darker display (pressing both keys simultaneously)
[←] + [→]	Re-initialization of the display, standard contrast (simultaneously pressing both keys)

Table 4.3: Key combination to set up display

4.1.3 Return to Status Display

To facilitate navigation through the individual menus the “Data” status display (0-1) can easily be reached starting from any menu item by simultaneously pressing:

Keys	Function / Operation
[↑] + [↓]	Return to status display and reset of password level (simultaneously pressing both keys)

Table 4.4: Key combination for fast return to status display

A return to the status display is automatically made if no keys have been pressed for approx. five minutes.



If this function is triggered the password level is reset to „Operator“ (Level: 0)

4.1.4 Edit Mode

The edit mode allows to change settings and parameters. You can enter the edit mode by pressing [**ENTER**]. Parameters that can be edited are selected by pressing [**↑**], [**↓**], [**←**] and [**→**].

In edit mode the parameter that is to be set or modified is shown inversely. If the parameter is selected by pressing [**ENTER**], its value can be increased or decreased by pressing the two arrow keys [**↑**], [**↓**]. E. g. the unit's, ten's and hundred's digits of three-digit parameters can be modified separately. The user can switch from one digit to the next (higher or lower) digit by pressing the [**←**] and [**→**] keys.

By pressing [**ENTER**] you can confirm changes – cancel them by pressing [**ESC**].

At some special menu items you will be asked to confirm your selection with <YES> or <NO>. In this case pressing [**ENTER**] corresponds to <YES>, pressing [**ESC**] corresponds to <NO>.

4.2 Menu Structure

The operator must be prevented from unintentionally modifying essential device settings. Therefore you can only enter menus where such parameters can be modified after having entered an installer password. These protected menus are shown as shaded in Fig. 4.2.



Settings and modifications of system parameters may only be carried out by specially trained personnel!

Menus with a white background can be viewed by the operator without a password. They are used in normal operation to operate and monitor the Sunny Island and the plant components it controls.




Fig. 4.2: Menu structure

As shown the menu is structured into the following main branches:

Menu branch	Description
DATA	Overview of the most important operating data; display of measured system values
OPERAT	Sunny Island operating functions and generator settings
SETUP	Setting of data and parameters
DIAG	Instructions for error diagnosis and correction, status and error history

Table 4.5: Contents of the four menu branches


The menus shown in Fig. 4.2 are described in detail in Chapters 7 to 10.

5 First Commissioning of the Sunny Island

After the inverter has been installed as described in Chapter 3 it can be commissioned for the first time. First insert the three batteries included in delivery into the battery tray in the terminal area of the Sunny Island. The correct polarity of the batteries is shown in each individual holder.


Make sure that both the DC fuses F1 and the AC fuses F2 of the Sunny Island are still switched off.

Now switch on the fuse switch disconnecter at your lead storage batteries if present (see Chapter 3.4.2) and the DC fuse of the Sunny Island afterwards. A short signaling sound can be heard, the display illumination is switched on and the message “START FIRMW” is displayed. During the following start-up phase the following messages are shown:



```
SUNNY ISLAND SUN
SUNNY ISLAND SU
D SUNNY ISLAND S
ND SUNNY ISLAND
AND SUNNY ISLAND
LAND SUNNY ISLAN
SLAND SUNNY ISLA
ISLAND SUNNY ISL
```

Fig. 5.1: Start-up phase of the Sunny Island



```
SUNNY ISLAND
Date: 07.01.2004
Time: 11:51:40
Vers: 2.16B 2.12
SN: 0012345678
```

Fig. 5.2: System message of the Sunny Island

After another two seconds you can see the starting menu (see Fig. 5.3). Should your Sunny Island display a different text, please write it down. Switch the inverter off again and contact the SMA hotline (see Chapter 20).




Fig. 5.3: "INIT" menu (0-0)

While the selection shown in Fig. 5.3 is displayed please do not press a key, simply wait for approximately 10 seconds.



You can skip the following menu and directly reach the menu branch "SETUP" (0-3, see below) by confirming "Restart" with the [**ENTER**] key in time.

You will see the following display:




Fig. 5.4: Status / Menu selection "DATA" (0-1)

By pressing [**→**] twice you reach the "SETUP" (0-3) menu. After pressing [**ENTER**] twice you reach the "SETTIM" (3-1) menu. Set the current date and time as described in Chapter 4.1.4.



This is a necessary preparation to enable the installer to enter the password correctly.

Quit the “SETTIM” (3-1) menu by pressing [**ESC**]. Now switch the Sunny Island off again with the DC fuse. Now the installer can configure the inverter as described in the following chapters.



Being the installer you can also trigger the restart required for first configuration without switching the Sunny Island off. First enter the installer password in the menu “PASSWD” (3-2) and then confirm “Restart” in the “FUNCT” (2+3) menu. Normally, however, switching the inverter off and on again should be the easier way.

6 Configuration

The Sunny Island will be used especially in those island grids which are modularly structured. The more complex such an island grid is, the higher the number of settings to be made at the Sunny Island to achieve optimum operating behavior.



The Sunny Island has to be configured with special care. Both the Sunny Island and the other connected components of the plant can be damaged due to incorrect or missing settings! Therefore the Sunny Island always has to be configured by the installer or another qualified person.

To make the process clear we distinguish between the following three reasons for configuration:

1. The Sunny Island has never before been adjusted to the plant where it is installed now. This is the case if it is newly installed or if many components are removed from or added to the plant at the same time.

In this case a basic configuration has to be made first via the menu item “New Sys MASTER“ resp. “New Sys SLAVE” in the initialization phase after the Sunny Island has been switched on. This includes the required settings for the connected battery.

2. The lead storage battery connected to the Sunny Island has been replaced or modified.

In this case a basic configuration has to be made first via the menu item “New Battery“ in the initialization phase after the Sunny Island has been switched on.

3. The Sunny Island has already been configured. For optimized operation some settings are to be changed.

This can be done in the corresponding menus practically any time. Normally the password for „Level: 1“ (installer) has to be entered in the “PASSWD“ (3-2) menu.



Parameter changes should always be made in standby mode. Otherwise the corresponding operating values are changed as well immediately after pressing [ENTER]. Faulty entries cannot be corrected fast enough and may lead to damages in the plant!



The settings defined will be maintained even if the Sunny Island is switched off. Therefore you do not have to enter all plant settings again e. g. after a battery change.

The individual configuration procedures are described in detail in the following chapters.

6.1 First Configuration

The first configuration of the Sunny Island in a new plant or a plant that has been drastically modified should be made by selecting the menu item “New Sys MASTER” resp. “New Sys SLAVE” during the initialization phase. To do so you require the password for „Level: 1“ (installer).

6.1.1 “Master” or Single Sunny Island (“New Sys MASTER”)

In order to configure a Sunny Island that is the only one or intended for being a “Master” in a system (e.g. in a three-phase system or in single-phase multiple-Sunny Island system (see Chapter 11.6)) select “New Sys MASTER” in the corresponding menu (as described in Chapter 5) with the arrow keys and confirm with [**ENTER**]. Now enter the password for „Level: 1“ (installer).




Fig. 6.1: Display to enter password



As soon as you have entered the password correctly all settings and values acquired adaptively up to this point are overwritten with standard values!

After you have entered the password you will reach a menu where you have to set up essential, “Master”-oriented parameters for the battery, the connected generator and the type of island grid to ensure proper operation.

Parameter	Default	Description
310_Auto Start	0	<p>Number of autostart attempts (0: autostart off) within one hour. After one hour the counter will be reset.</p> <p>Autostart means that approx. 10 sec after a switch-off (due to error or the like) the Sunny Island restarts.</p> <p>In addition, the Sunny Island starts automatically after switching on the DC voltage when the autostart is activated.</p> <p>ATTENTION:</p> <p>The Sunny Island will execute this number of autostart attempts anew in intervals of one hour.</p> <p>The Sunny Island’s low battery load mode will be deactivated if this parameter is set to 0!(s. Parameter “535_State Stop T” for details)</p>
401_Phase Mode	1Phs_Single	<p>1Phs_Single: single-phase operation, inverter is the only device</p> <p>1Phs_Psingle: single-phase parallel operation with one battery per device (grid and generator not possible!)</p> <p>1Phs_Mstr2: single-phase parallel operation with two devices with one single battery pack, device is master</p> <p>1Phs_Mstr3: single-phase parallel operation with three devices with one single battery pack, device is master</p> <p>1Phs_Slv2: single-phase parallel operation with two or three devices with one single battery pack, device is slave 2</p>

Parameter	Default	Description
		<p>1Phs_Slv3: single-phase parallel peroration with three devices with one single battery pack, device is slave 3</p> <p>3Phs_Mstr1Set: three-phase operation, device is master (L1)</p> <p>3Phs_parallel: three-phase operation in droop-mode (see Chapter 11.7.2 and 11.7.3), device is master (L1)</p> <p>3Phs_Slv1L2: three-phase operation, device is slave (L2)</p> <p>3Phs_Slv1L3: three-phase operation, device is slave (L3)</p>
647_ClustMode	Off	<p>Off: No special function is assigned to this Sunny Island</p> <p>SupMstr: Sunny Island is the “Super Master” that is in charge of controlling the other clusters in the system and the generator, where applicable.</p> <p>ClstMstr: Sunny Island is the Master of a secondary cluster in the system that is controlled by a “Super Master”</p> <p>Reprtr: Sunny Island is the Slave to which COM2 port another cluster is connected??</p>
501_Cbatnom	350 Ah	<p>Nominal capacity of the battery of 10 hours. This always has to be entered as defined in the manufacturer’s instructions even if the battery has already aged!</p> <p>In case that the manufacturer did not specify a capacity of 10 hours select the specification that is nearest to the capacity of 10 hours.</p>
502_Bat Type	Lead acid	<p>Lead storage battery with...</p> <p>Lead acid: ... liquid electrolyte</p> <p>Fleece: ... electrolyte bound in fleece</p> <p>Gel: ... electrolyte bound in gel</p>
503_Ubat nom	60.0 V	Nominal battery voltage.
504_Ubat min	51	min. battery voltage permissible
505_Ubat max	84	max. battery voltage permissible
506_acid density	1.24 kg/l	Nominal acid density of electrolyte, should be entered as defined in the manufacturer’s instructions to accelerate its adaptive determination by the Sunny Island.
509_Tbat max	40	Maximum battery temperature permissible
511_Bat Fan	Not installed	<p>Battery room fan installed (only for lead storage battery with liquid electrolyte)</p> <p>Not installed</p> <p>Installed</p>

Parameter	Default	Description
512_Acid Pump	Not installed	<p>Only for lead storage battery with liquid electrolyte:</p> <p>Not installed Electrolyte circulation pump not installed</p> <p>Installed Electrolyte circulation pump installed</p> <p>By selecting "Installed", the electrolyte circulation pump is switched on depending on settings of parameters 513 to 516. Irrespective of battery values, however, there is at least one circulation and 9 circulations maximum per day.</p>
602_GenSet Type	None	<p>None: No generator present in island grid</p> <p>Grid forming: Generator is grid-forming.</p> <p>Mains: Sunny Island is operated on the public utility grid.</p> <p>BHKW-Mains Sunny Island is operated together with an eco-power CHP and on the public utility grid</p> <p>BHKW-Island Sunny Island is operated together with an eco-power CHP</p> <p>Mains form Sunny Island is operated together with a grid-forming generator and on the public utility grid</p> <p>fast Grid form Generator is grid-forming and it is switched between the generator and the Sunny Island without interruption (special installation measures are necessary for this)</p> <p>fast Mains The Sunny Island is operated on the public utility grid and it is possible to switch from the Sunny Island as grid-former to the public utility grid without interruption. (special installation measures are necessary for this)</p> <p>fast Mains form The Sunny Island is operated together with a grid-forming generator and on the public utility grid. Switching takes place without interruption (special installation measures are necessary for this)</p> <p>DroopGen The Sunny Island is operated together with a generator capable of droop characteristics in droop mode.</p> <p>DroopMains The Sunny Island is operated together with a utility in droop mode.</p> <p>DrpGenMains The Sunny Island is operated together with a generator capable of droop characteristics and a utility in droop mode.</p> <p>BHKW-IsI-Therm Sunny Island is operated together with the eco-power CHP. In contrast to "BHKW-Island" the Sunny Island will not switch off the CHP when no more electrical power is required. Thus, the ecopower CHP will be able to provide as much thermal energy as required.</p>
603_GenSet Inte	None	<p>None: No generator start via Sunny Island</p> <p>Type 1: Autostart, relays K1+K2</p> <p>Type 2: 3 contacts Run / Start, relays K1, K2, K6</p>

Parameter	Default	Description
		Type 3: 3 contacts Start / Stop, relays K1, K2, K6 EcoPower Ecopower CHP (see also Fig. 12.1: Starting phase sequence for different generator types)
604_GenSet Ctrl	OFF	The Sunny Island reduces its current input in charge operation (RUN_I) OFF: ... not at all F_MAINS: ... as a function of generator frequency (see "407_Fext nom") I_GEN: ... as a function of generator current (converter required, see Chapter 3.4.5) BOTH: ... as a function of generator frequency (see "407_Fext nom") and current (converter required, see Chapter 3.4.5)
605_GenStRetr	3	Max. number of attempts to start the generator, before the state "Fail Locked" is reached (see also parameter 618). After the minimum run-time of the generator has expired, the counter will be reset.
606_CurTrfRatio	5 A/5A	Current transformer ratio (in A per 5 A) for measurement of generator current
607_Igen max	0 A	Max. generator current (per phase), only applies if "604_GenSet Ctrl" is set accordingly
645_RevPower	-0,5 kW	Generator reverse power protection: If the power delivered by the generator falls below this value, the generator will be disconnected
701_Man K1	OFF	Operating mode of relay K1 OFF: Switch relay K1 off ON: Switch relay K1 on AUTO: Sunny Island automatically controls relay K1.
702_Man K2	OFF	Operating mode of relay K2 (for details see 701)
703_Man K3	OFF	Operating mode of relay K3 (for details see 701)
704_Man K4	OFF	Operating mode of relay K4 (for details see 701)

Parameter	Default	Description
705_Man K5	OFF	<p>Operating mode of relay K5</p> <p>OFF: Switch relay K5 off</p> <p>ON: Switch relay K5 on</p> <p>AUTO: Sunny Island automatically controls relay K5.</p> <p>RUN: Relay is only switched on when the Sunny Island operates.</p> <p>RUN_U: Relay is only switched on when the Sunny Island operates as the grid-forming element.</p> <p>RUN_I: Relay is only switched on when the Sunny Island is in "grid-tied operation".</p> <p>HD_CTRL: Relay is switched on during transfer from grid-forming to grid-tied operation.</p> <p>TK_CTRL: Relay is switched on during transfer from grid-tied to grid-forming operation.</p> <p>HDTK_CTRL: Relay is switched on during any transfer from grid-tied to grid-forming operation or vice versa.</p> <p>GEN_MANU: Relay is switched on if generator has already been started before the Sunny Island.</p> <p>LOAD: Relay is switched on in relation to load (see also parameter 625 to 630)</p>
706_Man K6	OFF	Operating mode of relay K6 (for details see 705)
707_Man K7	OFF	Operating mode of relay K7 (for details see 701)
708_Man K8	OFF	Operating mode of relay K8 (for details see 701)
712_K1 On t1	N4	When this battery state is reached, K1 is switched on. (see Chapter 2.2.2)
713_K1 Off t1	N1	When this battery state is reached, K1 is switched off. (see Chapter 2.2.2)
801_Sunny Boys	Not installed	<p>Not installed: Sunny Island is not to control Sunny Boys.</p> <p>Installed: Sunny Island is to control Sunny Boys (via COM2)</p> <p>Inst. Mains: Sunny Island only is to control Sunny Boys if grid feeding is not possible (via COM2)</p> <p>Frequency: Sunny Island controls the Sunny Boys via grid frequency (depending on the Sunny Boy's firmware) in operation mode RUN_U</p>

Table 6.1: Parameters to be entered for configuration via "New Sys MASTER"



Lead storage batteries with a liquid electrolyte are also called non VARLA while batteries labeled VARLA (**VA**lve **R**egulated **L**ead **A**cid) or maintenance-free are normally gel or fleece batteries.



Initially, when started via “New Sys MASTER” or “New Battery”, the battery state will be set to L1 and will not change until a “normal charge” could have been performed. In pure photovoltaically powered systems this may take some days.

Furthermore, the displayed actual state of charge will not rise above 90% for a certain time due to the adaption process of the Sunny Island’s battery management.

This behavior is normal and there is no reason to be concerned.

In a three-phase system one Sunny Island has to be set up as the master (3Phs_Mstr1Set) while the other two are set up as slaves (3Phs_Slv1L2 and 3Phs_Slv1L3). The settings of other interconnection systems (for example “single-phase parallel”) are corresponding.

You can only leave this menu by pressing [**ESC**] after you have checked all parameters (see Fig. 4.2). Please check now referring to Chapters 8 and 16 whether additional settings for adaptation to the island grid are required or reasonable.

If this Sunny Island was the only one in the system or the last to be configured, you may now switch on the AC fuses (F2) of all Sunny Islands in the system.



It is strongly recommended to leave all loads in the system switched off until the battery state reaches N1 for the first time (the battery state (BAZ) is displayed in various menus, see Chapter 9 for details).

Screw all lower lids onto the enclosures again after you have reconnected their PE cables.



An AC grid is only available when the Sunny Island has been set into the operating mode “RUN_U” in the “START” (2-1) menu (see Chapter 7.1).

6.1.2 “Slave” Sunny Island (“New Sys SLAVE”)

In order to configure a Sunny Island that is intended for being a “Slave” in a system (e.g. in a three-phase system or in single-phase multiple-Sunny Island system (see Chapter 11.6)) select “New Sys Slave” in the corresponding menu (as described in Chapter 5) with the arrow keys and confirm with [**ENTER**]. Now enter the password for „Level: 1“ (installer).



Fig. 6.2: Display to enter password



As soon as you have entered the password correctly all settings and values acquired adaptively up to this point are overwritten with standard values!

After you have entered the password you will reach a menu where you have to set up essential, “Slave”-oriented parameters. As the main control functions are performed by the “Master”, only a few parameters that should be set for “Slaves” remain:

401_Phase Mode	1Phs_Single	<p>1Phs_Single: single-phase operation, inverter is the only device</p> <p>1Phs_Psingle: single-phase parallel operation with one battery per device (grid and generator not possible!)</p> <p>1Phs_Mstr2: single-phase parallel operation with two devices with one single battery pack, device is master</p> <p>1Phs_Mstr3: single-phase parallel operation with three devices with one single battery pack, device is master</p> <p>1Phs_Slv2: single-phase parallel operation with two or three devices with one single battery pack, device is slave 2</p> <p>1Phs_Slv3: single-phase parallel operation with three devices with one single battery pack, device is slave 3</p> <p>3Phs_Mstr1Set: three-phase operation, device is master (L1)</p> <p>3Phs_parallel: three-phase operation in droop-mode (see Chapter 11.7.2 and 11.7.3), device is master (L1)</p> <p>3Phs_Slv1L2: three-phase operation, device is slave (L2)</p> <p>3Phs_Slv1L3: three-phase operation, device is slave (L3)</p>
647_ClustMode	Off	<p>Off: No special function is assigned to this Sunny Island</p> <p>SupMstr: Sunny Island is the “Super Master” that is in charge of controlling the other clusters in the system and the generator, where applicable.</p> <p>ClstMstr: Sunny Island is the Master of a secondary cluster in the system that is controlled by a “Super Master”</p> <p>Reptr: Sunny Island is the Slave to which COM2 port another cluster is connected??</p>
504_Ubat min	51 V	min. battery voltage permissible
505_Ubat max	84 V	max. battery voltage permissible
604_GenSet Ctrl	OFF	<p>The Sunny Island reduces its current input in charge operation (RUN_I)</p> <p>OFF: ... not at all</p> <p>F_MAINS: ... as a function of generator frequency (see “407_Fext nom”)</p> <p>I_GEN: ... as a function of generator current (converter required, see Chapter 3.4.5)</p> <p>BOTH: ... as a function of generator frequency (see “407_Fext nom”) and current (converter required, see Chapter 3.4.5)</p>
606_CurTrfRatio	5 A/5A	Current transformer ratio (in A per 5 A) for measurement of generator current
702_Man K2	OFF	Operating mode of relay K2 (for details see 701)
703_Man K3	OFF	Operating mode of relay K3 (for details see 701)

Table 6.2: Parameters to be entered for configuration via “New Sys SLAVE“

In a three-phase system one Sunny Island has to be set up as the master (3Phs_Mstr1Set) while the other two are set up as slaves (3Phs_Slv1L2 and 3Phs_Slv1L3). The settings of other interconnection systems (for example single-phase parallel”) are corresponding.

You can only exit this menu by pressing [**ESC**] after you have checked all parameters (see Fig. 4.2). Please check now referring to Chapters 8 and 16 whether additional settings for adaptation to the island grid are required or reasonable.

If this Sunny Island was the last to be configured in the system, you may now switch on the AC fuses (F2) of all Sunny Islands in the system.

Screw all lower lids onto the enclosures again after you have reconnected their PE cables.



All “Slave” Sunny Islands will be controlled through their resp. “Master” Sunny Island. An AC grid driven by the Sunny Islands will not be available until the “Master” Sunny Island has been started.



After a Sunny Island has been configured as „Slave“ its system time will be adjusted to the system time of the „Master“.

6.2 Configuration after Battery Exchange (“New Battery”)

After the lead storage battery has been exchanged the Sunny Island has to be reconfigured. To do so select the menu item “New Battery” in the “INIT” (0-0) menu. You require the password for „Level: 1“ (installer).

After you have switched on the Sunny Island DC fuse you will reach – as already known from Chapter 5 – the menu in which you select the menu item “New Battery” with the arrow keys and confirm this with [**ENTER**]. Now enter the password for “Level: 1“ (installer).



Fig. 6.3: Display to enter password



In contrast to configuration via “New System“, only those settings that concern the battery are reset after correctly entering the password.

After entering the password you will reach a menu where selected essential parameters for the exchanged battery have to be set.

Parameter	Default	Description
501_Cbatnom	350 Ah	Nominal capacity of the battery of 10 hours. This always has to be entered as defined in the manufacturer's instructions even if the battery has already aged! In case the manufacturer did not specify a capacity of 10 hours select the specification that is nearest to the capacity of 10 hours.
502_Bat Type	Lead acid	Lead storage battery with... Lead acid: ... liquid electrolyte Fleece: ... electrolyte bound in fleece Gel: ... electrolyte bound in gel
503_Ubat nom	60.0 V	Nominal battery voltage.
504_Ubat min	51 V	min. battery voltage permissible
505_Ubat max	84 V	max. battery voltage permissible
506_acid density	1.24 kg/l	Nominal acid density of electrolyte, should be entered as defined in manufacturer's instructions to accelerate its adaptive determination by the Sunny Island.
509_Tbat max	40 °C	Maximum battery temperature permissible

Table 6.3: Parameters to be entered for configuration via “New Battery“



Lead storage batteries with a liquid electrolyte are also called non-VARLA while batteries labeled VARLA (**VA**lve **R**egulated **L**ead **A**cid) or maintenance-free are normally gel or fleece batteries.



Initially, when started via “New Sys MASTER” or “New Battery”, the battery state will be set to L1 and will not change until a “normal charge” could have been performed. In pure photovoltaically energized systems this may take some days.

Furthermore, the displayed actual state of charge will not rise above 90% for a certain time due to the adaptation process of the Sunny Island's battery management.

This behavior is normal and there is no reason to be concerned.

You can only exit this menu again by pressing [**ESC**] after you have checked all parameters (see Fig. 4.2).

Please check now referring to Chapters 8 and 16 whether additional settings for adaptation to the island grid are required or reasonable.



It is strongly recommended to leave all loads in the system switched off until the battery state reaches N1 for the first time (the battery state (BAZ) is displayed in various menus, see Chapter 9 for details).

6.3 Configuration after Restart (“Restart”)

If the Sunny Island has already been fully adjusted to an island grid it does not need to be reconfigured after a restart. All settings are maintained even if the inverter is switched off. If you still want to change parameters to optimize the system please follow the instructions below:

When you reach the “INIT” (0-0) menu after switching on the DC fuse of the Sunny Island – as described in Chapter 5 – confirm the automatic selection of “Restart” by pressing [**ENTER**]. This will not change any of the settings already made.

You will thus reach the menu branch selection “SETUP” (0-3) where – as described in Chapter 8 – you can change the desired parameters in the corresponding “PARxxx” (3+3 ... 3+9) menus after entering the installer password in the “PASSWD” (3-2) menu.

If you have not pressed [**ENTER**] early enough you will reach the menu branch selection “DATA” (0-1). From here it is also possible to reach all menus with the installer password and change the parameters there.



Changes of parameters should always be made in standby mode. Otherwise, the corresponding operating values will change immediately after pressing [ENTER]. Incorrect entries can then not be changed fast enough and may lead to damages in the plant!



To be sure that the modified parameters will take effect, please follow the steps below:

1. Set any parameter that has to be changed.
2. Select „Store Permanent“ in the „FUNCT“ (2+3) menu (alternatively wait for at least 30 seconds without pressing any buttons).
3. Restart the Sunny Island by selecting “Restart” in the “FUNCT” (2+3) menu (confirm the appearing question with <YES> by pressing [**ENTER**]).

7 Operation (OPERAT)

```

0-2  STANDBY
-----
Status
      STANDBY
401_Phase Mode
      1Phs_Single
GenState
      NONE
-----
<OPERAT SETUP >
  
```

Fig. 7.1: Menu selection “OPERAT” (0-2)

The menu selection “OPERAT” (0-2) shows the current operating modes of the Sunny Island and of a potentially connected generator.

In islanding operation the Sunny Island provides constant voltage and frequency on the AC voltage side and uses the battery as a buffer storage. All connected consumers are supplied and feeding devices such as the Sunny Boy String Inverters and combustion aggregates can be operated on the AC voltage side.

The menu selection “OPERAT” (0-2) is meant for operating steps in normal operation.




Fig. 7.2: Menu branch “OPERAT” (0-2)

7.1 Menu "START" (2-1), Operation of the Sunny Island



Fig. 7.3: Menu "START" (2-1)

By confirming the menu entry "START" in the menu "START" (2-1) the Sunny Island can be switched from standby operation to the operating mode configured before. As a default setting this is the operation as a grid-forming element ("RUN_U") where the Sunny Island forms the island grid and supplies the connected consumers. The operating mode – grid-forming ("RUN_U") or grid-tied ("RUN_I") – is stipulated by setting the parameter "602_GenSet Type" in the menu "PARGEN" (3+6).



Even in grid-tied operating mode the Sunny Island may be transitorily grid-forming. This is the case if no voltage has been found in the island grid.

When starting up, the Sunny Island will shortly beep, as an acoustic warning.

By confirming the menu entry "STOP" the Sunny Island is switched back into standby mode. In an island grid without any other grid-forming component this means that no AC voltage is on any more.



When the Sunny Island is started from the state it has been delivered in, the start-up must be made manually. The inverter can also be configured to an automatic (re-)start (see Chapter 8.3).

7.2 Menu “GENSET” (2-2), Operation of Generator

```

2-2  STANDBY
-----
State  NONE
Fail   NONE
>      AUTOSTART  <
      MANUAL START
      MANUAL STOP
      ACKNOWLEDGE
-----
START  GENSET  →

```

Fig. 7.4: Menu “GENSET” (2-2)

The menu “GENSET” (2-2) comprises functions concerning a connected generator. Such a generator can e. g. be started or stopped manually via this menu or can be set to automatic operation controlled by the Sunny Island.



For safety reasons and to prevent the generator from unnecessary starts, e. g. when the system is serviced, the operation mode for the generator will be set to „MANUAL STOP“ each time the Sunny Island is restarted.

Make sure that the operation mode for the generator is set to „AUTO-START“ again if you expect the Sunny Island to start and stop the generator automatically!

The menu item “ACKNOWLEDGE” enables the operator to easily confirm error states of the generator. At the next start-up attempt the complete starting sequence is run again. This function can be useful e. g. to solve start-up difficulties by the generator.

In addition “ACKNOWLEDGE” removes the lock-out that normally prevents another generator start for 6 hours after a configurable number of failed start-up attempts (see Chapter 8.6).

The upper lines show behind “State” and “Fail” whether a generator has been configured (see also Chapter 8.6), in which operating phase it currently is and whether an error has occurred.

Additionally the remaining times for e.g. crank, warm up phases etc. will be displayed in the last line when this menu is entered.

Name	Description
State	Operating state of generator
Fail	Fail state of generator
601_GenSet Oper	<p>Auto: The generator is automatically started and stopped by the Sunny Island.</p> <p>Man. Start: The generator is started immediately*.</p> <p>Man. Stop: The generator is stopped immediately*.</p> <p>Man. Ackn.: Waiting times due to failures or parameters are finished.</p> <p>* However, parameterized times are kept to.</p>
“PARGEN” (3+6)	
Name	Description
602_GenSet Type	<p>None: No generator present in island grid</p> <p>Grid forming: Generator is grid-forming.</p> <p>Mains: Sunny Island is operated on the public utility grid.</p> <p>BHKW-Mains Sunny Island is operated together with an ecopower CHP and on the public utility grid</p> <p>BHKW-Island Sunny Island is operated together with an ecopower CHP</p> <p>Mains form Sunny Island is operated together with a grid-forming generator and on the public utility grid</p> <p>fast Grid form Generator is grid-forming and it is switched between the generator and the Sunny Island without interruption (special installation measures are necessary for this)</p> <p>fast Mains The Sunny Island is operated on the public utility grid and it is possible to switch from the Sunny Island as grid-former to the public utility grid without interruption. (special installation measures are necessary for this)</p> <p>fast Mains form The Sunny Island is operated together with a grid-forming generator and on the public utility grid. Switching takes place without interruption (special installation measures are necessary for this)</p> <p>DroopGen The Sunny Island is operated together with a generator capable of droop characteristics in droop mode.</p> <p>DroopMains The Sunny Island is operated together with a utility in droop mode.</p> <p>DrpGenMains The Sunny Island is operated together with a generator capable of droop characteristics and a utility in droop mode.</p> <p>BHKW-IsL-Term Sunny Island is operated together with the ecopower CHP. In contrast to “BHKW-Island”, the Sunny Island will not switch off the CHP when no more electrical power is required. Thus, the ecopower CHP will be able to provide as much thermal energy as required</p>

Name	Description
603_GenSet Interf	<p>None: No generator start by Sunny Island</p> <p>Type 1: Autostart, relays K1 + K2</p> <p>Type 2: 3 contacts Run / Start, relays K1, K2, K6</p> <p>Type 3: 3 contacts Start / Stop, relays K1, K2, K6</p> <p>EcoPower Ecopower CHP</p> <p>(see also Fig. 12.1: Starting phase sequence for different generator types)</p>
604_GenSet Ctrl	<p>The Sunny Island reduces its absorption of current in charging operation (RUN_I)...</p> <p>OFF: ... not at all</p> <p>F_MAINS: ... as a function of generator frequency</p> <p>I_GEN: ... as a function of generator current (converter required, see Chapter 3.4.5)</p> <p>BOTH: as a function of generator frequency and current (converter required, see Chapter 3.4.5)</p>

Table 7.1: Settings for the menu “GENSET“ (2-2)

7.3 Menu “FUNCT” (2+3), Special Functions

This menu can only be selected after the installer password (level: 1) has been entered.




Fig. 7.5: Menu “FUNCT” (2+3)

In this menu cumulatively measured values can be reset, default parameters can be loaded and a firmware update can be made.

The selection of “Load Defaults”, “Restart” or “Update Firmware” has either to be confirmed with <YES> (by pressing [**ENTER**]) or canceled with <NO> (by pressing [**ESC**]).



These functions can only be triggered in standby operation of the Sunny Island for increased safety.



How to run a firmware update is described in detail in a separate document. This will be delivered together with the PC programme required for the update.

If “Update Firmware” was selected the Sunny Island will wait for data coming from an external PC displaying Fig. 7.6.

```

SUNNY ISLAND (C)
SMA 2003
BOOT (V2.2) OK
UPDT
DON'T SWITCH OFF
WHILE UPDATE IN
PROGRESS!

```

Fig. 7.6: Update information display

The Sunny Island will remain in this state until a firmware update is actually being performed. If you reached this state by mistake, without having the opportunity to update the firmware, you may – **only in this case!** – switch off the Sunny Island, ignoring the warning, in order to get it back into normal operation.



Switching off the Sunny Island while an update process is in progress may disable the Sunny Island irrecoverably!

7.4 Menu „BHKW“ (2+5), ecopower support

This menu can only be selected after the installer password (level: 1) has been entered.

```

2+5  STANDBY
-----
BHKWSTATE 0
PBHKW      0W
PBHKWMAX   0W

PBHKWSET   0W
BHKWMODE   0
&FUNCT    BHKW

```

Fig. 7.7: Menu „BHKW“ (2+5)

In order to be controlled by the Sunny Island this function has to be unlocked in the ecopower mini combined heat and power units of the company VALENTIN Energie- und Umwelttechnik GmbH.

The Sunny Island is capable of controlling both, single-phase and three-phase ecopower mini CHPs.

If one or more CHPs are available in the system, the corresponding values must be set in the menu „PARGRD“ (3+4). The CHP is controlled via the serial RS232 interface COM3 of the Sunny Island. The communication parameters are set automatically.

The menu „BHKW“ (2+5) is primarily used for the display of the CHP's operating state. In addition, it can be used for the commissioning of the plant to manually switch on and off the CHP with special inputs. All inputs are only valid until the menu is quit. The menu items are:

Menu Item	Meaning
BHKWSTATE	State, meaning see CHP documentation
PBHKW	Effective power, can be set; sum of all phases
PBHKWMAX	Total power capacity of all connected CHPs
PBHKWSET	Setpoint of CHP Power required by the Sunny Island, can be set
BHKWMODE	Operating mode, can be set, meaning see CHP documentation

Table 7.2: Settings in the menu „BHKW“ (2+5)



As long as PBHKWMAX is zero either no „ecopower Mini-BHKW“ (CHP) is installed in the system or proper communication is not possible between Sunny Island and the CHP.

8 Settings (SETUP)




Fig. 8.1: Menu selection "SETUP" (0-3)

In the menu branch "SETUP" (0-3) you can set up all parameters. Usually you have to enter the installer password (level: 1) (see Chapter 8.2). Only less important settings (like time and date) can be changed by the operator without having to enter the password.



The settings in this menu branch influence the behavior of the inverter and the entire system. Special care should therefore be applied when changing these settings. This should only be done by qualified personnel.



Changes of parameters should always be made in standby mode. Otherwise the corresponding operating values may change immediately after pressing [ENTER]. Faulty settings cannot be corrected fast enough and may lead to damage in the plant!



To be sure that the modified parameters will take effect, please follow the steps below:

1. Set any parameter that has to be changed.
2. Select „Store Permanent“ in the „FUNCT“ (2+3) menu (alternatively wait for at least 30 seconds without pressing any buttons).
3. Restart the Sunny Island by selecting "Restart" in the "FUNCT" (2+3) menu (confirm the appearing question "RESTART ?" with <YES> by pressing [ENTER]).




Fig. 8.2: Menu branch “SETUP” (0-3)

8.1 Menu “SETTIM” (3-1), Setting the System Clock




Fig. 8.3: Menu “SETTIM” (3-1)

In this menu the integrated clock of the Sunny Island can be set. It is necessary to correctly set the time e. g. for password entry, time-dependent relay control and chronological recording of system and failure states (see Chapter 10).

In the menu “SETTIM” (3-1) shown in Fig. 8.3 switch to edit mode by pressing [**ENTER**]. You can set the time and date as described in Chapter 4.1.4. Finish each entry (year, month...) separately by pressing [**ENTER**] and only then change to the next setting. You can leave the menu by pressing [**ESC**].



In order to have a correct system time even after the Sunny Island is switched off, make sure that the three AA-batteries were assembled properly (see Chapter 5).

8.2 Menu “PASSWD” (3-2), Entry of Password




Fig. 8.4: Menu “PASSWD” (3-2)

Functions which seriously influence the operating behavior of the Sunny Island are password-protected. To reach the menus shown in gray in Fig. 4.2 you need an installer password (level: 1). The menus with a white background (level: 0) can be selected without having to enter a password.



Functions influencing the plant-specific settings and thus the operating safety of the Sunny Island are locked by the installer password. The system parameters can only be changed after this password has been entered.

Password protection is activated again

- if a wrong password has been entered in the menu “PASSWD” (3-2),
- on a restart,
- when using the return function (see Chapter 4.1.3),
- if no keys have been pressed for approximately 5 minutes.

8.3 Menu “PARSYS” (3+3), Parameters System

This menu can only be selected after the installer password (level: 1) has been entered.




Fig. 8.5: Menu “PARSYS” (3+3)

In the menu “PARSYS” (3+3) you can set the parameters that concern the Sunny Island itself. Essentially these are the settings for communication and thus the interface configuration.



Especially for three-phase systems changes of these settings can lead to incorrect configuration which the Sunny Island cannot immediately detect in operation. Therefore changes of interface parameters are only implemented at the next restart of the Sunny Island. Please follow the instructions indicated at the beginning of Chapter 8.

In this menu the operator can also stipulate the number of autostart attempts to be made after an error has occurred or the DC voltage has been switched on. If this value is set to 0 (state in which the inverter is delivered) the Sunny Island does not start automatically.



By setting the parameter “310_Auto Start” to 0, the low-battery load mode (see Chapter 16, Parameter “517_BS Tstop”) will be inhibited, while any positive number will not affect this mode.

“PARSYS” (3+3)	
Name	Description
310_Auto Start	<p>0 ... 255: Number of autostart attempts (0: autostart off) within 1 hour. After 1 hour the counter is reset. Autostart means that the Sunny Island restarts automatically app. 10 sec after an error message. In addition, the Sunny Island starts automatically after switching on the DC voltage in case the autostart function is activated.</p> <p>ATTENTION! The Sunny Island will execute this number of autostart attempts anew in intervals of one hour. The Sunny Island's low battery load mode will be deactivated if this parameter is set to 0! (s. Parameter “535_State Stop T” for details)</p>
312_COM1 Proto	<p>Communication protocol COM1:</p> <p>None: Interface is not used</p> <p>SMANET: Interface uses SMANet protocol</p> <p>SUNNYNET: Interface uses SunnyNet protocol</p> <p>Set to SUNNYNET for communication with Sunny Boys.</p>
313_COM1 Baud	<p>Baud rate COM1 (bits/s)</p> <p>1200, 9600, 19200</p> <p>Set to 1200 for communication with Sunny Boys or Sunny Boy Controls.</p> <p>In three-phase operation all devices have to be set to 19200!</p>
317_COM2 Baud	<p>Corresponding to parameter 313 (see above)</p> <p>Set to 1200 for communication with Sunny Boys or Sunny Boy Controls with Sunny Boys.</p>

Table 8.1: Settings in menu “PARSYS” (3+3)

8.4 Menu “PARGRD” (3+4), Parameters Grid

This menu can only be selected after the installer password (level: 1) has been entered.

```

3+4  STANDBY
-----
401_Phase Mode
    1Phs_Single
402_Uconv nom
    230.0 V
403_Fconv nom
    50.00 Hz
PARSYS PARGRD
  
```

Fig. 8.6: Menu “PARGRD” (3+4)

The Sunny Island is informed about the operating values of the connected AC grid with the settings in the menu “PARGRD” (3+4). These values are the voltage and frequency which the Sunny Island, being the grid-forming device, has to make available. In addition these are limiting values. When these limits are exceeded the Sunny Island in grid-tied operation detects this state as an error.



After changing the parameter “401_Phase Mode” the Sunny Island must be restarted (for example in the menu “FUNCT” (2+3), see Chapter 7.3).

“PARGRD” (3+4)		
Name	Description	
401_Phase Mode	1Phs_Single:	single-phase operation, device is single device
	1Phs_Psingle:	single-phase parallel operation with one battery per device (no grid and generator possible!!)
	1Phs_Mstr2:	single-phase parallel operation with “two devices with one single battery pack”, device is master
	1Phs_Mstr3:	single-phase parallel operation with “three devices with one single battery pack”, device is master
	1Phs_Slv2:	single-phase parallel operation with “two or three devices with one single battery pack”, device is slave 2
	1Phs_Slv3:	single-phase parallel operation with “three devices with one single battery pack”, device is slave 3
	3Phs_Mstr1Set:	three-phase operation, device is master (L1)
	3Phs_Slv1L2:	three-phase operation, device is slave (L2)
	3Phs_Slv1L3:	three-phase operation, device is slave (L3)
402_Uconv nom	200 ... 260 V:	setpoint AC voltage the Sunny Island is to supply as grid-former (RUN_U)
403_Fconv nom	40 ... 70 Hz:	setpoint AC frequency the Sunny Island is to supply as grid-former (RUN_U)
404_Uext nom	150 ... 260 V:	nominal AC voltage (RUN_I)
405_Uext min	150 ... 260 V:	minimum AC voltage
406_Uext max	150 ... 260 V:	maximum AC voltage
407_Fext nom	40 ... 70 Hz:	nominal AC frequency, Sunny Island operates grid-tied (RUN_I)
408_Fext min	40 ... 70 Hz:	min. AC frequency
409_Fext max	40 ... 70 Hz:	max. AC frequency
411_lac chrg mx	0 ... 16 A:	max. current which the Sunny Island may take from the AC grid in grid-tied operation (RUN_I, battery is charged thereby)

Table 8.2: Settings in menu “PARGRD” (3+4)

8.5 Menu “PARBAT“ (3+5), Parameters Battery

This menu can only be selected after the installer password (level: 1) has been entered.

```

3+5  STANDBY
501_Cbat nom
    350 Ah
502_Bat Type
    Lead Acid
503_Ubat nom
    60.0 V
PARGRD PARBAT
  
```

Fig. 8.7: Menu “PARBAT“ (3+5)

In the menu “PARBAT“ (3+5) the operator can change the parameters for the battery management of the Sunny Island. In addition to the characteristic values defined by the connected lead storage battery itself such as battery capacity, battery type and nominal battery voltage, the settings for optimum maintenance of the capacity can be adjusted to the plant as well (e. g. type and frequency of full charges and regularizing charges). For more details on battery management and the required settings see Chapter 2.2.

“PARBAT“ (3+5)	
Name	Description
501_Cbat nom	0 ... 10000 Ah: Nominal battery capacity of 10 hours (C10); Always enter value stated by manufacturer even if battery has already aged! In case that the manufacturer did not specify a capacity of 10 hours select the specification that is nearest to the capacity of 10 hours.
502_Bat Type	Battery type as stated by manufacturer Gel gel Fleece fleece Lead-Acid liquid electrolyte
503_Ubat nom	48 ... 60 V: Nominal battery voltage.
504_Ubat min	40 ... 70 V: Min. permissible battery voltage
505_Ubat max	45 ... 84 V: Max. permissible battery voltage
506_acid density	1.1 ... 1.35 kg/l: Nominal acid density as stated by manufacturer (only taken into account if inverter is started via “New System“ or “New Battery“ (see Chapter 6))

“PARBAT“ (3+5)		
Name	Description	
508_Tbat Sense	<p>Not Installed Battery temperature sensor is not installed</p> <p>Installed Battery temperature sensor is installed</p> <p>Automatically set to “Installed” in case of single-phase systems or masters in three-phase systems. In all other cases set to “Not Installed”.</p> <p>Can be set to “Installed” for slaves with additional temperature sensors installed.</p>	
509_Tbat max	30 ... 55 °C:	Max. battery temperature permissible
511_Bat Fan	<p>Battery room fan installed:</p> <p>0: Not Installed Battery room fan not installed</p> <p>1: Installed Battery room fan is installed</p>	
512_Acid Pump	<p>Only for lead storage battery with liquid electrolyte:</p> <p>0: Not Installed: Electrolyte circulation pump is not installed</p> <p>1: Installed: Electrolyte circulation pump is installed.</p> <p>By selecting “Installed” the electrolyte circulation pump is switched on depending on the settings of parameters 513 to 516. Irrespective of the battery values, however, there is at least one and maximum 9 circulations a day.</p>	
513_Circ time	1 ... 3600 s:	Run time of electrolyte circulation
516_Circ Qd	0.1 ... 50.0 %:	Electrolyte circulation is triggered as soon as the battery has been charged with the corresponding ampere hours related to its capacity (cumulative).
518_tset full	1 ... 180 d:	Time period after which full charge is to be made.
519_tset equal	7 ... 365 d:	Time period after which equalizing charge is to be made.
520_U float	2.2 ... 2.4 V:	Float charge voltage per cell
527_tcharge	1 ... 600 min:	Charging time for normal charge (with lead acid battery, see “502_Bat Type”)
528_tcharge full	1 ... 20 h:	Charging time for full charge (with lead acid battery, see “502_Bat Type”).
529_tcharge equal	1 ... 48 h:	Charging time for equalizing charge (with lead acid battery, see “502_Bat Type”)
530_Ucharge	2.29 ... 2.7 V:	<p>Charging voltage for normal charge per cell (with lead acid battery, see “502_Bat Type”)</p> <p>In case of electrolyte circulation pump installed the value should be reduced to 2.45 V. Please follow manufacturer's instructions.</p>
531_Ucharge full	2.25 ... 2.7 V:	<p>Charging voltage for full charge per cell (with lead acid batteries, see “502_Bat Type”)</p> <p>In case of electrolyte circulation pump installed the value should be reduced to 2.45 V. Please follow manufacturer's instructions.</p>
532_Ucharge equal	2.25 ... 2.7 V:	Charging voltage for equalizing charge per cell (with lead acid battery, see “502_Bat Type”)

“PARBAT“ (3+5)	
Name	Description
	Please follow manufacturer's instructions.
533_Stdby t beg	0 ... 23 h: Beginning of period when low-strain operation of battery is permissible (see “535_Stat StopT”)
534_Stdby t end	0 ... 23 h: End of period when low-strain operation of battery is permissible (see “535_Stat StopT”)
535_State StopT	<p>L4 ... O3: In case of deep-cycle discharge the device will switch off to reduce strain on the battery, if no charging current of a minimum of 1 A flows into the battery for more than 5 minutes within the defined time period (see also “533_Stdby t beg”, „534_Stdby t end“).</p> <p>The low battery load mode is always activated, when one battery state lower is reached. However, from 6 am to 6 pm the Sunny Island attempts to switch on every four hours.</p>
536_Fan on del	<p>0 ... 1440 min: ON delay for battery room fan</p> <p>In order to use this setting, “511_Bat Fan” must be set to “Installed“</p>
537_Fan off del	<p>0 ... 360 min: OFF delay for battery room fan</p> <p>In order to use this setting, “511_Bat Fan” must be set to “Installed“</p>
538_lloss nom	<p>Specific leakage current of battery during float charge at 20 °C</p> <p>100 ... 0 mA per 100 Ah</p> <p>Approximate values:</p> <p>30 mA/100 Ah for new batteries</p> <p>80 mA/100 Ah for batteries strongly aged</p> <p>This value is NOT automatically determined by the Sunny Island. Battery management can therefore be optimized by manually adjusting the value from time to time.</p>

Table 8.3: Settings in menu “PARBAT“ (3+5)

8.6 Menu “PARGEN” (3+6), Parameters Generator

This menu can only be selected after the installer password (level: 1) has been entered.

In the menu “PARGEN” (3+6) the operator can change the parameters for a connected generator. Under the parameter “602_GenSet Type” the type of starting procedure can be defined. The Sunny Island provides three different starting procedures (see Fig. 12.1). The individual time periods within these procedures can also be set in the menu “PARGEN” (3+6).

```

3+6  STANDBY
602_GenSet Type
None
603_GenSet Inte
None
604_GenSet Ctr1
OFF
↳PARGEN PARGEN+↵
  
```

Fig. 8.8: Menu “PARGEN” (3+6)

“PARGEN” (3+6)		
Name	Description	
602_GenSet Type	None:	No generator present in island grid
	Grid forming:	Generator is grid-forming.
	Mains:	Sunny Island is operated on the public utility grid.
	BHKW-Mains	Sunny Island is operated together with an ecopower CHP and on the public utility grid
	BHKW-Island	Sunny Island is operated together with an ecopower CHP
	Mains form	Sunny Island is operated together with a grid-forming generator and on the public utility grid
	fast Grid form	Generator is grid-forming and it is switched between the generator and the Sunny Island without interruption (special installation measures are necessary for this)
	fast Mains	The Sunny Island is operated on the public utility grid and it is possible to switch from the Sunny Island as grid-former to the public utility grid without interruption. (special installa-

“PARGEN“ (3+6)		
Name	Description	
	fast Mains form	tion measures are necessary for this) The Sunny Island is operated together with a grid-forming generator and on the public utility grid. Switching takes place without interruption (special installation measures are necessary for this)
	DroopGen	The Sunny Island is operated together with a generator capable of droop characteristics in droop mode.
	DroopMains	The Sunny Island is operated together with a utility in droop mode.
	DrpGenMains	The Sunny Island is operated together with a generator capable of droop characteristics and a utility in droop mode.
	BHKW-Isl-Therm	Sunny Island is operated together with the ecopower CHP. In contrast to “BHKW-Island”, the Sunny Island will not switch off the CHP when no more electrical power is required. Thus, the ecopower CHP will be able to provide as much thermal energy as required.
603_GenSet Interf	None:	no generator start by Sunny Island
	Type 1:	Autostart, relays K1+K2
	Type 2:	3 contacts run / start, relays K1, K2, K6
	Type 3:	3 contacts run / Stopp, relays K1, K2, K6
	EcoPower	Ecopower CHP
	(see also Fig. 12.1: Starting phase sequence for different generator types)	
604_GenSet Ctrl	The Sunny Island reduces its current input in charge operation (RUN_I) ...	
	OFF:	... no reduction
	F_MAINS:	... reduction as a function of generator frequency
	I_GEN:	... as a function of generator current (converter required, see Chapter 3.4.5)
	BOTH:	... as a function of generator frequency and current (converter required, see Chapter 3.4.5)
605_GenStRetr	0 ... 30:	Max. number of attempts to start the generator, before the state “Fail Locked“ is reached (see also parameter 618). After the minimum run-time of the generator has expired, the counter will be reset.
606_CurTrfRatio	0 ... 1000 A per 5 A:	Current transformer ratio (in A per 5 A) for measurement of generator current
607_lgen max	0 ... 500 A:	Max. generator current (per phase)
610_tGen glow	1 ... 180 s:	Length of time the relay is controlled to glow up the generator
611_tGen crank	1 ... 60 s:	Length of time the relay is controlled to crank the generator
612_tGen warm	1 ... 900 s:	Warm-up time of generator
613_tGen minrun	1 ... 180 min:	Minimum run time of generator
614_tGen cool	1 ... 900 s:	Cooling time of generator

“PARGEN“ (3+6)		
Name	Description	
615_tGen stop	1 ... 180 s:	Length of time the relay is controlled to stop the generator
616_tGen lock	1 ... 180 min:	Period of time the generator – after having been stopped - cannot be restarted via the Sunny Island (can be shortened by acknowledgement in the “GENSET“ (2-2) menu)
617_tGen fail	1 ... 180 min:	Period of time the generator cannot be restarted via the Sunny Island after a generator failure (can be shortened by acknowledgement in the “GENSET“ (2-2) menu)
618_tGen faillock	1 ... 168 h:	Period of time the generator cannot be restarted via the Sunny Island after a certain number of failures as defined in “605_GenStRetr“ has occurred during start-up (can be shortened by acknowledgement in the “GENSET“ (2-2) menu)
625_PIdL GenOn	-100 ... 100 %	Switch-on threshold in % of the nominal power at one phase for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”
626_PIdL GenOff	-100 ... 100 %	Switch-off threshold in % of the nominal power at one phase for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”
627_PIdS GenOn	- 100 ... 100 %	Switch-on threshold in % of the nominal power based on the cumulative power within the three-phase system for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”
628_PIdS GenOff	- 100 ... 100 %	Switch-off threshold in % of the nominal power based on the cumulative power within the three-phase system for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”
629_TavgLdLx	5 ... 60 s	Averaging time for the power calculation per phase (see also “625_PIdL GenOn” and “626_PIdL GenOff”)
630_TavgLdSum	1 ... 20 min	Averaging time for the calculation of the cumulative power within the three-phase system (see also “627_PIdS GenOn” and “628_PIdS GenOff”)
631_PIdLzMin	0 ... 100 %	Lower limit for the charging state, when the Ecopower CHP will always be started
632_PIdLzMax	0 ... 100 %	Upper limit for the charging state, when the Ecopower CHP will never be started
633_PConsMin	0 ... 2000 W	Power limit for the load power (cumulative power averaged over all three phases within the time period of the parameter

“PARGEN“ (3+6)		
Name	Description	
	“630_TavgLdSum“), that has to be exceeded, in order to start the Ecopower CHP even in the case of charging states between “631_PldLzMin” and “632_PldLzMax“.	
634_PConsMax	0 ... 10.000 W	Upper limit for the load power (cumulative power averaged over all three phases within the time period of the parameter), when the Ecopower CHP will already be started in the case of a charging state of “632_PldLzMax“.
635_PChargeMax	0 ... 16.000 W	Setpoint for the charging power, that the Sunny Island obtains from the Ecopower CHP.
636_PDump1	0 ... 8.000 W	Power of Dumpload 1, that has to be connected to the relay K1 of the Sunny Island during the operation with the ecopower CHP. (“701_Man K1“ = Auto)
637_PDump2	0 ... 8.000 W	Power of Dumpload 2, that has to be connected to the relay K6 of the Sunny Island during the operation with the Ecopower CHP. (“706_Man K6“ = Auto)
638_PBHKWMin	0 ... 4.000 W	Minimum power of the Ecopower CHP
639_PBHKWMax	0 ... 10.000 W	Maximum power of the Ecopower CHP
640_BHKW_ton	0 ... 10.000 s	Minimum run-time of the Ecopower CHP
641_BHKW_toff	0 ... 10.000 s	Minimum pause time of the Ecopower CHP
642_BHKW_tmax	0 ... 20.000 s	Maximum run-time of the Ecopower CHP in mode 2 (fast control) 0: No limitation
644_PldOnLx	0 ... 3300 W	Activation of the Ecopower CHP when the load at one phase has been exceeded 0: No load-dependent activation
710 ... 715	Conditions for generator start: see Chapters 8.7 and 2.	

Table 8.4: Settings in menu “PARGEN“ (3+6)

Unlike all other special functions associated with the relays, the function to start the generator via K1 depends on the battery state and may also depend on the day time and can thus be defined by parameters 710 to 715, as shown in Chapter 8.7.

8.7 Menu “PARREL“ (3+7), Parameters Relays

This menu can only be selected after the installer password (level: 1) has been entered.




Fig. 8.9: Menu “PARREL“ (3+7)

In the menu “PARREL“ (3+7) you can define how the relays K1 to K8 (available as accessories) are to be controlled. In the state the Sunny Island is delivered in, none of the relays is controlled (setting “OFF”).

Manual

Each relay can be switched on and off individually any time by selecting the setting “ON“ or “OFF“.



After a restart the setting “ON“ is reset to “OFF“ for safety reasons. Settings for manual control mode (“ON“, “OFF“) override the automatic control by the Sunny Island.

As a function of the battery state and time of day??

There is also the possibility to switch the relays battery state dependent (see Chapter 2.2.2). Usually all relays can be used for this purpose unless they have been assigned special functions (see below).

To activate this function, the parameter “7xx_Man Kx” of the respective relay (e.g. for K1 it would be 701_Man K1”) has to be set to “AUTO”.

To define a switching operation, at least two battery states have to be chosen (“7xx_Kx On t1” and “7xx_Kx Off t1”). Depending on whether the state entered for the “On”-parameter is above or below the state entered for the “Off”-parameter, different kinds of switching modes will be performed as shown in Fig. 8.10 and Fig. 8.11.




Fig. 8.10: Switching operations recommended for el. consumers




Fig. 8.11: Switching operations recommended for el. feeders




Fig. 8.12: Switching behavior when „Kx On tx“ is equal to „Kx Off tx“




Fig. 8.13: Switching behavior: Exception

- To control energy sources it is advisable to choose an “On” state that is below the “Off” state, while in most cases the “ON state should be above the “Off” state in order to switch loads.



The fact whether the battery state for switch-on is higher or lower than the battery state for switch-off determines when a relay is actually switched.

As described above there are two different modes: “Consumer type” (switch-on limit is above switch-off limit) and “Feeder type” (switch-on limit is below switch-off limit). If the same battery state is set for both the switch-on and the switch-off limit the relay is controlled as for the “Consumer type” as also shown in Fig. 8.12.

If the same values have been entered under the parameters “7xx_Kx t2 begin” and “7xx_Kx t2 end” a simple setting to a battery state-dependent control of this relay has already been finished. Often, however – especially in island grids supplied by PV – an operating mode is desired where the devices are controlled depending on the battery state, but additionally also depending on the time of the day. To this end it is possible to define a second time period (“special time period t2”, lasting from “7xx_Kx t2 begin” to “7xx_Kx t2 end”, see also Fig. 8.14. For this second period, battery states

for switching of the relay can be selected again. The setting is made accordingly as described above, but with the parameters “7xx_Kx On t2” and “7xx_Kx Off t2”.



The new settings will only take effect after the Sunny Island has been re-started (by selecting “START” in the “START” (2-1) menu). If additional settings were made, the instructions indicated at the beginning of Chapter 8 should be followed.




Fig. 8.14: Exemplary settings for “special time period t2”

Special tasks

Some of the relays can be assigned special tasks. This depends on the settings in other menus:

Relay	Special function	Configurable in menu
K1	Generator start	"PARGEN" (3+6)
	"Dumpload 1" (for ecopower mini CHP)	"PARGEN" (3+6)
K2	Contactor control generator <> island grid	"PARGEN" (3+6)
K3	Contactor control grid <> island grid	"PARGEN" (3+6)
	Warming up/starting generator (up to BFR 1.09)	"PARGEN" (3+6)
K4	Contactor control Sunny Island <> island grid	"PARGEN" (3+6)
K5	Operating state indicator	"PARREL" (3+7)
	Power-related switching	"PARREL" (3+7)
	Measuring-point selection	"PARGEN" (3+6)
	Warming up/starting generator (BFR 1.10 up to BFR 1.49)	"PARGEN" (3+6)
K6	Operating state indicator	"PARREL" (3+7)
	Power-related switching	"PARREL" (3+7)
	Warming up/Starting generator (from BFR 1.50)	"PARGEN" (3+6)
	"Dumpload 2" (for ecopower mini CHP)	"PARGEN" (3+6)
K7	Battery room fan	"PARBAT" (3+5)
K8	Electrolyte pump	"PARBAT" (3+5)

Table 8.5: Special functions of relays

A special function is normally assigned indirectly. If e. g. a generator "type 2" has been set in the "PARGEN" (3+6) menu, the relay K1 is automatically assigned switching on the ignition, K2 is assigned the grid contactor of the generator and K5 the cranking of the generator.

The special functions of the individual relays are in turn activated by setting the respective parameters (701 to 708) to "AUTO". Only the special function "Operating state indicator" can be directly selected with these parameters.



If a relay has been assigned both a battery state-dependent control and a special function, only the special function is performed!

Exception: To start the generator via K1 the Sunny Island will abide by the settings of parameters 710 to 715.



The relays are controlled in regular operation only. If the Sunny Island is switched into standby mode, the AC voltage is missing or an error state occurs, all relays are dropped out after a short period of time, even when switched to “ON” in manual controlled mode

“PARREL“ (3+7)	
Name	Description
701_Man K1	Operating mode of relay K1 OFF: Switching relay K1 off ON: Switching relay K1 on AUTO: Sunny Island automatically controls relay K1.
702_Man K2	as parameter 701, but for K2
703_Man K3	as parameter 701, but for K3
704_Man K4	as parameter 701, but for K4
705_Man K5	Operating mode of relay K5 OFF: Switching relay K5 off ON: Switching relay K5 on AUTO: Sunny Island automatically controls relay K5. RUN: Relay is only switched on when Sunny Island is running. RUN_U: Relay is only switched on when Sunny Island is in grid-forming operation. RUN_I: Relay is only switched on when Sunny Island is in grid-tied operation. SYNC_HD: Relay is switched during transfer from grid-forming to grid-tied operation. SYNC_TK: Relay is switched during transfer from grid-tied to grid-forming operation. SYNC_HDTK: Relay is switched during any transfer from grid-tied to grid-forming operation or vice versa. GEN_MANU: Relay is switched if generator has already been started before the Sunny Island.

“PARREL“ (3+7)	
Name	Description
	LOAD: Relay is switched in relation to load (see parameter 625 to 630)
706_Man K6	as parameter 705, but for K6
707_Man K7	Operating mode of relay K7 OFF: Switching relay K7 off ON: Switching relay K7 on AUTO: Sunny Island automatically controls relay K7.
708_Man K8	as parameter 707, but for K8
710_K1 t2 begin	0 ... 23 h: Begin of special time period t2 for K1
711_K1 t2 end	0 ... 23 h: End of special time period t2 for K1
712_K1 On t1	L4 ... O3: Battery state where K1 is switched on.
713_K1 Off t1	L4 ... O3: Battery state where K1 is switched off.
714_K1 On t2	as parameter 712, but in special time period t2
715_K1 Off t2	as parameter 713, but in special time period t2
716_K2 t2 begin	as parameter 710, but for K2
717 ... 757	as above, but for K2 to K8

Table 8.6: Settings in the menu “PARREL“ (3+7)

8.8 Menu “PARSB” (3+8), Parameters Sunny Boy

This menu can only be selected after the installer password (level: 1) has been entered.




Fig. 8.15: Menu “PARSB” (3+8)

You should define settings in the menu “PARSB” (3+8) if there are Sunny Boy inverters in the island grid which are to be controlled by the Sunny Island via the RS485 interface (COM2). To this end a communication cable has to be installed between the Sunny Island and the Sunny Boy(s).

Depending on the Sunny Boy’s firmware it is also possible to control the Sunny Boys via the grid’s frequency without the need of a dedicated communication cable. In this case “801_Sunny Boys” should be set to “Frequency”).

In “droop mode” (see Chapter 2.1.3) the Sunny Boys have to be adjusted to and will be controlled via the P vs. f characteristics of the Sunny Island. Consequently, “801_Sunny Boys” should be set to “Not installed” in this mode.

In order to shut down all frequency-sensitive power sources connected to the grid, the Sunny Island can raise the grid’s frequency (running in RUN_U) when no more power can be fed into the battery. Nevertheless, more energy will be supplied into the AC-grid than can be used by all loads. In this case, this “emergency cutout mode” prevents the system to shut down completely when the sources are not capable of derating via frequency or RS485 communication.

“PARSB“ (3+8)	
Name	Description
801_Sunny Boys	<p>Not installed: Sunny Island is not to control Sunny Boys.</p> <p>Installed: Sunny Island is to control Sunny Boys (via COM2)</p> <p>Inst. Mains: Sunny Island is to control Sunny Boys only if grid feeding is not possible (via COM2)</p> <p>Frequency: Sunny Island is to control Sunny Boys via AC frequency (depending on Sunny Boy's firmware) in operation mode RUN_U</p>

Table 8.7: Settings in the menu “PARSB“ (3+8)

8.9 Menu “PARALL” (3+9), all Parameters

This menu can only be selected after the installer password (level: 1) has been entered.




Fig. 8.16: Menu “PARALL” (3+9)

The menu “PARALL” (3+9) comprises all parameters from the “PARxxx” menus described in the chapters above. Therefore you can change the parameters from different areas in this menu without having to select the corresponding special menu. E. g. this can facilitate configuration of newly installed, complex island grid plants.

As it makes no difference whether parameters are changed in this general menu or in the respective special menu, it is important as well to set up the parameters with special care and only with the required technical know-how.



Special care has to be applied when changing the settings. Incorrect or missing settings can lead to damage to the Sunny Island as well as to the connected plant components! Settings must always be changed by the installer or another qualified person.

9 Operating Data (DATA)




Fig. 9.1: STATUS and menu selection “DATA” (0-1)

What makes the Sunny Island so special are its comprehensive control and powerful system management. For these two it is necessary to acquire the most different electrical and physical variables. The operator can access them in the menu branch “DATA”.




Fig. 9.2: Menu branch “DATA”

In normal operation a selection of the most important measured values is continuously shown on the Sunny Island display. In addition, the current state of the relay is displayed by pressing the [**ESC**] – button.




Fig. 9.3: STATUS and state of the relay

You can go back to the window „STATUS and menu selection ‚DATA‘ (0-1)“ (see Fig. 9.1) by pressing any button.

The values displayed are:

Measured value	Description
LZ	Actual battery state of charge (SOC act), also as bar
BAZ	Battery state (Bat State)
PSI	AC power of Sunny Island (Pconv), also as bar positive: discharging power; negative: charging power
PSUM	Cumulative AC power of connected Sunny Islands (Pconv Sum), (for example, in case of three-phase system), also as bar positive: discharging power; negative: charging power
Relais	Display of the relay state x: relay control is not enabled (operating mode set to “OFF”) o: relay control is enabled, but relay is not activated l: relay is activated

Table 9.1: Spot values shown in “DATA“ (0-1)

9.1 Menu „DATAV“ (1-0), Overview of Measured Values




Fig. 9.4: Menu „DATAV“ (1-0)


An overview of the current values is displayed in the menu „DATAV“ (1-0), similarly to the both menu STATUS. Whereas the STATUS display rather serves as a fast function control, the menu „DATAV“ is a support for installation and optimization of the system.

The values displayed are:

Section	Description
BAT	Actual battery voltage (“Ubat mean”), target battery voltage (“Uchrg act”),
	Battery state (“Bat State”), actual battery state of charge (“SOC act”), battery current (“ibat mean”), positive: battery is discharged, negative: battery is charged
AC	Voltage at the AC output port of the Sunny Island (“Uconv eff”), frequency of the AC output voltage (“Fconv”)
	Power of the Sunny Island (“Pconv”), positive: battery is discharged, negative: battery is charged
XT	Voltage at the Generator / Mains sync input port of the Sunny Island (“Uext eff”), frequency of the Generator / Mains sync voltage (“Fext”)
	Power of the generator (“Pext”), measured via Generator / Mains Sync input port and Generator / Mains current terminal If an “ecopower Mini-BHKW” is installed, this equals the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
GEN	Generator status (“GenState”), appears / disappears by pressing [ENTER]

Table 9.2: Values shown in „DATAV“ (1-0)

9.2 Menu “DATSYS” (1-1), System Data



```


1-1  STANDBY
SN:  1213600047
Vers: 2.16B  2.12
UP:   0.0h

DATAU  DATSYS→
  
```

Fig. 9.5: Menu “DATSYS (1-1)

The menu “DATSYS (1-1)” shows internal data of the Sunny Island. These are the serial number, the release number of the firmware version for system management and control as well as the so-called up-time (total operating hours).

9.3 Menu “DATALL” (1-2), Overall Plant Data



```

1-2  STANDBY
Status
STANDBY
Batt. Ah In
0.00 Ah
Batt. Ah Out
0.00 Ah
←DATSYS  DATALL→
  
```

Fig. 9.6: Menu “DATALL” (1-2)


Table 9.3 explains only the plant data which are visible to the operator (password level: 0). You will find a complete list of all plant data in the appendix.

“DATALL“ (1-2)	
Name	Description
Mode	Current operating mode
Pext Sum	Total of active generator power (three phases) If an “ecopower Mini-BHKW” is installed this equals the sum of the Sunny Island’s power and the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
Bat State	Current battery state (see Chapter 2.2.2)
SOC act	Actual battery state of charge (in per cent)
Pbat Sum	Total battery power (three phases)
Ibat Sum	Total battery current (three phases)
GenState	Operating state of the generator
GenFail	Error of the generator
K1 State	Switch state of relay K1
K2 State	Switch state of relay K2
K3 State	Switch state of relay K3
K4 State	Switch state of relay K4
K5 State	Switch state of relay K5
K6 State	Switch state of relay K6
K7 State	Switch state of relay K7
K8 State	Switch state of relay K8
Fext	Frequency at Generator / Mains sync. input
Uext eff	RMS value of voltage at Generator / Mains sync. input
Iext eff	RMS value of current at Generator / Mains current input
Pext	Power of generator connected to Generator / Mains sync. and current inputs If an “ecopower Mini-BHKW” is installed this equals the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
Ubat mean	Mean value of battery voltage
Ibat mean	Mean value of battery current
Pbat mean	Mean value of battery power
Tbat mean	Mean value of battery temperature
Fconv	Current AC output frequency
Uconv eff	Current AC output voltage
Iconv eff	RMS value of current AC output current
Pconv	Current AC active power Sunny Island
Sconv	Current AC apparent power Sunny Island
SOC diff	Estimated error of the calculated actual battery state of charge (“SOC act”)

Table 9.3: Menu “DATALL“ (1-2), password level: 0

9.4 Menu “DATBAT“ (1+3), Battery Data

This menu can only be selected after the installer password (level: 1) has been entered.



The screenshot shows a monochrome display with the following text:

```
1+3  STANDBY
Bat State
L1
SOC act
50.0 %
Ubat mean
60.50 V
←DATALL  DATBAT→
```

Fig. 9.7: Menu “DATBAT“ (1-3)

As there is a very large number of plant data shown in the complete (level: 1) menu “DATALL“ (1-2), the menu “DATBAT“ (1+3) only shows those data concerning the battery:

“DATBAT“ (1+3)	
Name	Description
Bat State	Current battery state
SOC act	Actual battery state of charge
Ubat mean	Mean value of battery voltage
Uchrg act	Setpoint value of battery voltage
Ibat mean	Mean value of battery current
Ibat Sum	Total of battery current SI (three phases)
Tbat mean	Mean value of battery temperature
Pbat mean	Mean value of battery power
Pbat Sum	Total battery power SI (three phases)
SOC RSK	State of charge of module open-circuit voltage calibration
SOC dff RSK	Estimated error of the state of charge “SOC RSK”
Cbat act	Actual capacity
Qdn full	Charge throughput (discharge) since last full charge
Qdn equal	Charge throughput (discharge) since last equalizing charge
tpast full	Time since last full charge
tpast equal	Time since last equalizing charge
t Uconst charge	Time of constant U phase for normal charges
t Uconst full	Time of constant U phase for full charges
t Uconst equal	Time of constant U phase for equalizing charges
ChargeOper	Actual charge mode
SOC AHB	State of charge of full charge calibration
SOC diff AHB	Estimated error of the state of charge “SOC AHB”

Table 9.4: Menu “DATBAT“ (1+3)

9.5 Menu “DATGRD” (1+4), Grid Data

This menu can only be entered after the installer password (level: 1) has been entered.




Fig. 9.8: Menu “DATGRD” (1+4)

As there is a very large number of plant data shown in the complete (level: 1) menu “DATALL” (1-2), the menu “DATGRD” (1+4) only shows those data concerning the AC island grid:

“DATGRD“ (1+4)	
Name	Description
Uconv eff	Current grid voltage
Fconv	Current grid frequency
Iconv eff	Grid current (RMS value)
Iconv Sum	Inverter current (three phases)
Pconv	Active grid power Sunny Island
Pconv Sum	Total of active grid power Sunny Island (three phases)
Qconv	Reactive grid power Sunny Island
Qconv Sum	Total of reactive grid power SI (three phases)
Sconv	Apparent grid power Sunny Island
Sconv Sum	Total of apparent grid power Sunny Island (three phases)
Uext eff	RMS value of voltage on Generator / Mains sync. input
Fext	Current grid frequency at synchronous input port
Iext eff	Current generator current (of converter)
Iext Sum	Total of generator current (three phases)
Pext	Current active generator power If an “ecopower Mini-BHKW” is installed this equals the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
Pext Sum	Total of active generator power (three phases) If an “ecopower Mini-BHKW” is installed this equals the sum of the Sunny Island’s Power and the power of the CHP unit, as received from by the Sunny Island on its COM3 port.

Table 9.5: Menu “DATGRD“ (1+4)

10 Diagnosis (DIAG)




Fig. 10.1: Menu selection “DIAG” (0-4)

The Sunny Island has a very powerful system management. It makes it possible to adjust the controlling behavior of the Sunny Island precisely to the connected island grid and its components. To be able to optimize the required settings it is helpful to have a look at the history of the plant’s behavior. However, the operator should not be dependent on a PC that has to be operating all the time to be able to view these data. Therefore, the Sunny Island not only continuously acquires changes of its operating state (“events”), but also any excess of a limiting value or error (“alerts”).

“Alerts” are to be divided into more serious ones that the user has to confirm, and less serious ones which are merely recorded in the error list (see Chapter 18). The “DIAG” (0-4) menu selection shows the error status of the system. The menu branch itself comprises detailed lists of the latest errors and system states. For a clear distinction, “events” are marked with an “E” in front, “alerts” with an “A”.




Fig. 10.2: Menu branch “DIAG”

If an error has occurred or a limiting value has been exceeded, the Sunny Island first switches to the operating state “FAULT” for a few seconds.



Selecting the menu item “Acknowledge” in the menu “ACKN” (4-1) shortens the time the inverter is in “FAULT” state even if the type of error occurred does not have to be confirmed.

Subsequently the Sunny Island switches to the operating state “STANDBY”. This means that an automatic starting attempt can be made if this has been activated with the parameter “310_Auto Start” (e. g. in the menu “PARSYS” (3+3)).

If an error state that has made the Sunny Island switch off persists, the Sunny Island first performs the defined number of starting attempts and subsequently switches to the operating state “STANDBY”.



The Sunny Island may start autonomously! Keep this in mind when you want to work on the island grid. Always switch off the AC fuses of all Sunny Islands in the island grid first!

“DIAG” (0-4)	
Parameter	Description
Pending:	Number of errors occurred and detected
Not Ackn.:	Number of errors still to be confirmed by the operator
Current Error:	Error occurred last and still present

Table 10.1: Displayed menu selection “DIAG” (0-4)

10.1 Menu “ACKN” (4-1), Error Confirmation




Fig. 10.3: Menu “ACKN” (4-1)

This menu always shows the last serious error that has occurred. The operator has to confirm this error state by selecting the menu item “Acknowledge”. If there are more than one of those error messages they have to be confirmed one after the other.

10.2 Menu “HISTOR” (4-2), Overall Protocol




Fig. 10.4: Menu “HISTOR” (4-2)

This menu comprises a chronological list of all changes of operating states logged by the Sunny Island (“events”), exceeded limiting values and errors (“errors”, “alerts”). The date and time of occurrence are logged as well for each of these. A list of messages available is provided in Chapter 18.

10.3 Menu “ERRHIS” (4-3), Error Protocol

```

4-3  STANDBY
25.11.18:32:03C
A0042 Battery
Voltage Low
25.11.18:31:57S
A0042 Battery
Voltage Low
⇐HISTOR ERRHIS⇒
  
```

Fig. 10.5: Menu “ERRHIS” (4-3)

The menu “ERRHIS” (4-3) lists the exceeded limiting values and errors occurred that are shown in the menu “HISTOR” (4-2).

10.4 Menu “EVTHIS” (4-4), State Protocol

```

4-4  STANDBY
25.11.17:29:32
E0014 STANDBY

25.11.17:29:04
E0001 Reset

⇐ERRHIS EVTHIS⇒
  
```

Fig. 10.6: Menu “EVTHIS” (4-4)

The menu “EVTHIS” (4-4) lists the changes of operating states that are shown in the menu “HISTOR” (4-2).

11 Island Grids – Examples

This chapter covers basic examples for island grids that can help engineers and installers to understand island grids based on the Sunny Island. It refers to parameter settings that usually have to be made in order to operate in a specific configuration. Due to the fact that the plant configuration can differ from the examples quoted here, the configuration of the Sunny Island can differ from the parameter settings suggested below. All examples show the wiring only in principle. Additional measures (such as circuit breakers or special groundings) might be mandatory depending on local regulations. All wiring diagrams show single-phase systems only. Three-phase systems can easily be performed accordingly.

A more detailed description of the parameters can be found in Chapter 16.



To be sure that the modified parameters will take effect, please follow the steps below:

1. Set any parameter that has to be changed.
2. Select „Store Permanent“ in the „FUNCT“ (2+3) menu (alternatively wait for at least 30 seconds without pressing any buttons).
3. Restart the Sunny Island by selecting “Restart” in the “FUNCT” (2+3) menu (confirm the appearing question “RESTART ?” with <YES> by pressing [**ENTER**]).

11.1 Photovoltaically powered Island Grid

Fig. 11.1 shows a basic example for an island grid using exclusively solar energy. To reduce the requirements in terms of battery and PV generator size it is possible to provide an additional circuitry (see Fig. 12.5) that allows the temporary connection of an external generator whenever necessary. In an island grid that only consists of power sources based on renewable energy optimum battery management can only be guaranteed if it is combined with load management. This is due to the fact that energy yield may vary strongly depending on the season. The Sunny Island is optimized for the integration of grid-feeding PV inverters, especially Sunny Boys, in an island grid and allows sophisticated load management. The Sunny Boy inverters and the Sunny Island communicate via the COM2 interface (RS485). Via this interface the Sunny Island derates the output power of the Sunny Boys, in case the battery is about to be overcharged. Even a derating of the power without additional cabling via the frequency is possible and recommended. (This depends on the Sunny Boys firmware version)

Disconnection of consumers

In an island grid that does not include a feeder available at any time (combustion aggregate) the consumers connected should be classified in terms of which battery states have to be reached for the Sunny Island to switch them off or - if required - switch them on. This allows a careful operation of the battery and a high reliability of the most important consumers. Any consumers in the island grid whose temporary switch-off will not have serious consequences (such as air conditioning) should be used in order to reduce consumption within the island grid in case of a low battery. The Sunny Island should disconnect these consumers via one of the freely configurable relays (K1 to K8) if for example the battery state N3 or N4 is reached. When battery state L2 is reached all consumers – if possible - should be switched off at the latest. A model for wiring is shown in Chapter 3.4.10.



Even in island grids with feeders independent of weather conditions we recommend to wire up the consumers in a way to be able to switch them off with the Sunny Island (via one of the relays K1 to K8). Especially in case of a failure (generator defective etc.) the battery can thus be protected against harmful conditions and emergency operation can be made as efficient as possible.

Emergency operation

In case of a flat battery in a purely PV-supplied island grid (when the battery state reaches one state below the one that was defined in parameter “535_State StopT”) the Sunny Island has an operating mode allowing to make the AC grid available to feeders nonetheless. In this mode the inverter generates the grid voltage for a few minutes every four hours over the day and detects whether there is enough feeding power to charge the battery. This is an effective way to avoid a long-term total shut-down of the system even under the worst conditions. This feature is only active if the parameter “310_Auto Start” is not set to zero.

Please refer to Chapter 2.2 for details.




Fig. 11.1: Sunny Island + PV

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island.

Parameter	Unit	Default	Description	Master	Slaves
401_Phase Mode		1Phs_Single	Device setting	1Phs_Single (?)	3Phs_Slv1L2 / L3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
706_Man K6		OFF	Operation mode of K6	AUTO	X
801_Sunny Boys		Not installed	Control method for the Sunny Boys	Frequency (?)	Not installed (?)
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Master	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
740_K6 t2 begin	h	0	Start of special period t2 for K6	?	X
741_K6 t2 end	h	0	End of special period t2 for K6	?	X
742_K6 On t1		N3	Switch-on threshold for K6	?	X
743_K6 Off t1		N3	Switch-off threshold for K6	?	X
744_K6 On t2		N3	Switch-on threshold in special period t2 for K6	?	X
745_K6 Off t2		N3	Switch-off threshold in special period t2 for K6	?	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them their default values should be retained unchanged.

For a more detailed description of the parameters refer to Chapter 16.

11.2 Photovoltaically powered Island Grid with Generator

The energy of the island grid shown in Fig. 11.2 derives from both photovoltaic generators and a combustion engine. Normally, the voltage and frequency of the island grid are specified by the Sunny Island. If additional energy is necessary, the Sunny Island activates the generator functioning as grid-forming element and switches to grid parallel operation (RUN_I, see Chapter 2.1.2). Thus, the voltage and frequency of the island grid is then controlled by the generator.



Even in island grids with feeders independent of weather conditions it is recommended to wire up the consumers in a way to be able to switch them off by the Sunny Island (via one of its remaining relays). Especially in case of a failure (generator defective etc.) the battery can thus be protected against harmful conditions and emergency operation can be made as efficient as possible.




Fig. 11.2: Sunny Island + PV + Genset

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island.

Parameter	Unit	Default	Description	Master	Slaves
401_Phase Mode		1Phs_Single	Device setting	1Phs_Single (?)	3Phs_Slv1L2 / L3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
602_GenSet Type		None	Generator type	fast Grid form (?)	X
603_GenSet Interf		None	Generator interface	Type 1 (?)	X
604_GenSet Ctrl		OFF	Generator load limiting	I_GEN (?)	I_GEN (?)
606_CurTrfRatio	Ain/5 Aout	5	Current transformer ratio	?	?
607_Igen max	A	0	Max. generator current (per phase)	?	?
701_Man K1		OFF	Operation mode of K1	AUTO	X
702_Man K2		OFF	Operation mode of K2	AUTO	AUTO
704_Man K4		OFF	Operation mode of K4	AUTO	X
706_Man K6		OFF	Operation mode of K6	AUTO	X
801_Sunny Boys		Not installed	Control method for the Sunny Boys	Frequency (?)	Not installed
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Master	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
710_K1 t2 begin	h	0	Start of special period t2 for K1	?	X
711_K1 t2 end	h	0	End of special period t2 for K1	?	X
712_K1 On t1		N4	Switch-on threshold for K1	?	X
713_K1 Off t1		N1	Switch-off threshold for K1	?	X
714_K1 On t2		N4	Switch-on threshold in special period t2 for K1	?	X
715_K1 Off t2		N1	Switch-off threshold in special period t2 for K1	?	X
740_K6 t2 begin	h	0	Start of special period t2 for K6	?	X
741_K6 t2 end	h	0	End of special period t2 for K6	?	X
742_K6 On t1		N3	Switch-on threshold for K6	?	X
743_K6 Off t1		N3	Switch-off threshold for K6	?	X
744_K6 On t2		N3	Switch-on threshold in special period t2 for K6	?	X
745_K6 Off t2		N3	Switch-off threshold in special period t2 for K6	?	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them, their default values should be retained unchanged.

For a more detailed description of the parameters refer to chapter 14..



In a three-phase system each Sunny Island has to be equipped with a "SI-PBRE" for K2. All contacts of these relays have to be connected in serial to control the generator contactor.

11.3 Mains Backup System with Photovoltaics

A special version of a mains backup system is shown Fig. 11.3. It is possible in this configuration to feed the solar energy into the public grid as long as the grid is available. In case of public grid failure, the solar energy will automatically be used to supply the arising island grid. Even a discrete billing of solar energy fed into the public grid is possible.



This type of plant configuration requires a very sophisticated planning and commissioning in order to prevent any kind of accident with live wires that are assumed to be safe to touch. All local regulations and laws must be met and the approval of the public utility company is mandatory!




Fig. 11.3: Sunny Island + Mains + PV

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island.

Parameter	Unit	Default	Description	Master	Slaves
401_Phase Mode		1Phs_Single	Device setting	1Phs_Single (?)	3Phs_Slv1L2 / L3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
602_GenSet Type		None	Generator type	fast Mains (?)	X
703_Man K3		OFF	Operation mode of K3	AUTO	AUTO
704_Man K4		OFF	Operation mode of K4	AUTO	X
801_Sunny Boys		Not installed	Control method for the Sunny Boys	Frequency	Not Installed
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Master	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them, their default values should be retained unchanged.

For a more detailed description of the parameters refer to Chapter 16.



In a three-phase system each Sunny Island has to be equipped with a SIPBRE-OE for K3. All contacts of these relays have to be connected in serial to control the mains contactor.

11.4 Mains Backup System with Generator and PV

For mains backup systems with frequent long-term grid failures it might be expedient to integrate a genset. The Sunny Island is capable of controlling this configuration as well, as shown in Fig. 11.4.

Fig. 11.4 shows a system without the opportunity for a discrete billing of solar energy fed into the public grid. But this function can easily be integrated (cf. Fig. 11.3).



This type of plant configuration requires a very sophisticated planning and commissioning in order to prevent any kind of accident with live wires that are assumed to be safe to touch. All local regulations and laws must be met and the approval of the public utility company is mandatory!




Fig. 11.4: Sunny Island + Mains + Generator + PV

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island.

Parameter	Unit	Default	Description	Master	Slaves
401_Phase Mode		1Phs_Single	Device setting	1Phs_Single (?)	3Phs_Slv1L2 / L3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
602_GenSet Type		None	Generator type	fast Mains form (?)	None
603_GenSet Interf		None	Generator interface	Type 1 (?)	X
604_GenSet Ctrl		OFF	Generator load limiting	I_GEN (?)	I_GEN (?)
606_CurTrfRatio	Ain/5 Aout	5	Current transformer ratio	?	?
607_Igen max	A	0	Max. generator/mains current (per phase)	?	?
701_Man K1		OFF	Operation mode of K1	AUTO	X
702_Man K2		OFF	Operation mode of K2	AUTO	AUTO
703_Man K3		OFF	Operation mode of K3	AUTO	AUTO
704_Man K4		OFF	Operation mode of K4	AUTO	X
705_Man K5		OFF	Operation mode of K5	AUTO	X
801_Sunny Boys		Not installed	Control method for the Sunny Boys	Frequency	Not Installed
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Master	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
710_K1 t2 begin	h	0	Start of special period t2 for K1	?	X
711_K1 t2 end	h	0	End of special period t2 for K1	?	X
712_K1 On t1		N4	Switch-on threshold for K1	?	X
713_K1 Off t1		N1	Switch-off threshold for K1	?	X
714_K1 On t2		N4	Switch-on threshold in special period t2 for K1	?	X
715_K1 Off t2		N1	Switch-off threshold in special period t2 for K1	?	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them, their default values should be retained unchanged.

For a more detailed description of the parameters refer to Chapter 16.



In a three-phase system each Sunny Island has to be equipped with a SIBPRE for K2 and a SIPBRE-OE for K3. All contacts of the K2 relays have to be connected in serial to control the generator contactor. All contacts of the K3 relays have to be connected in serial to control the mains contactor.

11.5 Integrating CHP-Units

If both electricity and heat is needed in a system, using a combined heat and power unit will be advisable. The Sunny Island has special functions to support particularly CHP units of the type „ecopower Mini-BHKW“, distributed by VALENTIN Energie- und Umwelttechnik GmbH, Germany.



Be sure that the „ecopower Mini-BHKW“'s communication capability is enabled!

As CHPs will normally be thermally driven and also for some particular control purposes, some dedicated dumploads have to be available in the system as outlined in Fig. 11.5. (Please also cf. Chapters 3.4.11 and 3.4.12.)




Fig. 11.5: Sunny Island + CHP + PV

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island.

Parameter	Unit	Default	Description	Master	Slaves
401_Phase Mode		1Phs_Single	Device setting	1Phs_Single (?)	3Phs_Slv1L2 / L3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
602_GenSet Type		None	Generator type	BHKW-Island	None
603_GenSet Interf		None	Generator interface	Eco Power	X
636_PDump1	W	500	Power of Dumpload 1	500 (?)	X
637_PDump2	W	2000	Power of Dumpload 2	2000 (?)	X
646_PDump3	W	4500	Power of Dumpload 3	4500 (?)	X
701_Man K1		OFF	Operating mode of K1	AUTO	X
702_Man K2		OFF	Operating mode of K2	AUTO	X
706_Man K6		OFF	Operating mode of K6	AUTO	X
710_K1 t2 begin	h	0	Start of special period t2 for K1	?	X
711_K1 t2 end	h	0	End of special period t2 for K1	?	X
712_K1 On t1		N4	Switch-on threshold for K1	?	X
713_K1 Off t1		N1	Switch-off threshold for K1	?	X
714_K1 On t2		N4	Switch-on threshold in special period t2 for K1	?	X
715_K1 Off t2		N1	Switch-off threshold in special period t2 for K1	?	X
801_Sunny Boys		Not installed	Control method for the Sunny Boys	Frequency (?)	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Master	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
631_PldzMin	%	60	Charging state below which CHP will always be started	?	X
632_PldzMax	%	85	Charging state above which CHP will ever be started	?	X
633_PConsMin	W	1000	Lower limit for load power	?	X
634_PConsMax	W	3000	Upper limit for load power	?	X
635_PChargeMax	W	3000	Setpoint for charging power	?	X
644_PldOnLx	W	0	Load-dependent activation of CHP	?	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them, their default values should be retained unchanged.

For a more detailed description of the parameters refer to Chapter 16.

11.6 Multiple Sunny Island Systems (w/ Data interchange)

Even in systems with high overload capable devices, such as the Sunny Island, there may be the demand for higher power. To this end, it is possible to connect Sunny Islands in parallel.

11.6.1 Single-Phase System

In a single-phase system it is possible to connect up to three Sunny Islands in parallel to the same battery. As only one of these Sunny Islands will have the opportunity to perform the battery management and the control of the generator, this has to know the actual battery current of all Sunny Islands. A communication cable between the COM1 ports of the Sunny Islands is therefore required.




Fig. 11.6: Three Sunny Islands, single-phase system w/ data interchange

An extra feature possible due to this configuration is the load-dependent en-/disabling of the additional Sunny Islands (see Fig. 11.7).



For a proper operation either all of the parameters „422_Ps2off“, „423_Ps2on3off“ and „424_Ps3on“ have to be set to reasonable values, or they all have to be left at their default values.

If only two Sunny Islands are provided in the system „424_Ps3on“ and „423_Ps2on3off“ should be set to the same values.




Fig. 11.7: Load-dependent en-/disabling of the additional Sunny Islands

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island.

Parameter	Unit	Default	Description	Master	Slaves
401_Phase Mode		1Phs_Single	Device setting	1Phs_Mstr3 (?)	1Phs_Slv2 / 3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
602_GenSet Type		None	Generator type	fast Grid form (?)	None
603_GenSet Interf		None	Generator control method	Type 1 (?)	X
701_Man K1		OFF	Operating mode of K1	AUTO	X
702_Man K2		OFF	Operating mode of K2	AUTO	AUTO
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Master	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
422_Ps2off	kW	0,00	Cumulative load limit for switching off Slave2	2,00 (?)	X
423_Ps2on3off	kW	0,00	Cumulative load limit for switching on Slave2 resp. switching off Slave3	4,00 (?)	X
424_Ps3on	kW	0,00	Cumulative load limit for switching on Slave3	7,5 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
710_K1 t2 begin	h	0	Start of special period t2 for K1	?	X
711_K1 t2 end	h	0	End of special period t2 for K	?	X
712_K1 On t1		N4	Switch-on threshold for K1	?	X
713_K1 Off t1		N1	Switch-off threshold for K1	?	X
714_K1 On t2		N4	Switch-on threshold in special period t2 for K1	?	X
715_K1 Off t2		N1	Switch-off threshold in special period t2 for K1	?	X
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them, their default values should be retained unchanged.

For a more detailed description of the parameters refer to Chapter 16.

11.6.2 Three-Phase System

Up to two three-phase Sunny Island clusters can be connected in parallel. In order to be able to control a generator, the clusters have to communicate their energy states. A communication cable is therefore required (in addition to the synchronization cabling on COM1). This cable has to be attached to the COM2-ports of the Slave2's resp. the Slave3's of each cluster as shown in Fig. 11.8.

It is also visible that in this configuration each cluster needs its own battery.

The recommendations given for the parameter settings refer to a system including a generator. For systems without a generator please refer to Chapter 11.7.2.



The parameter „603_GenSet Interf“ has to be set equally for each Master. This means, that the corresponding relays of all Masters in the system are not available anymore for any other purposes, even though the generator is controlled by the relays of the „Super Master“ only.




Fig. 11.8: Two three-phase clusters in parallel w/ data interchange

Parameter settings, mandatory in this configuration

The following parameters have to be set for a proper operation of the Sunny Island. The term “cluster1” refers to the cluster that is meant for controlling the generator (if existing).

Parameter	Unit	Default	Description	Masters	Slaves
401_Phase Mode		1Phs_Single	Device setting	3Phs_Mstr1 Set	3Phs_Slv1 L2 / L3
501_Cbat nom	Ah	350	Nom. battery capacity (C10)	?	X
502_Bat Type		Lead-Acid	Battery type	?	X
503_Ubat nom	V	60	Nom. battery voltage	60 (?)	X
504_Ubat min	V	51	Min. permissible battery voltage	51 (?)	51 (?)
505_Ubat max	V	84	Max. permissible battery voltage	81 (?)	81 (?)
601_GenSet Oper		Auto	Generator control method	Cluster1: Auto Cluster2: Man. Stop	X
602_GenSet Type		None	Generator type	DroopGen	DroopGen
603_GenSet Ctrl		OFF	Control interface for the generator	Type 1 (?)	X
647_ClustMode		Off	Function to be fulfilled in a two cluster configuration	Cluster1: SupMstr Cluster2: ClstMstr	Slave2: Reprtr Slave3: Off
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Parameter settings, recommended for this configuration

The proper settings of the following parameters should be checked. In general, the system should function well with the default values, but minor optimizations might be advisable.

Parameter	Unit	Default	Description	Masters	Slaves
310_Auto Start		0	Number of autostart attempts	3 (?)	X
506_acid density	kg/l	1,24	Nom. acid density acc. to manufacturer	1,24 (?)	X
509_Tbat max	°C	40	Max. battery temperature permissible	40 (?)	X
710_K1 t2 begin	h	0	Start of special period t2 for K1	?	X
711_K1 t2 end	h	0	End of special period t2 for K1	?	X
712_K1 On t1		N4	Switch-on threshold for K1	?	X
713_K1 Off t1		N1	Switch-off threshold for K1	?	X
714_K1 On t2		N4	Switch-on threshold in special period t2 for K1	?	X
715_K1 Off t2		N1	Switch-off threshold in special period t2 for K1	?	X
801_Sunny Boys		Not installed	Control method for the Sunny Boys	Not installed (?)	Not Installed
X: don't care; ?: system-dependent; <value>(?): preferred setting, but system-dependent at last					

Many more parameters will have an effect on the system. But unless there are cogent reasons to change them, their default values should be retained unchanged.

For a more detailed description of the parameters refer to Chapter 16.

11.7 Multiple Sunny Island Systems (w/o Data interchange)

Sunny Islands with firmware 3.00², and higher are able to operate in parallel without any communication. The information about the energy resp. load status is derived solely from the frequency and the voltage of the AC grid („droop mode“, see Chapter 2.1.3).

This means, as a side effect, that it is not possible to synchronize the island grid to an external generator/utility in this mode, because any frequency and voltage variation will inevitably lead to an undesirable misinterpretation by all Sunny Islands. In fact an integration of an external, grid forming energy source is only possible if it a) can synchronize itself to the grid and b) is capable of adjusting to P vs. f and Q vs. V characteristics (see Fig. 2.3 and Fig. 2.4).

As PV-inverters of the Sunny Boy family can be prepared for adjusting to the P vs. f characteristics there is no need for special settings in the Sunny Islands concerning their power limiting.

In this operating mode each Sunny Island acts independently from other Sunny Islands. Each Sunny Island (resp. each three-phase cluster) has therefore to be connected to its own battery.

There is no limit in the number of Sunny Islands in such systems in principle. However, without further considerations it should be limited to four Sunny Islands connected in parallel per phase to play it safe.

² estimated completion date: 4Q/04

11.7.1 Single-Phase System




Fig. 11.9: Single-Phase System

11.7.2 Three-Phase System




Fig. 11.10: Three-Phase System

11.7.3 Mixed Single/Three-Phase Systems

In case of different utilizations of the different phases it is even possible to back one or two of the phases with additional Sunny Islands, each running in single-phase droop mode.



Make sure that in such systems the device that provides for the correct angle between the three phases is of redundant dimensioning as its failure will lead to an uncontrolled shifting of all phases!

It should be strived for a well-balanced existence of loads and sources on each phase in order to avoid needless and inefficient power transfer between the phases through the three-phase Sunny Island clusters.




Fig. 11.11: Three-phase system with backup single phase Sunny Islands

12 Terminal Diagrams for Generator Options

For simple and fast installation you can see on the following pages examples for wiring to connect a generator to an island system. The examples are based on single-phase island systems. In principle the same installation measures have to be performed when erecting a three-phase island system. Three-phase options are not shown here so as not to confuse the reader.

12.1 Stationary Generators




Fig. 12.1: Starting phase sequence for different generator types

* depending on the firmware version, other relays are used for this feature (see Table 8.5)




Fig. 12.2: Single-phase island system with generator “type 1” (automatic start)




Fig. 12.3: Single-phase island system with generator “type 2”




Fig. 12.4: Single-phase island system with generator “type 3”

12.2 Temporarily connected Generators

In plants with a scarce battery storage capacity and without a motorized generator, i. e. where the only feeders are photovoltaic or wind generators, it may become necessary to have the battery recharged by a mobile generator. This can be the case when unfavorable weather conditions persist for a longer time period.

For this purpose the operator can use a special terminal box available from SMA as an accessory (SMA order code “SI-GENCASE.01”) which can be firmly installed in the plant. The circuit diagram is shown in Fig. 12.5. The figure also shows the connection of an external generator in different operating modes and includes instructions for operation.

According to the current configuration, it may be necessary to change several parameters, so that the following settings apply:

Parameter	Value
401_Phase Mode	1Phs_Single (see Chapter 8.4)
602_GenSet Type	Mains
603_GenSet Interf	Type 1
702_Man K2	AUTO

Table 12.1: Setting for the external charge of the battery

In addition, the automatic generator control of the Sunny Island **must not** be deactivated (menu „GENSET“ (2-2), see Chapter 7.2).




Fig. 12.5: External charging of the battery by an auxiliary generator

12.3 “ecopower Mini-BHKW”, CHP-units

In systems where not only electrical energy but also thermal energy is required, the integration of a CHP-unit is advisable. In particular, the “ecopower Mini-BHKW” type is supported by the Sunny Island.

Although the relay K1 is used for the switching of a dump load in this configuration, the K1 related parameters 710 to 715 are still used to define the conditions for the request of electrical energy from the CHP, as it is known from “Type 1” generators.

A connection scheme can be found in Chapters 3.4.11 and 3.4.12.

13 Technical Data

Power unit

AC output power (30 min @ $T_u = 25\text{ °C}$)	$P_{AC, 30}$	4500 VA ^{*3}
Continuous output power ($T_u = 25\text{ °C}$):	P_{nom}	3700 VA
Continuous output power:	P_{nom}	3300 VA
Max. efficiency:	η_{max}	$\geq 90\%$

Voltages, currents

Nominal battery voltage:	$V_{Bat, nom}$	60 V = (48 V =)
Battery voltage range:	V_{Bat}	41 V ... 81 V =
Nominal battery current:	$I_{Bat nom}$	60 A = (75 A =)
Max. battery current:	$I_{Bat max}$	125 A =
Nominal AC voltage:	V_{ACnom}	230 V ~
AC voltage range:	V_{AC}	200 V ... 260 V ~
ext. AC voltage range:	$V_{AC, ext}$	150 V ... 260 V ~
AC nominal current:	I_{ACnom}	16 A _{eff}
Nominal frequency:	f_{nom}	50 Hz or 60 Hz
Frequency range:	f	48 Hz ... 62 Hz

^{*3} typical value for $V_{bat} > 60\text{ V}$, see Chapter 2.1.4

Harmonic distortion in output voltage:	$K_{VAC} < 3 \%$ (with $K_{Ugrid} < 2 \%$, $P_{AC} > 0.5 P_{ACnom}$)
Overload capacity:	as described in Chapter 2.1.4
Switching time grid/inverter operation:	
active:	approx. 0 sec.
passive:	approx. 1 sec.
droop-mode:	0 sec.
Voltage ripple:	$V_{pp} < 5 \%$
Pole confusion prevention:	none
Short-circuit proof:	on grid side due to current control
Phase differential factor:	$\cos \varphi = 1$
EMC:	EN 50081-1 EN 55022 / class B (EN 50081-1) EN 55011/ class B
Grid interference:	EN 55014-1
Test voltage:	1,5 kV ~ (AC vs. PE) 1,5 kV ~ (AC vs. DC) 700 V = (DC vs. PE)

Certification

CE Declaration of Conformity:	yes
-------------------------------	-----

Protection degree

Protection degree acc. to IEC 60529:	IP20
--------------------------------------	------

Dimensions and weight

Dimensions (width x height x depth): 510 x 560 x 270 mm

Weight: approx. 45 kg

Ambient conditions

Ambient temperature range (permissible): -25 °C to +45 °C

Relative humidity (permissible): 0 ... 93 %, non-condensing

Limit curves of relays (accessories)




Fig. 13.1: Limit curves of relays

14 Servicing and Maintenance

The Sunny Island was designed as a robust device which requires extremely little servicing. A few standard servicing tasks have to be fulfilled which can be easily combined with servicing of other components in the island grid (lead storage battery, diesel generator etc.).

Device batteries

The inverter only puts a load on the three LR6 (AA, round) batteries in the terminal area of the Sunny Island if it is not in operation, i. e. it is supplied neither by the lead storage battery nor by the AC grid. If not under load the batteries have to be exchanged every five years only. Only replace them with alkaline cells of equal quality. For environmentally friendly disposal of used cells follow the instructions of the local authorities.

In case of increased ambient temperatures and frequent long-term switch-off of the Sunny Island it may be necessary to exchange the batteries approximately every six months. Please also follow the battery manufacturer's instructions!



In normal operation the batteries are not urgently required for Sunny Island operation. In case of a failure, however, important data can be lost without the batteries. These data could otherwise help you considerably in finding the cause of the failure. Keep in mind that warranty may be restricted in certain cases if data is lost due to improper servicing of the batteries.

Connections

Annually check the incoming cables including the terminal area of the Sunny Island for any visible damage and loosened mechanical connections. Apart from visual inspections, any intervention in the terminal area always has to be performed by a qualified technician (see safety instructions in Chapter 1.3)!

If any incoming cables are damaged the Sunny Island has to be disconnected from all power supply units. The failures then have to be repaired by a qualified electrician.

Enclosure

Check the enclosure of the Sunny Island for mechanical integrity. Should there be any damages reducing the Sunny Island's operating safety (cracks, holes, fissures, missing covers) the Sunny Island has to be decommissioned immediately!

Large dirt particles should be removed from the device with a soft hand brush or a similar tool. Fine dust can be wiped off the enclosure parts with a soft moistened cloth. Cleaning agents containing solvents or abrasives should not be used to avoid scratching the paint layer.

The Sunny Island has lateral ventilation grates. These should be kept clear of dust and other deposits to ensure reliable and powerful operation. These grates can be best cleaned with soft brushes. During cleaning make sure to keep dust from entering the inverter. Cleaning intervals depend on local conditions as well as the operating mode of the Sunny Island and are to be determined in an inspection which first should be made every three months.

User interface, display

The user interface can best be cleaned with a soft moistened cloth. Cleaning agents containing solvents or abrasives may not be used!



Avoid unintentionally touching the membrane keys during cleaning which could trigger unwanted functions! Either clean the membrane keyboard while the device is switched off or make sure password protection is activated (level: 0, see Chapter 8.2).

Function

Regularly check whether there are any failures which have to be confirmed as described in Chapter 10. If you do not find a plausible explanation for a failure, have the island grid examined by a qualified technician. Especially in the first months after commissioning of the island grid we recommend to check the inverter in short intervals (monthly or even weekly). This can help you detect hidden faults in installation or configuration.

Spot-check and evaluate the entries in the menu branch "DIAG" (0-4). In case of any inconsistencies have a qualified technician upgrade configuration of your island system. We recommend to check and evaluate the entries very frequently in the first months after commissioning.

Parameters

As long as the layout of the island grid is not changed it is not necessary to adjust the device parameters over time. The Sunny Island is capable of automatically taking into account deviations which e. g. may be caused by ageing of the battery. Parameter "538_lloss nom" is an exception as it should be adjusted to the (estimated) ageing state of the battery from time to time as described in Chapter 16.

To make sure the control functions based on system time are performed correctly and status and error messages are assigned the correct time of occurrence you should check the system time from time to time and adjust it if required.

15 Warranty and Liability Regulations

Warranty

You have acquired a product which was subjected to an careful inspection before dispatch. The statutory warranty period is **24 months** from the date of purchase by the end user. It covers defects based on faulty manufacturing, material or processing of the device. Should your inverter show a defect or malfunction within the warranty period please contact your distributor or installer.

In addition SMA grants a six-month warranty for repairs or compensation deliveries. This six-month period applies in case the original warranty period expires in the meantime.

Evidence

SMA will only render warranty services if the rejected device is returned to SMA together with a copy of the invoice the distributor has issued to the consumer. The type plate at the device must be fully legible. In case of non-fulfillment SMA reserves the right to refuse warranty services free of charge.

Conditions

SMA will decide whether it will repair the device in its works without invoicing material and labor costs or deliver a replacement device.

The rejected device is to be returned to SMA in the original packing or in a transport packing of equal quality free of charge.

The customer has to grant SMA the necessary time and opportunity to repair the defects.

Exclusion of Liability

The above rights held by the customer and any liability by SMA are excluded in case of damages due to

- transportation damages,
- improper installation or commissioning,
- improper alterations, modification or repairing attempts,
- inappropriate use or operation,
- insufficient air supply to the device,
- non-compliance with relevant safety regulations (VDE etc.),
- non-fulfillment of maintenance instructions if applicable,
- force majeure (e. g. lightning, over-voltage, storm, fire).

Any liability in case of more extensive damage claims is excluded if not compelling as stated by law.

We do not guarantee that the software is completely free of failures. In case of a failure an instruction how to avoid the effects of the fault is also considered as sufficient repair. Only the customer is responsible for the correct selection, orderly use, supervision and the results of the use of software.

SMA reserves the right to make alterations serving the improvement of the device.

16 Parameters (Overview)

The system parameters can only be displayed and changed after the installer password has been entered. The following overview is meant primarily as a reference list for set-up of parameters via one of the interfaces of the Sunny Island. Therefore the names of parameters are not always exactly the same as those shown on the Sunny Island display. The column "Description" additionally shows the number which has to be transmitted to select the respective setting. The parameter number indicates, in which specific "PARxxx" (3+x) menu the respective parameter can be found.

Parameter number	„PARxxx“ (3+x) –menu
300 ... 399	„PARSYS“ (3+3)
400 ... 499	„PARGRD“ (3+4)
500 ... 599	„PARBAT“ (3+5)
600 ... 699	„PARGEN“ (3+6)
700 ... 799	„PARREL“ (3+7)
800 ... 899	„PARSB“ (3+8)

Table 16.1: Allocation parameter number / menu



General Note: To be sure that the modified parameters will take effect, please follow the steps below:

1. Set any parameter that has to be changed.
2. Select „Store Permanent“ in the „FUNCT“ (2+3) menu (alternatively wait for at least 30 seconds without pressing any buttons).
3. Restart the Sunny Island by selecting “Restart” in the “FUNCT” (2+3) menu (confirm the appearing question “RESTART ?” with <YES> by pressing [**ENTER**]).

For some parameters a simplified proceeding will be sufficient. Some settings even will take effect immediately after pressing [**ENTER**]. In the following parameter list to

each parameter an indication is given which steps have at least to be taken to let a changed setting become operative ((**A**), (**B**), (**C**), ...).

- (**A**): The setting will take effect immediately after pressing [**ENTER**].
- (**A***): The setting will take effect when the charging mode is changed.
- (**B**): The setting will take effect after the Sunny Island has been started. I.e. if the setting was changed while the Sunny Island was running, it has to be stopped and to be started again (in menu “START” (2-1)).
- (**C**): To activate the changed settings, the Slaves have to be restarted (see the “general note” above) and the Master has to be stopped (or to be in standby-mode already) and started again (in menu “START” (2-1)).
- (**D**): To activate the changed settings, Master and Slaves have to be restarted (see the “general note” above).



Parameter changes should always be made in standby mode. Otherwise the corresponding operating values may be changed as well immediately after pressing [ENTER]. Faulty entries cannot be corrected fast enough and may lead to damages in the plant!

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
308_Start-Stop (A)		0	2	1	Can also be set in Menu “START” (2-1), thus, it cannot be found in the PARSYS-Menu 0: Reserved 1: Start: Starts the Sunny Island 2: Stop: Stops the Sunny Island
310_Auto Start (A)		0	255	0	Number of autostart attempts (0: autostart off) within one hour. After one hour the counter will be reset. Autostart means that approx. 10 sec after a switch-off (due to error or the like) the Sunny Island re-starts. In addition, the Sunny Island starts automatically after switching on the DC voltage when the Autostart is activated. ATTENTION! The Sunny Island will execute this number of autostart attempts anew in intervals of one hour. The Sunny Island’s low battery load mode will be deactivated if this parameter is set to 0!(s. Parameter “535_State Stop T” for details)
312_COM1 Proto (D)		0	2	1	Communication protocol COM1: 0: None: interface not in use 1: SMANET: interface based on SMANet protocol 2: SUNNYNET: interface based on SunnyNet protocol For communication to Sunny Boys: set to SUNNYNET
313_COM1 Baud (D)		0	9	6	Baud rate COM1 (bits/s) 2: 1200 5: 9600 6: 19200 For communication to Sunny Boys or Sunny Boy Controls: set to 1200 In three-phase operation all inverters have to be set to 19200!
316_COM2 Proto (D)		0	2	2	Communication protocol COM2: 0: None: interface not in use 1: SMANET: interface based on SMANet protocol 2: SUNNYNET: interface based on SunnyNet protocol For communication to Sunny Boys: set to SUNNYNET

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
317_COM2 Baud (D)		0	9	2	Baud rate COM2 (bits/s) 2: 1200 5: 9600 6: 19200 For communication to Sunny Boys or Sunny Boy Controls: set to 1200.
401_Phase Mode (D)		0	17	0	0: 1Phs_Single: single-phase operation, inverter is the only device 1: 1Phs_Psingle: single-phase parallel operation with one battery per device (grid and generator not possible!) 2: 1Phs_Mstr2: single-phase parallel operation with two devices with one single battery pack, device is master 3: 1Phs_Mstr3: single-phase parallel operation with three devices with one single battery pack, device is master 4: 1Phs_Slv2: single-phase parallel operation with two or three devices with one single battery pack, device is slave 2 5: 1Phs_Slv3: single-phase parallel operation with three devices with one single battery pack, device is slave 3 6: 3Phs_Mstr1Set: three-phase operation, device is master (L1) 7; 3Phs_parallel: three-phase operation in droop-mode (see Chapter 11.7.2 and 11.7.3), device is master (L1) 10: 3Phs_Slv1L2: three-phase operation, device is slave (L2) 11: 3Phs_Slv1L3: three-phase operation, device is slave (L3)
402_Uconv nom (A)	V	200	260	230	Setpoint value of AC voltage which the Sunny Island is to provide in its function as the grid-forming element (RUN_U)
403_Fconv nom (A)	Hz	40	70	50 (60)	Setpoint value of AC frequency which the Sunny Island is to provide in its function as the grid-forming element (RUN_U)
404_Uext nom (A)	V	150	260	230	Nominal AC voltage (RUN_I)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
405_Uext min (A)	V	150	260	200	Lower limit for AC voltage
406_Uext max (A)	V	150	260	255	Upper limit for AC voltage
407_Fext nom (A)	Hz	40	70	50 (60)	Nominal AC frequency, Sunny Island is in “grid-tied” operation (RUN_I), 50 Hz (60 Hz) design This value will be used for limiting the generator’s load, if “604_GenSet Ctrl” is set to F_MAINS or BOTH.
408_Fext min (A)	Hz	40	70	47 (57)	Lower limit for AC frequency, 50 Hz (60 Hz) design
409_Fext max (A)	Hz	40	70	56 (66)	Upper limit for AC frequency, 50 Hz (60 Hz) design
411_lac chrg mx (A)	A	0	16	12	Max. current the Sunny Island may take out of the AC grid in “grid-tied” operation (RUN_I, battery is being charged in the process)
420_DroopFreq (D)	Hz/ P_{nom}	-5	+5	-1,000	If the system’s frequency will differ from the nominal value by this amount, the Sunny Island will feed P_{nom} into the island grid in droop mode (see 2.1.3).
421_DroopVolt (D)	%/ Q_{nom}	-25	+25	-6,000	If the system’s voltage will differ from the nominal value by this amount, the Sunny Island will feed Q_{nom} into the island grid in droop mode (see 2.1.3).
422_Ps2off (D)	kW	0	10	0,00	Relates to two/three Sunny Island in parallel configurations (see Chapter 11.6.1): If the cumulative load on all Sunny Islands falls below this value, the Slave2 Sunny Island will go idle If one of the parameters 422, 423 or 424 is set to a value different from 0.00, all these parameters have to be set to reasonable values.
423_Ps2on3off (D)	kW	0	16	0,00	Relates to two/three Sunny Island in parallel configurations (see Chapter 11.6.1): If the cumulative load on all Sunny Islands falls below this value, the Slave3 Sunny Island will go idle, resp. if it raises above this value, the Slave2 Sunny Island will be activated. If one of the parameters 422, 423 or 424 is set to a value different from 0.00, all these parameters have to be set to reasonable values.

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
424_Ps3on (D)	kW	0	16	0,00	Relates to two/three Sunny Island in parallel configurations (see Chapter 11.6.1): If the cumulative load on all Sunny Islands raises above this value, the Slave3 Sunny Island will be activated If one of the parameters 422, 423 or 424 is set to a value different from 0.00, all these parameters have to be set to reasonable values. In a system where no Slave3 is present, the setting of this parameter should be equal to the setting of "423_Ps2on3off"
425_SlvTimeHyst (D)	s	0	240	0	Relates to two/three Sunny Island in parallel configurations (see Chapter 11.6.1): Delay before a Slave goes idle after a corresponding condition occurred (cf. 422_Ps2off and 423_Ps2on3off)
426_RevCurrent (A)	A	0	200	0	If the current that flows into the grid/generator exceeds this value, it is interpreted as grid/generator failure and the Sunny Island will throw off the grid/generator. This mechanism is only active when "602_GenSet Type" is set to DroopMains or DroopMainsForm and mains is active. 0: Reverse current detection inactive
501_Cbat nom (A)	Ah	100	10000	350	Nominal battery capacity of 10 hours (C10); always enter the value stated by the manufacturer even if the battery has already aged!
502_Bat Type (A)		0	2	2	Battery type as stated by manufacturer 0: Gel gel 1: Fleece fleece 2: Lead-Acid liquid electrolyte
503_Ubat nom (A)	V	48	60	60	Nominal battery voltage.
504_Ubat min (A)	V	40	70	51	min. battery voltage permissible
505_Ubat max (A)	V	45	84	84	max. battery voltage permissible
506_acid density (A)	kg/l	1,1	1,35	1,24	Nominal acid density according to manufacturer (only taken into account if inverter is started via "New System" or "New Battery" (see Chapter 6))

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
508_Tbat Sense (A)		0	1	1	Battery temperature sensor installed 0: Not installed 1: Installed Automatically set to 1 in single-phase systems or masters in three-phase systems; in all other cases set to 0. Can be set to 1 in slaves if temperature sensors are additionally installed there.
509_Tbat max (A)	degC	30	55	40	Maximum battery temperature permissible
511_Bat Fan (A)		0	1	0	Battery room fan installed (only for lead storage battery with liquid electrolyte) 0: Not installed 1: Installed
512_Acid Pump (A)		0	1	0	Only for lead storage battery with liquid electrolyte: 0: Not installed Electrolyte circulation pump not installed 1: Installed Electrolyte circulation pump installed By selecting “Installed” the electrolyte circulation pump is switched on depending on settings of parameters 513 to 516. Irrespective of battery values, however, there is at least one circulation and 9 circulations maximum per day.
513_Circ time (A)	s	1	3600	300	Run time of electrolyte circulation (per circulation process)
516_Circ Qd (A)	%	0,1	50	10	Electrolyte circulation is triggered as soon as the battery has been charged with the corresponding ampere hours related to its capacity (cumulative).
518_tset full (A)	d	1	180	14	Time period after which full charge is required.
519_tset equal (A)	d	7	365	90	Time period after which equalizing charge is required.
520_U float (A)	V	2,2	2,4	2,25	Float charge voltage per cell
527_tcharge (A*)	min	1	600	90	Charging time for normal charge (for lead-acid batteries, see also “502_Bat Type“)
528_tcharge full (A*)	h	1	20	5	Charging time for full charge (for lead-acid batteries, see also “502_Bat Type“)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
529_tcharge equal (A*)	h	1	48	10	Charging time for equalizing charge (for lead-acid batteries, see also “502_Bat Type”)
530_Ucharge (A*)	V	2,25	2,59	2,54	Charging voltage for normal charge per cell (for lead-acid batteries, see also “502_Bat Type”) The value should be reduced to 2,45 V in case an electrolyte circulation pump is installed. Please follow the instructions of the battery manufacturer.
531_Ucharge full (A*)	V	2,25	2,59	2,5	Charging voltage for full charge per cell (for lead-acid batteries, see also “502_Bat Type”) The value should be reduced to 2,45 V in case an electrolyte circulation pump is installed. Please follow the instructions of the battery manufacturer.
532_Ucharge equal (A*)	V	2,25	2,59	2,45	Charging voltage for equalizing charge per cell (for lead-acid batteries, see also “502_Bat Type”) Please follow the instructions of the battery manufacturer.
533_Stdbyt beg (C)	h	0	23	0	Start of time period when the low battery load mode is permitted (see also “535_Stat StopT”)
534_Stdbyt end (C)	h	0	23	0	End of time period when the low battery load mode is permitted (see also “535_Stat StopT”)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
535_State StopT (C)		0	10	2	<p>In case of deep-cycle discharge the device will switch off to reduce strain on the battery, if no charging current of a minimum of 1 A flows into the battery for more than 5 minutes within the defined time period (see also “533_Stdbyt beg”, „534_Stdbyt end”).</p> <p>The low battery load mode is always activated, when one battery state lower is reached. However from 6 am to 6 pm the Sunny Island attempts to switch on every four hours.</p> <p>Battery state when the low battery load mode is activated:</p> <p>0: L4 1: L3 2: L2 3: L1 4: N4 5: N3 6: N2 7: N1 8: O1 9: O2 10: O3</p>
536_Fan on del (A)	min	0	1440	1	<p>Delay of switch-on for battery room fan</p> <p>In order to use this setting, “511_Bat Fan” must be set to “Installed”</p>
537_Fan off del (A)	min	0	360	60	<p>Delay of switch-off for battery room fan</p> <p>In order to use this setting, “511_Bat Fan” must be set to “Installed”</p>
538_lloss nom (A)	mA /100 Ah	0	-100	-30	<p>Specific leakage current of battery for float charge and 20 °C</p> <p>Approximate values:</p> <p>-30 mA/100Ah for new batteries -80 mA/100Ah for batteries that have considerably aged</p> <p>The value is NOT automatically defined by the Sunny Island. Battery management can therefore be further optimized by manually adjusting the value from time to time.</p>
539_LineResist (A)	mOhms	0	500	0.000	Resistance of the battery (DC) cable

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
601_GenSet Oper (A)		0	3	0	<p>0: Auto: The generator is automatically started and stopped by the Sunny Island.</p> <p>1: Man. Start: The generator is immediately* started.</p> <p>2: Man. Stop: The generator is immediately* stopped.</p> <p>3: Man. Ackn: Waiting times due to failures or parameters are finished.</p> <p>* However, parameterized times are kept to.</p>
602_GenSet Type (A)		0	13	0	<p>0: None: No generator present in island grid</p> <p>1: Grid forming: Generator is grid-forming.</p> <p>3: Mains: Sunny Island is operated on the public utility grid.</p> <p>4: BHKW-Mains Sunny Island is operated together with an ecopower CHP and on the public utility grid</p> <p>5: BHKW-Island Sunny Island is operated together with an ecopower CHP</p> <p>6: Mains form Sunny Island is operated together with a grid-forming generator and on the public utility grid</p> <p>7: fast Grid form Generator is grid-forming and it is switched between the generator and the Sunny Island without interruption (special installation measures are necessary for this)</p> <p>8: fast Mains The Sunny Island is operated on the public utility grid and it is possible to switch from the Sunny Island as grid-former to the public utility grid without interruption. (special installation measures are necessary for this)</p> <p>9: fast Mains form The Sunny Island is operated together with a grid-forming generator and on the public utility grid. Switching takes place without interruption (special installation measure are necessary for this)</p> <p>10: DroopGen The Sunny Island is operated together with a generator capable of droop characteristics in droop mode.</p>

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
					<p>11: DroopMains The Sunny Island is operated together with an utility in droop mode.</p> <p>12: DrpGenMains The Sunny Island is operated together with a generator capable of droop characteristic and an utility in droop mode.</p> <p>13: BHKW-IsI-Therm Sunny Island is operated together with the ecopower CHP. In difference to “BHKW-Island” the Sunny Island will not switch off the CHP when no more electrical power is needed. So the ecopower CHP will be able to provide as much thermal energy as needed</p>
603_GenSet Interf (A)		0	4	0	<p>0: None: generator not controlled by Sunny Island</p> <p>1: Type 1: autostart, relays K1+K2</p> <p>2: Type 2: 3 contacts run / start, relays K1, K2, K6</p> <p>3: Type 3: 3 contacts start / stop, relays K1, K2, K6</p> <p>4: EcoPower Ecopower CHP</p> <p>(see also Fig. 12.1: Starting phase sequence for different generator types)</p>
604_GenSet Ctrl (C)		0	3	0	<p>The Sunny Island reduces its current input in charge operation (RUN_I)</p> <p>0: OFF: ... not at all</p> <p>1: F_MAINS: ... as a function of generator frequency (see “407_Fext nom”)</p> <p>2: I_GEN: ... as a function of generator current (converter required, see Chapter 3.4.5)</p> <p>3: BOTH: ... as a function of generator frequency (see “407_Fext nom”) and current (converter required, see Chapter 3.4.5)</p>
605_GenStRetr (C)		1	30	3	Max. number of attempts to start the generator, before the state “Fail Locked” is reached (see also parameter 618). After the minimum run-time of the generator has expired, the counter will be reset.
606_CurTrfRatio (A)	Ain/5 Aout	1	1000	5	Current transformer ratio (in A per 5 A) for measurement of generator current

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
607_lgen max (A)	A	0	500	0	Max. generator current (per phase), only applies if “604_GenSet Ctrl” is set accordingly
608_tGen switch (D)	msec	-40	+40	-10	Time to compensate the tripping time of the Sunny Island’s contactor (SIBPRETR). The optimized value will NOT exactly equal the tripping time of the contactor!
610_tGen glow (C)	s	1	180	15	Length of time the relay is controlled to glow up the generator
611_tGen crank (C)	s	1	60	10	Length of time the relay is controlled to crank the generator
612_tGen warm (C)	s	1	900	15	Warm-up time of generator
613_tGen minrun (C)	min	1	180	5	Minimum run time of generator
614_tGen cool (C)	s	0	900	60	Cooling time of generator
615_tGen stop (C)	s	1	900	10	Length of time the relay is controlled to stop the generator
616_tGen lock (C)	min	1	180	5	Period of time the generator – after having been stopp-d – cannot be restarted via the Sunny Island (can be shortened by confirmation in the “GENSET” (2-2) menu)
617_tGen fail (C)	min	1	180	5	Period of time the generator cannot be restarted via the Sunny Island after a generator failure (can be shortened by confirmation in the “GENSET” (2-2) menu)
618_tGen faillock (C)	h	1	168	6	Period of time the generator cannot be restarted via the Sunny Island after a certain number of failures as defined in “605_GenStRetr” has occurred during start-up (can be shortened by confirmation in the “GENSET” (2-2) menu)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
625_PIdL GenOn (A)	%	-100	100	0	Switch-on threshold in % of the nominal power at one phase for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”. These settings should only be used for single phase systems with one Sunny Island per battery. 0: Load-dependent generator activation is inactive
626_PIdL GenOff (A)	%	-100	100	0	Switch-off threshold in % of the nominal power at one phase for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”. These settings should only be used for single phase systems with one Sunny Island per battery. 0: Load-dependent generator activation is inactive
627_PIdS GenOn (A)	%	-100	100	0	Switch-on threshold in % of the nominal power based on the cumulative power within the three-phase system for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”. These settings should be used for systems with more than one Sunny Island per battery. 0: Load-dependent generator activation is inactive
628_PIdS GenOff (A)	%	-100	100	0	Switch-off threshold in % of the nominal power based on the cumulative power within the three-phase system for the power-related generator start or the power-related relays (only K5 or K6). If the relays shall be switched in relation to the power, the parameters “705_Man K5” and/or “706_Man K6” must be set to “LOAD”. These settings should be used for systems with more than one Sunny Island per battery. 0: Load-dependent generator activation is inactive
629_TavgLdLx (A)	Sec	5	60	10	Averaging time for the power calculation per phase (see also “625_PIdL GenOn” and “626_PIdL GenOff”)
630_TavgLdSum (A)	Min	1	20	1	Averaging time for the calculation of the cumulative power within the three-phase system (see also “627_PIdS GenOn” and “628_PIdS GenOff”)
631_PIdLzMin (A)	%	0	100	60	Lower limit for the charging state, when the Eco-power CHP will always be started
632_PIdLzMax (A)	%	0	100	85	Upper limit for the charging state, when the Eco-power CHP will never be started

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
633_PConsMin (A)	W	0	2000	1000	Lower limit for the load power (cumulative power averaged over all three phases within the time period of the parameter “630_TavgLdSum”), that has to be exceeded, in order to start the Ecopower CHP even in the case of charging states between “631_PldLzMin” and “632_PldLzMax”.
634_PConsMax (A)	W	0	10000	3000	Upper limit for the load power (cumulative power averaged over all three phases within the time period of the parameter), when the Ecopower CHP will already be started in the case of a charging state of “632_PldLzMax”.
635_PChargeMax (A)	W	0	16000	3000	Setpoint for the charging power, that the Sunny Island obtains from the Ecopower CHP.
636_PDump1 (A)	W	0	8000	500	Power of Dumpload 1, that has to be connected to the relay K1 of the Sunny Island during the operation with the Ecopower CHP. (“701_Man K1” = Auto)
637_PDump2 (A)	W	0	8000	2000	Power of Dumpload 2, that has to be connected to the relay K6 of the Sunny Island during the operation with the Ecopower CHP. (“706_Man K6” = Auto)
638_PBHKWMin (A)	W	0	4000	2200	Minimum power of the Ecopower CHP
639_PBHKWMax (A)	W	0	10000	4700	Maximum power of the Ecopower CHP
640_BHKW_ton (A)	s	0	10000	300	Minimum run-time of the ecopower CHP
641_BHKW_toff (A)	s	0	10000	300	Minimum pause time of the ecopower CHP
642_BHKW_tmax (A)	s	0	20000	0	Maximum run-time of the ecopower CHP in mode 2 (fast control) 0: No limitation
644_PldOnLx (A)	W	0	4700	0	The ecopower CHP will be activated when this load has been exceeded on one of the phases 0: No load dependent activation
645_RevPower (A)	kW	-100	100	-0,5	Generator reverse power protection: If the power delivered by the generator falls below this value, the generator will be disconnected
646_PDump3 (A)	W	0	8000	4500	Power of Dumpload 3, that has to be connected to the relay K2 of the Sunny Island during the operation with the Ecopower CHP. (“702_Man K2” = Auto)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
647_ClustMode (D)		Off	0	3	0: Off: No special function is assigned to this Sunny Island 1: SupMstr: Sunny Island is the “Super Master” that is in charge of controlling the other clusters in the system and the generator, where applicable. 2: ClstMstr: Sunny Island is the Master of a secondary cluster in the system that is controlled by a “Super Master” 3: Reprtr: Sunny Island is the Slave to which COM2 port another cluster is connected
701_Man K1 (A)		0	2	0	Operating mode of relay K1 0: OFF: Switch relay K1 off 1: ON: Switch relay K1 on 2: AUTO: Sunny Island automatically controls relay K1.
702_Man K2 (A)		0	2	0	Operating mode of relay K2 0: OFF: Switch relay K2 off 1: ON: Switch relay K2 on 2: AUTO: Sunny Island automatically controls relay K2.
703_Man K3 (A)		0	2	0	Operating mode of relay K3 0: OFF: Switch relay K3 off 1: ON: Switch relay K3 on 2: AUTO: Sunny Island automatically controls relay K3.
704_Man K4 (A)		0	2	0	Operating mode of relay K4 0: OFF: Switch relay K4 off 1: ON: Switch relay K4 on 2: AUTO: Sunny Island automatically controls relay K4.

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
705_Man K5 (A)		0	9	0	<p>Operating mode of relay K5</p> <p>0: OFF: Switch relay K5 off</p> <p>1: ON: Switch relay K5 on</p> <p>2: AUTO: Sunny Island automatically controls relay K5.</p> <p>3: RUN: Relay is only switched on when the Sunny Island operates.</p> <p>4: RUN_U: Relay is only switched on when the Sunny Island operates as the grid-forming element.</p> <p>5: RUN_I: Relay is only switched on when the Sunny Island is in “grid-tied operation”.</p> <p>6: SYNC_HD: Relay is switched during transfer from grid-forming to grid-tied operation.</p> <p>7: SYNC_TK: Relay is switched during transfer from grid-tied to grid-forming operation.</p> <p>8: SYNC_HDTK: Relay is switched during any transfer from grid-tied to grid-forming operation or vice versa.</p> <p>9: Reserved:</p> <p>10: LOAD: Relay is switched in relation to load (see also parameter 625 to 630)</p>
706_Man K6 (A)		0	10	0	<p>Operating mode of relay K6</p> <p>0: OFF: Switch relay K6 off</p> <p>1: ON: Switch relay K6 on</p> <p>2: AUTO: Sunny Island automatically controls relay K6.</p> <p>3: RUN: Relay is only switched on when the Sunny Island operates.</p> <p>4: RUN_U: Relay is only switched on when the Sunny Island operates as the grid-forming element.</p> <p>5: RUN_I: Relay is only switched on when the Sunny Island is in “grid-tied operation”.</p> <p>6: SYNC_HD: Relay is switched during transfer from grid-forming to grid-tied operation.</p> <p>7: SYNC_TK: Relay is switched during transfer from grid-tied to grid-forming</p>

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
					operation. 8: SYNC_HDTK: Relay is switched during any transfer from grid-tied to grid-forming operation or vice versa. 9: Reserved: 10: LOAD: Relay is switched in relation to load (see also parameter 625 to 630)
707_Man K7 (A)		0	2	0	Operating mode of relay K7 0: OFF: Switch relay K7 off 1: ON: Switch relay K7 on 2: AUTO: Sunny Island automatically controls relay K7.
708_Man K8 (A)		0	2	0	Operating mode of relay K8 0: OFF: Switch relay K8 off 1: ON: Switch relay K8 on 2: AUTO: Sunny Island automatically controls relay K8.
710_K1 t2 begin (C)	h	0	23	0	Start of special period t2 for K1
711_K1 t2 end (C)	h	0	23	0	End of special period t2 for K1
712_K1 On t1 (D)		0	10	4	When this battery state is reached, K1 is switched on. 0: L4 deep-cycle discharge 1: L3 2: L2 3: L1 4: N4 5: N3 6: N2 7: N1 Battery full 8: O1 Overcharge 9: O2 10: O3

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
713_K1 Off t1 (D)		0	10	7	When this battery state is reached, K1 is switched off. 0: L4 deep-cycle discharge 1: L3 2: L2 3: L1 4: N4 5: N3 6: N2 7: N1 Battery full 8: O1 Overcharge 9: O2 10: O3
714_K1 On t2 (D)		0	10	3	Switch-on threshold for K1 in special period t2 (see 712)
715_K1 Off t2 (D)		0	10	7	Switch-off threshold for K1 in special period t2 (see 713)
716_K2 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K2 (see 710)
717_K2 t2 end (C)	h	0	23	0	End of special period t2 for K2 (see 711)
718_K2 On t1 (D)		0	10	5	Switch-on threshold for K2 (see 712)
719_K2 Off t1 (D)		0	10	5	Switch-off threshold for K2 (see 713)
720_K2 On t2 (D)		0	10	5	Switch-on threshold for K2 in special period t2 (see 714)
721_K2 Off t2 (D)		0	10	5	Switch-off threshold for K2 in special period t2 (see 715)
722_K3 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K3 (see 710)
723_K3 t2 end (C)	h	0	23	0	End of special period t2 for K3 (see 711)
724_K3 On t1 (D)		0	10	5	Switch-on threshold for K3 (see 712)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
725_K3 Off t1 (D)		0	10	5	Switch-off threshold for K3 (see 713)
726_K3 On t2 (D)		0	10	5	Switch-on threshold for K3 in special period t2 (see 714)
727_K3 Off t2 (D)		0	10	5	Switch-off threshold for K3 in special period t2 (see 715)
728_K4 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K4 (see 710)
729_K4 t2 end (C)	h	0	23	0	End of special period t2 for K4 (see 711)
730_K4 On t1 (D)		0	10	5	Switch-on threshold for K4 (see 712)
731_K4 Off t1 (D)		0	10	5	Switch-off threshold for K4 (see 713)
732_K4 On t2 (D)		0	10	5	Switch-on threshold for K4 in special period t2 (see 714)
733_K4 Off t2 (D)		0	10	5	Switch-off threshold for K4 in special period t2 (see 715)
734_K5 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K5 (see 710)
735_K5 t2 end (C)	h	0	23	0	End of special period t2 for K5 (see 711)
736_K5 On t1 (D)		0	10	5	Switch-on threshold for K5 (see 712)
737_K5 Off t1 (D)		0	10	5	Switch-off threshold for K5 (see 713)
738_K5 On t2 (D)		0	10	5	Switch-on threshold for K5 in special period t2 (see 714)
739_K5 Off t2 (D)		0	10	5	Switch-off threshold for K5 in special period t2 (see 715)
740_K6 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K6 (see 710)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
741_K6 t2 end (C)	h	0	23	0	End of special period t2 for K6 (see 711)
742_K6 On t1 (D)		0	10	5	Switch-on threshold for K6 (see 712)
743_K6 Off t1 (D)		0	10	5	Switch-off threshold for K6 (see 713)
744_K6 On t2 (D)		0	10	5	Switch-on threshold for K6 in special period t2 (see 714)
745_K6 Off t2 (D)		0	10	5	Switch-off threshold for K6 in special period t2 (see 715)
746_K7 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K7 (see 710)
747_K7 t2 end (C)	h	0	23	0	End of special period t2 for K7 (see 711)
748_K7 On t1 (D)		0	10	5	Switch-on threshold for K7 (see 712)
749_K7 Off t1 (D)		0	10	5	Switch-off threshold for K7 (see 713)
750_K7 On t2 (D)		0	10	5	Switch-on threshold for K7 in special period t2 (see 714)
751_K7 Off t2 (D)		0	10	5	Switch-off threshold for K7 in special period t2 (see 715)
752_K8 t2 begin (C)	h	0	23	0	Beginning of special period t2 for K8 (see 710)
753_K8 t2 end (C)	h	0	23	0	End of special period t2 for K8 (see 711)
754_K8 On t1 (D)		0	10	5	Switch-on threshold for K8 (see 712)
755_K8 Off t1 (D)		0	10	5	Switch-off threshold for K8 (see 713)
756_K8 On t2 (D)		0	10	5	Switch-on threshold for K8 in special period t2 (see 714)

„PARALL“ (3+9)					
Parameter	Unit	Min.	Max.	Default	Description
757_K8 Off t2 (D)		0	10	5	Switch-off threshold for K8 in special period t2 (see 715)
801_Sunny Boys (A)		0	3	0	0: Not installed: Sunny Island is not to control Sunny Boys. 1: Installed: Sunny Island is to control Sunny Boys (via COM2) 2: Inst. Mains: Sunny Island only is to control Sunny Boys if grid feeding is not possible (via COM2) 3: Frequency Sunny Island controls the Sunny Boys via grid frequency (This mode is only possible when the Sunny Boys are equipped with an advanced firmware) in RUN_U

17 Measured Values Displayed (Overview)

Name	Unit	Min.	Max.	Default	Description
“DATSYS” (1-1)					
SN:					Serial number
Vers:					Firmware versions of BFR and DSP
UP:	h	0.0			Operating hour meter

Name	Unit	Min.	Max.	Default	Description
“DATALL” (1-2), Passwort-Level: 1					
Mode		0	13	0	Current operating state 0: - - - - - Initialization 1: INIT Initialization 2: STANDBY Waiting state 3: SLAVE Slave mode (three-phase operation) 4: STARTUP Start 5: RUN_U Inverter operation (island grid) 6: RUN_UEXT Generator operated with droop characteristics 7: RUN_I Charging operation on grid or generator 8: GEN_MANU man. start of generator detected 9: SYNC_HD Transfer from RUN_U to RUN_I 10: SYNC_TK Transfer from RUN_I to RUN_U 11: SHUTDOWN Shutdown 12: ERRSHDWN Shutdown due to error 13: Disturbance Fault state
Batt. Ah In	Ah	0	0	0	Ah into the battery
Batt. Ah Out	Ah	0	0	0	Ah out of the battery
E_Total_In	kWh	0	0	0	Input power AC side
E_Total	kWh	0	0	0	Output power AC-side
Energy Count	h	0	0	0	Run-time of energy counter
h-Total	h				Time since switch-on (“Up-Time”)
Pconv Sum	kW	-320	320	0	Sum of grid active power SI (three phases)
Qconv Sum	kvar	-320	320	0	Sum of grid reactive power SI (three phases)
Sconv Sum	kVA	-320	320	0	Sum of grid apparent power SI (three phases)
Iconv Sum	A	0	640	0	Inverter current (three phases)
Pext Sum	kW	-320	320	0	Sum of generator active power (three phases)

Name	Unit	Min.	Max.	Default	Description
					If an "ecopower Mini-BHKW" is installed, this equals the sum of the Sunny Island's power and the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
Pext L1	kW	-320	320	0	Generator active power phase 1
Pext L2	kW	-320	320	0	Generator active power at phase 2
Pext L3	kW	-320	320	0	Generator active power at phase 3
Iext Sum	A	0	640	0	Sum of generator current (three phases)
Psi L1	kW	-320	320		Grid active power of Sunny Island phase 1
Psi L2	kW	-320	320		Grid active power of Sunny Island phase 2
Psi L3	kW	-320	320		Grid active power of Sunny Island phase 3
Bat State		L4	O3	L1	Current battery state 0: L4 deep-cycle discharge 1: L3 2: L2 3: L1 4: N4 5: N3 6: N2 7: N1 battery full 8: O1 overcharge 9: O2 10: O3
SOC act	%	-100	110	0	Actual battery state of charge
Pbat Sum	W	-32000	32000	0	Sum of battery power SI (three phases)
Ibat Sum	A	-320	320	0	Sum of battery current SI (three phases)
GenState		0	10	0	Generator state 0: none not active 1: off off 2: glow glowing up 3: crank cranking 4: warm warming up 5: run running 6: cool cooling down 7: Stop stopping 8: lock locked after operation 9: fail failure 10: fail_look locked after multiple failure

Name	Unit	Min.	Max.	Default	Description
GenFail		0	6	0	Generator failure state 0: none no failure 1: F_crank failure during cranking 2: F_warm failure during warming up 3: F_Run failure in operation 4: F_Runlim limitation violation of generator frequency, voltage or reverse power 5: F_Cool failure during cooling down 6: F_Stop failure during stop (could not be stopped)
K1 State		0	1	0	State of relay 0: off 1: on
K2 State		0	1	0	State of relay
K3 State		0	1	0	State of relay
K4 State		0	1	0	State of relay
K5 State		0	1	0	State of relay
K6 State		0	1	0	State of relay
K7 State		0	1	0	State of relay
K8 State		0	1	0	State of relay
SB Step	%	-100	100	0	Current step size for Sunny Boy power limitation (via COM2)
Fext	Hz	0	100	0	Current grid frequency on Generator / Mains sync. input
Uext eff	V	0	500	0	RMS value of synchronous voltage
Iext eff	A	0	500	0	Current generator current (from converter)
Pext	kW	-320	320	0	Current generator active power If an "ecopower Mini-BHKW" is installed this equals the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
Ubat mean	V	0	200	0	Mean value of battery voltage
Ibat mean	A	-150	150	0	Mean value of battery current
Pbat mean	W	-32000	32000	0	Mean value of battery power
Tbat mean	degC	-25	125	0	Mean value of battery temperature
Uzw Cuk mean	V	0	500	0	Mean value of the intermediate circuit voltage
Fconv	Hz	0	100	0	Current grid frequency
Uconv eff	V	0	500	0	Current grid voltage actual value
Iconv eff	A	0	320	0	RMS value of grid current
Pconv	W	-32000	32000	0	Grid active power Sunny Island
Sconv	VA	-32000	32000	0	Grid apparent power SI
Qconv	var	-32000	32000	0	Grid reactive power SI
Uchrg act	V	0	200	0	Setpoint value of battery voltage

Name	Unit	Min.	Max.	Default	Description
SOC diff RSK	%	0	100	0	Estimated error of "SOC RSK"
Cbat act	Ah	50	10000	100	Current battery capacity
SOC diff AHB	%	0	100	50	Error of state of charge for full charge calibration
Qdn full	Ah/ 100Ah	-10000	10000	0	Charge throughput (discharge) since last full charge
Qdn equal	Ah/ 100Ah	-10000	10000	0	Charge throughput (discharge) since last equalizing charge
tpast full	d	0	3700	0	Time since last full charge
tpast equal	d	0	3700	0	Time since last equalizing charge
t Uconst chg	h	0	10	0	Time of constant U Phase for normal charges
t Uconst full	h	0	20	0	Time of constant U phase for full charges
t Uconst equal	h				Time of constant U phase for equalizing charges
Qd float	Ah/ 100Ah	-100	0	0	Charge taken out since beginning of float charge
ChargeOper		0	5	1	State of battery management (charging methods) 1: none (required charge voltage for battery management) 2: normal (normal charge) 3: full (full charge) 4: float (float charge) 5: equalize (equalizing charge)
SOC diff	%	0	100	50	Difference of state of charge calculation
SOC AHG	%	-100	110	50	Charge degree for full charge calibration
SOC RSK	%	-100	110	50	Charge degree of module for open-circuit voltage calibration

Name	Unit	Min.	Max.	Default	Description
"DATBAT" (1+3)					
Bat State		0	10	0	Current battery state 0: L4 deep-cycle discharge 1: L3 2: L2 3: L1 4: N4 5: N3 6: N2 7: N1 battery full 8: O1 overcharge 9: O2 10: O3
SOC act	%	-100	110	0	Actual battery state of charge
Ubat mean	V	0	200	0	Mean value of battery voltage

Name	Unit	Min.	Max.	Default	Description
Uchrg act	V	0	200	0	Setpoint value of battery voltage
Ibat mean	A	-150	150	0	Mean value of battery current
Ibat Sum	A	-320	320	0	Sum of battery current SI (three phases)
Tbat mean	degC	-25	125	0	Battery temperature mean value
Pbat mean	W	-32000	32000	0	Battery power mean value
Pbat Sum	W	-32000	32000	0	Sum of battery power SI (three phases)
SOC RSK	%	-100	110	50	State of charge of module for open-circuit voltage calibration
SOC diff RSK	%	0	100	50	Error SOC for open-circuit voltage calibration
Cbat act	Ah	50	10000	100	Current capacity
Qdn full	Ah/ 100Ah	-10000	10000	0	Charge throughput (discharge) since last full charge
Qdn equal	Ah/ 100Ah	-10000	10000	0	Charge throughput (discharge) since last equalizing charge
tpast full	d	0	3700	0	Time since last full charge
tpast equal	d	0	3700	0	Time since last equalizing charge
t Uconst chg	h	0	10	0	Time of constant U phase for normal charges
t Uconst full	h	0	20	0	Time of constant U phase for full charges
t Uconst equal	h	0	40	0	Time of constant U phase for equalizing charges
ChargeOper		0	5	1	State of battery management (charging method) 1: none (required charge voltage for battery management) 2: normal (normal charge) 3: full (full charge) 4: float (float charge) 5: equalize (equalizing charge)
SOC AHB	%	0		0	State of charge for full charge calibration

Name	Unit	Min.	Max.	Default	Description
“DATGRD” (1+4)					
Uconv eff	V	0	500	0	Current grid voltage actual value
Fconv	Hz	0	100	0	Current grid frequency
Iconv eff	A	0	320	0	Averaged grid current
Iconv Sum	A	0	640	0	Inverter current (three phases)
Pconv	W	-32000	32000	0	Grid active power Sunny Island
Pconv Sum	kW	-320	320	0	Sum of grid active power SI (three phases)
Qconv	var	-32000	32000	0	Grid reactive power SI
Qconv Sum	kvar	-320	320	0	Sum of grid reactive power SI (three phases)

Name	Unit	Min.	Max.	Default	Description
Sconv	VA	-32000	32000	0	Grid apparent power SI
Sconv Sum	kVA	-320	320	0	Sum of grid apparent power SI (three phases)
Uext eff	V	0	500	0	RMS value of synchronous voltage
Fext	Hz	0	100	0	Current grid frequency on synchronous input
Iext eff	A	0	500	0	Current generator current (of converter)
Iext Sum	A	0	640	0	Sum of generator current (three phases)
Pext	kW	-320	320	0	Current generator active power If an "ecopower Mini-BHKW" is installed, this equals the power of the CHP unit, as received from by the Sunny Island on its COM3 port.
Pext Sum	kW	-320	320	0	Sum of generator active power (three phases) If an "ecopower Mini-BHKW" is installed, this equals the sum of the Sunny Island's power and the power of the CHP unit, as received from by the Sunny Island on its COM3 port.

18 Error and Status Signals

The following list provides an overview of possible error and status signals of the Sunny Island. These are e. g. used in the menu branch “DIAG“. In case of an acute error the signal is also directly shown on the display for a short time.

The status signals are meant to provide information on the status the plant is in. They also allow optimum configuration of system settings.

If error signals are shown on the display repeatedly without any apparent reason (such as an operating error), please write down the error signal and contact the manufacturer (see Chapter 20).

18.1 Error Signals

Nr.	Ackn	Display	Reason
A0001, A0002		Internal Error	Invalid adjustment data
A0003	x	Internal Error	Error during hardware test
A0004		Internal Error	Watchdog Reset
A0005	x	Internal Error	Error during start-up
A0006	x	Internal Error	Invalid data in data flash
A0007- A0011		Internal Error	Violation of plausibility limit values
A0012	x	Internal Error	Error in control system
A0013- A0022	x	Internal Error	Exceeding of limit values (DC side)
A0023- A0031	x	Internal Error	Exceeding of limit values (AC side)
A0032- A0037		Internal Error	Violation of plausibility limits of internal measured values
A0038	x	Internal Error	DSP timeout
A0039		Overtemp Battery	Battery temperature rise (parameter)

Nr.	Ackn	Display	Reason
A0040	x	Battery Low	Battery state under limit value L4 or parameter
A0041		Battery Temp Sense fail	Battery temperature sensor fails (break, short-circuit)
A0042		Battery Voltage Low	Undervoltage of battery
A0043		Battery Voltage High	Overvoltage of battery
A0044		High Grid Volt	Overvoltage in the grid (parameter or fixed DSP limits)
A0045		Low Grid Volt	Undervoltage in the grid (parameter or fixed DSP limits)
A0046		High Grid Freq	Overfrequency in the grid (parameter or fixed DSP limits)
A0047		Low Grid Freq	Underfrequency in the grid (parameter or fixed DSP limits)
A0048	x	Unexp Grid State	Unexpected grid voltage/frequency at the inverter input port
A0049	x	Contactor or Fuse	Failure of grid relay or fuse
A0050	x	Sync error	Switching of operating mode failed
A0051		Genset start failed	Generator start failed
A0052		Genset reverse power	Energy was refed into the generator
A0053		Sync signal failed	DSP Sync signal failed
A0054		SI Communication error	Communication error in interconnection mode (COM1)
A0055		Slave Errors	One of the slaves announces error

Table 18.1: Error signals

18.2 Status Signals (“Events“)

Nr.	Signal	Description
E0001	Reset	Restart of system
E0002	Set Date/Time	Date/time set
E0003	Inval EE SIH	Invalid adjustment data detected – device uses defaults
E0004	Inval EE CNV	Invalid adjustment data detected – device uses defaults
E0005	Inval EE CUK	Invalid adjustment data detected – device uses defaults
E0006	Parameter Default	Parameters set to defaults
E0007	BMS: New System	Restart of battery management via “New System“, the automatically adapted internal values of the battery characteristics have been reset
E0008	BMS: New Battery	Restart of battery management via “New Battery“, the automatically adapted internal values of the battery characteristics have been reset
E0009	BMS: Restart	Restart, the battery management keeps on working with the present internal values for the battery characteristics
E0012	SYSINIT	Initial state
E0014	STANDBY	Operating state STANDBY
E0015	SLAVE	Device was reconfigured as slave
E0016	STARTUP	Start-up process
E0017	RUN_U	Grid-forming operation
E0018	RUN_UDRP	“Droop mode” operation
E0019	RUN_I	Grid-tied operation
E0020	GEN_MANU	Running generator detected during start-up
E0021	SYNC_HD	Transfer from RUN_U to RUN_I
E0022	SYNC_TK	Transfer from RUN_I to RUN_U
E0023	SHUTDOWN	Transfer to STANDBY
E0024	ERRSHDWN	Transfer to STANDBY due to failure
E0026	FAULT	Failure state
E0027	Bat L4	Battery state L4 has been reached
E0028	Bat L3	Battery state L3 has been reached
E0029	Bat L2	Battery state L2 has been reached
E0030	Bat L1	Battery state L1 has been reached
E0031	Bat N4	Battery state N4 has been reached
E0032	Bat N3	Battery state N3 has been reached
E0033	Bat N2	Battery state N2 has been reached

Nr.	Signal	Description
E0034	Bat N1	Battery state N1 has been reached
E0035	Bat O1	Battery state O1 has been reached
E0036	Bat O2	Battery state O2 has been reached
E0037	Bat O3	Battery state O3 has been reached
E0038	K1 ON	Relay K1 switched on
E0039	K1 OFF	Relay K1 switched off
E0040	K2 ON	Relay K2 switched on
E0041	K2 OFF	Relay K2 switched off
E0042	K3 ON	Relay K3 switched on
E0043	K3 OFF	Relay K3 switched off
E0044	K4 ON	Relay K4 switched on
E0045	K4 OFF	Relay K4 switched off
E0046	K5 ON	Relay K5 switched on
E0047	K5 OFF	Relay K5 switched off
E0048	K6 ON	Relay K6 switched on
E0049	K6 OFF	Relay K6 switched off
E0050	K7 ON	Relay K7 switched on
E0051	K7 OFF	Relay K7 switched off
E0052	K8 ON	Relay K8 switched on
E0053	K8 OFF	Relay K8 switched off
E0054	Frequency increm. ON	Frequency increment active (see Chapter 8.8)
E0055	Frequency increm. OFF	Frequency increment finished
E0056	Frequency decrem. ON	Frequency lowering started (only in special configurations)
E0057	Frequency decrem. OFF	Frequency lowering stopped (only in special configurations)
E0058	SI Autostart	Automatic start of Sunny Island performed
E0059	SI Man Start	Manual start of Sunny Island performed (via menu)
E0060	SI Man Stop	Manual stop of Sunny Island performed (via menu)
E0061	Genset Autostart	Automatic start of generator performed (battery state-controlled)
E0062	Genset Man Start	Manual start of generator performed (via menu)
E0063	Genset Man Stop	Manual stop of generator triggered (via menu) – if required generator will run on until its min. run time has expired.
E0064	Genset Man Ackn	Acknowledgement of failures, overwriting waiting time – as the case may be the generator will be stopped immediately

Nr.	Signal	Description
E0065	SLAVE STANDBY	Sunny Island is slave and has switched to standby.
E0066	SLAVE DCLINK	Sunny Island is slave and has switched to DC-LINK state.
E0067	SLAVE CONV	Sunny Island is slave and has switched to RUN_U mode.
E0068	SLAVE CONVDR	Sunny Island is slave and has switched to droop mode.
E0069	SLAVE CHARGE	Sunny Island is slave and has switched to RUN_I mode.
E0070	SLAVE ERROR	Sunny Island is slave and in failure state.
E0071	SLAVE ACKN	Sunny Island is slave and has received acknowledge.
E0072	Mains Reverse	Reverse current into mains detected
E0073	Low Batt Mode 1	First level of low battery load mode is active
E0074	Low Batt Mode 2	Second level of low battery load mode is active

Table 18.2: Status signals

19 Declaration of Conformity

DECLARATION OF CONFORMITY

for Island Inverters



Product: Sunny Island
Type: SI4500

We declare that the SI4500 complies with the relevant regulations of the European Union, especially the EMC regulation according to 89/336/EEG and the low voltage regulation according to 73/23/EEG. The inverter is therefore marked with a CE sign.

The device especially complies with

DIN EN 50081, part 1
DIN EN 50082, part 1
DIN EN 50178 (04.98) (VDE 0160)
DIN EN 61000-3-2 in charging operation

Niestetal, 3. November 2003

SMA Regelsysteme GmbH

i.V. Mike Meinhardt
(Head of Island Grid Components Development)

INDUSTRIECOMPUTER - SOLARTECHNIK - BAHNTECHNIK

SMA America, Inc. • 12438-C Loma Rica Drive, Grass Valley, CA 95945
Phone 530 - 273 - 4895 • Fax 530 - 274 - 7271
www.SMA-AMERICA.com • E-mail: info@SMA-AMERICA.com

SMA Regelsysteme GmbH • Hannoversche Straße 1-5, D-34266 Niestetal
Tel. (+49) 5 61 95 22 - 0 • Fax (+49) 5 61 95 22 - 100
www.SMA.de • E-mail: info@SMA.de



SI4500CEB4503

20 Contact

SMA Regelsysteme GmbH

Hannoversche Straße 1 – 5

34266 Niestetal

Germany

Tel.: +49 561 95 22 499

Fax: +49 561 95 22 4609

E-mail: hotline@sma.de

Internet: <http://www.sma.de>

21 List of Figures

Fig. 2.1: Sunny Island as grid-forming element.....	16
Fig. 2.2: Sunny Island with external grid-former.....	18
Fig. 2.3: Frequency vs. load characteristics.....	19
Fig. 2.4: Voltage vs. reactive power characteristics	19
Fig. 2.5: Battery states with charging methods	25
Fig. 2.6: Battery states, states of charge and suggested switching operations	26
Fig. 3.1: Mounting bracket with fastening points	36
Fig. 3.2: Side view of the Sunny Island with dimensions	37
Fig. 3.3: Cable glands and terminals of the Sunny Island.....	39
Fig. 3.4: Terminal strip of the Sunny Island	41
Fig. 3.5: Connection of battery to the Sunny Island	46
Fig. 3.6: Connection of a temperature sensor.....	47
Fig. 3.7: AC voltage connection	48
Fig. 3.8: Connection of generator current and voltage measurement.....	49
Fig. 3.9: Power loss due to the secondary circuit to the inverter.....	50
Fig. 3.10: Connection of a (diesel) generator.....	51
Fig. 3.11: Example of connection for an accelerated switch-over (generator)	52
Fig. 3.12: Connection to an external utility	54
Fig. 3.13: Connection for an accelerated switch-over (utility)	55
Fig. 3.14: Connection to generator and utility	57
Fig. 3.15: Example of an accelerated switch-over (generator and utility)	58
Fig. 3.16: Connection of a battery room fan and electrolyte pump	59
Fig. 3.17: Connection of an additional load (“dump load“)	60
Fig. 3.18: Connection to an „ecopower Mini-BHKW“	61

Fig. 3.19: Connection to an „ecopower Mini-BHKW“ and utility	62
Fig. 3.20: Interfaces of the Sunny Island.....	64
Fig. 3.21: Recommended cable for RS485 communication.....	66
Fig. 3.22: Connection of Sunny Boys at Sunny Island's COM2 (RS485).....	68
Fig. 3.23: Connection of Sunny Boys and a Sunny Boy Control at COM2 (RS485) ..	70
Fig. 3.24: Data communication with serial interface.....	72
Fig. 3.25: Communication in a three-phase island grid.....	74
Fig. 4.1: Operation of the Sunny Island.....	75
Fig. 4.2: Menu structure	79
Fig. 5.1: Start-up phase of the Sunny Island.....	81
Fig. 5.2: System message of the Sunny Island.....	81
Fig. 5.3: "INIT" menu (0-0)	82
Fig. 5.4: Status / Menu selection "DATA" (0-1)	82
Fig. 6.1: Display to enter password.....	86
Fig. 6.2: Display to enter password.....	92
Fig. 6.3: Display to enter password.....	95
Fig. 7.1: Menu selection "OPERAT" (0-2)	99
Fig. 7.2: Menu branch "OPERAT" (0-2)	99
Fig. 7.3: Menu "START" (2-1)	100
Fig. 7.4: Menu "GENSET" (2-2)	101
Fig. 7.5: Menu "FUNCT" (2+3)	104
Fig. 7.6: Update information display.....	105
Fig. 7.7: Menu „BHKW“ (2+5)	105
Fig. 8.1: Menu selection "SETUP" (0-3).....	107
Fig. 8.2: Menu branch "SETUP" (0-3)	108
Fig. 8.3: Menu "SETTIM" (3-1)	108

Fig. 8.4: Menu "PASSWD" (3-2).....	109
Fig. 8.5: Menu "PARSYS" (3+3).....	110
Fig. 8.6: Menu "PARGRD" (3+4)	112
Fig. 8.7: Menu "PARBAT" (3+5)	114
Fig. 8.8: Menu "PARGEN" (3+6)	117
Fig. 8.9: Menu "PARREL" (3+7)	121
Fig. 8.10: Switching operations recommended for el. consumers	122
Fig. 8.11: Switching operations recommended for el. feeders	122
Fig. 8.12: Switching behavior when „Kx On tx“ is equal to „Kx Off tx“	123
Fig. 8.13: Switching behavior: Exception	123
Fig. 8.14: Exemplary settings for "special time period t2"	124
Fig. 8.15: Menu "PARSB" (3+8)	128
Fig. 8.16: Menu "PARALL" (3+9)	130
Fig. 9.1: STATUS and menu selection "DATA" (0-1)	131
Fig. 9.2: Menu branch "DATA"	131
Fig. 9.3: STATUS and state of the relay	132
Fig. 9.4: Menu „DATAV“ (1-0)	133
Fig. 9.5: Menu "DATSYS" (1-1)	134
Fig. 9.6: Menu "DATALL" (1-2).....	134
Fig. 9.7: Menu "DATBAT" (1-3)	136
Fig. 9.8: Menu "DATGRD" (1+4)	138
Fig. 10.1: Menu selection "DIAG" (0-4)	140
Fig. 10.2: Menu branch "DIAG"	141
Fig. 10.3: Menu "ACKN" (4-1)	142
Fig. 10.4: Menu "HISTOR" (4-2).....	142
Fig. 10.5: Menu "ERRHIS" (4-3).....	143

Fig. 10.6: Menu “EVTHIS“ (4-4)	143
Fig. 11.1: Sunny Island + PV	147
Fig. 11.2: Sunny Island + PV + Genset.....	151
Fig. 11.3: Sunny Island + Mains + PV	155
Fig. 11.4: Sunny Island + Mains + Generator + PV	158
Fig. 11.5: Sunny Island + CHP + PV	162
Fig. 11.6: Three Sunny Islands, single-phase system w/ data interchange	165
Fig. 11.7: Load-dependent en-/disabling of the additional Sunny Islands.....	166
Fig. 11.8: Two three-phase clusters in parallel w/ data interchange	169
Fig. 11.9: Single-Phase System.....	173
Fig. 11.10: Three-Phase System	173
Fig. 11.11: Three-phase system with backup single phase Sunny Islands.....	174
Fig. 12.1: Starting phase sequence for different generator types	175
Fig. 12.2: Single-phase island system with generator “type 1“ (automatic start)	176
Fig. 12.3: Single-phase island system with generator “type 2“	177
Fig. 12.4: Single-phase island system with generator “type 3“	178
Fig. 12.5: External charging of the battery by an auxiliary generator.....	180
Fig. 13.1: Limit curves of relays	184

22 List of Tables

Table 2.1: Classification of battery states	27
Table 2.2: Battery states and recommended measures	28
Table 3.1: Description of terminal strip.....	42
Table 3.2: Assignment of COM1 (SYNC BUS) interface	65
Table 3.3: Assignment of COM2 interface (RS485 / RS232).....	66
Table 3.4: Assignment of Sunny Island interface (COM3)	73
Table 4.1: Meaning of symbols	76
Table 4.2: Function of keys	76
Table 4.3: Key combination to set up display.....	77
Table 4.4: Key combination for fast return to status display	77
Table 4.5: Contents of the four menu branches.....	80
Table 6.1: Parameters to be entered for configuration via “New Sys MASTER“	90
Table 6.2: Parameters to be entered for configuration via “New Sys SLAVE“	93
Table 6.3: Parameters to be entered for configuration via “New Battery“	96
Table 7.1: Settings for the menu “GENSET“ (2-2)	103
Table 7.2: Settings in the menu „BHKW“ (2+5).....	106
Table 8.1: Settings in menu “PARSYS“ (3+3).....	111
Table 8.2: Settings in menu “PARGRD“ (3+4)	113
Table 8.3: Settings in menu “PARBAT“ (3+5)	116
Table 8.4: Settings in menu “PARGEN“ (3+6)	120
Table 8.5: Special functions of relays	125
Table 8.6: Settings in the menu “PARREL“ (3+7)	127
Table 8.7: Settings in the menu “PARSB“ (3+8)	129
Table 9.1: Spot values shown in “DATA“ (0-1).....	132
Table 9.2: Values shown in „DATAV“ (1-0)	133
Table 9.3: Menu “DATALL“ (1-2), password level: 0.....	135
Table 9.4: Menu “DATBAT“ (1+3)	137
Table 9.5: Menu “DATGRD“ (1+4)	139
Table 10.1: Displayed menu selection “DIAG“ (0-4)	141
Table 18.1: Error signals	218
Table 18.2: Status signals.....	221

INDUSTRIECOMPUTER-SOLARTECHNIK-BAHNTECHNIK



SMA America , Inc., 12438-C, Loma Rica Drive, Grass Valley, CA 95945
Phone 530-273-4895 • Fax 530-274-7271
www.SMA-AMERICA.com • email: info@SMA-AMERICA.com

SMA Regelsysteme GmbH • Hannoversche Straße 1-5, D-34266 Niestetal
Tel. (+49) 5 61 95 22 - 0 • Fax (+49) 5 61 95 22 -100
www.SMA.de • e-mail: info@SMA.de